De'Longhi SGGW 854 N

DeLonghi SGGW 854 N Freestanding Gas Cooker

Instruction Manual

1. Product Overview

The DeLonghi SGGW 854 N is a freestanding gas cooker designed for domestic use. It features a white finish, a gas hob with four burners, and an electric/gas oven. The appliance is controlled via front-mounted rotary knobs. This manual provides essential information for the safe and efficient use of your cooker.



Figure 1: DeLonghi SGGW 854 N Freestanding Gas Cooker. This image shows the appliance with its four gas burners, control knobs, and oven door.

2. Safety Information

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in fire, electric shock, or personal injury.

- **Gas Safety:** Ensure proper ventilation when using gas burners. Do not store flammable materials near the appliance. In case of a gas leak, turn off the gas supply, open windows, and do not operate electrical switches.
- **Electrical Safety:** The appliance must be properly earthed. Do not use extension cords or adapters. Disconnect from power before cleaning or maintenance.
- **Hot Surfaces:** The hob, oven, and surrounding areas become hot during operation. Use oven mitts and keep children away from the appliance.
- **Supervision:** Never leave the appliance unattended during operation.
- **Installation:** Installation must be performed by a qualified technician in accordance with local regulations.

3. Setup and Installation

This appliance is designed for freestanding installation. Ensure adequate space and ventilation around the unit. Installation must be carried out by a qualified professional.

3.1 Unpacking

- Carefully remove all packaging materials.
- Check the appliance for any damage incurred during transit. Report any damage to your retailer immediately.
- Retain packaging materials for future transport or disposal.

3.2 Positioning

- Place the cooker on a stable, level surface.
- Ensure minimum clearances from adjacent walls and furniture as specified in the installation guide (provided separately with the appliance).

3.3 Gas Connection

The gas connection must be performed by a certified gas technician. Ensure the gas type (natural gas or LPG) matches the appliance's specifications. A gas cylinder compartment is provided for LPG models.

3.4 Electrical Connection

Connect the appliance to a properly earthed 230 V AC power supply. The electrical connection should also be performed by a qualified electrician.

4. Operating Instructions

4.1 Gas Hob Operation

1. Place a suitable cooking pot or pan centrally on the burner grid.
2. Push and turn the corresponding control knob counter-clockwise to the maximum flame setting.
3. Press the electronic ignition button (if applicable) or use a match/lighter to ignite the gas.
4. Once ignited, hold the knob for a few seconds to activate the flame supervision device.
5. Adjust the flame size by turning the knob between the maximum and minimum settings.
6. To turn off, turn the knob clockwise to the 'off' position.

The hob features 4 burners and 2 enameled grids for cooking. A central work area is also present.

4.2 Oven Operation (Electric/Gas)

The oven has a total capacity of 40 liters and features both electric and gas functions, including an electric grill.

1. Open the oven door and place food on the appropriate shelf.
2. Select the desired cooking function (gas oven or electric grill) and temperature using the oven control knobs.
3. For gas oven, press the electronic ignition button (if applicable) or use a match/lighter to ignite the gas burner inside the oven. Hold the knob for a few seconds after ignition.
4. Monitor cooking progress through the double inner door glass.
5. To turn off, set the control knob to the 'off' position.

The oven also includes a light shaded crystal lid and an openable compartment for warming food.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and efficient operation of your cooker.

- **Before Cleaning:** Always ensure the appliance is switched off and cooled down. Disconnect from the main power supply.
- **Exterior Cleaning:** Wipe exterior surfaces with a soft cloth and mild detergent. Avoid abrasive cleaners or scouring pads.
- **Hob Cleaning:** Remove burner caps and grids. Wash them in warm soapy water. Clean the hob surface with a damp cloth. Ensure all parts are dry before reassembling.
- **Oven Cleaning:** For light soiling, wipe the interior with a damp cloth. For heavier grease, use a specialized oven cleaner, following the product instructions carefully. The double inner door glass can be cleaned for better visibility.
- **Gas Burners:** Periodically check burner holes for blockages and clean with a brush if necessary.

6. Troubleshooting

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Burner does not ignite.	No gas supply, burner cap/crown incorrectly placed, ignition electrode dirty/wet.	Check gas supply. Re-position burner parts. Clean and dry ignition electrode.
Oven not heating.	Power supply issue, oven control knob not set correctly, gas supply issue (for gas oven).	Check power connection. Ensure knob is set to desired function/temperature. Check gas supply.
Uneven cooking in oven.	Incorrect shelf position, oven door not fully closed, food too close to elements.	Adjust shelf position. Ensure door is sealed. Use appropriate cookware.

If the problem persists after attempting these solutions, please contact a qualified service technician.

7. Specifications

Brand:	De'Longhi
Model Name:	SGGW 854 N
Model Number:	119969
Installation Type:	Freestanding
Color:	White
Control Type:	Rotary Knobs (Front)
Hob Type:	Gas (4 burners)
Oven Type:	Electric/Gas
Total Oven Capacity:	40 Liters (Medium)
Grill Type:	Electric Grill
Material:	Stainless Steel
Dimensions (W x D x H):	86 x 50 x 85 cm
Weight:	54 kg
AC Input Voltage:	230 V
Energy Efficiency Class:	A
Energy Consumption (Conventional):	1.43 kWh

8. Warranty and Support

Specific warranty details for the DeLonghi SGGW 854 N cooker are typically provided with the product at the time of purchase. Please refer to the warranty card or documentation included in the product packaging for terms, conditions, and duration.

For technical support, spare parts, or service inquiries, please contact your local De'Longhi customer service center. Contact information can usually be found on the De'Longhi official website or in the product documentation.

© 2023 De'Longhi. All rights reserved.