Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

THOMAS SABO WA0244-201-201-42 MM

THOMAS SABO Men's Analog Quartz Stainless Steel Wristwatch WA0244-201-201-42 mm User Manual

Model: WA0244-201-201-42 MM

Overview Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

Thank you for choosing the THOMAS SABO WA0244-201-201-42 mm Men's Analog Quartz Stainless Steel Wristwatch. This elegant timepiece features a refined Milanese bracelet and a silver-colored dial with a sunray finish. It is designed for individuals who appreciate minimalism and classic design in a chronograph watch.



Image 1.1: Front view of the THOMAS SABO WA0244-201-201-42 mm wristwatch.

2. Setup and Initial Use

2.1 Setting the Time

1. Pull the crown (the knob on the side of the watch) out to the second click position.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its normal position.

2.2 Adjusting the Milanese Bracelet

The Milanese bracelet features an adjustable sliding clasp for a comfortable fit.

1. Locate the clasp and gently lift the small lever on the top of the clasp using a small, flat tool (e.g., a small screwdriver or a watch tool).
2. Slide the clasp along the bracelet to the desired position for your wrist size.

3. Press the lever back down firmly until it clicks into place, securing the clasp. Ensure it is fully closed to prevent accidental opening.



Image 2.1: The THOMAS SABO wristwatch worn on a wrist, demonstrating fit.

3. Operating Instructions

3.1 Timekeeping

Your watch is an analog quartz movement timepiece, providing accurate time display with hour, minute, and second hands.

3.2 Chronograph (Stopwatch) Function

This watch features a chronograph function, allowing you to measure elapsed time.

1. **Start:** Press the upper pusher (button) on the side of the watch to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press the upper pusher again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** After stopping the chronograph, press the lower pusher to reset all chronograph hands to their zero positions.

4. Care and Maintenance

4.1 Cleaning

- Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dust and fingerprints.
- For stainless steel, a slightly damp cloth can be used, followed by a dry cloth. Avoid harsh chemicals or abrasive materials.
- Clean the glass with a soft, lint-free cloth.

4.2 Battery Replacement

The watch is powered by a product-specific battery. When the watch stops or the second hand starts skipping (indicating low battery), it is time for a replacement. Battery replacement should be performed by a qualified watch technician to ensure proper

sealing and function.

4.3 General Care Tips

- Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes.
- Keep the watch away from strong magnetic fields, as these can affect the accuracy of the quartz movement.
- While the watch is made of stainless steel, avoid contact with corrosive substances, perfumes, or harsh chemicals.
- Store the watch in a dry, safe place when not in use, preferably in its original packaging or a watch box.

5. Troubleshooting

5.1 Watch Not Running

- **Check the crown:** Ensure the crown is fully pushed in. If it is pulled out, the watch will not run.
- **Battery:** The battery may be depleted. Refer to Section 4.2 for battery replacement.

5.2 Incorrect Time Display

- **Reset the time:** Follow the instructions in Section 2.1 to reset the time.
- **Magnetic interference:** If the watch has been exposed to strong magnetic fields, its accuracy might be affected. Consult a professional watchmaker.

5.3 Chronograph Hands Not Resetting to Zero

- Ensure the chronograph is stopped before attempting to reset. Press the upper pusher to stop, then the lower pusher to reset.
- If the issue persists, a professional adjustment may be required.

6. Product Specifications

Feature	Detail
Brand	THOMAS SABO
Model Name	WA0244-201-201-42 MM
Display Type	Analog
Movement	Quartz
Special Features	Chronograph (Stopwatch)
Case Diameter	42 Millimeters
Case Thickness	11 Millimeters
Band Material Type	Stainless Steel
Band Width	20 Millimeters
Band Color	Silver
Dial Color	White
Product Dimensions	0.99 x 0.99 x 0.99 cm

Item Weight	0.15 g
Batteries	1 Product-specific battery required (included)
Manufacturer	THOMAS SABO GmbH

7. Warranty and Support

7.1 Warranty Information

This product is sold without an explicit warranty. Please refer to your retailer's return policy or local consumer protection laws for any applicable rights.

7.2 Customer Support

For further assistance, technical support, or service inquiries, please contact the retailer where you purchased the watch or visit the official THOMAS SABO website for contact information.

© 2023 THOMAS SABO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01D8Z94LO

More documents and user manuals: **https://manuals.plus/**