**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Comforday 55119**

# Comforday Model 55119 Digital Programmable Timer User Manual

Model: 55119

## 1. Introduction

Thank you for choosing the Comforday Digital Programmable Timer. This device is designed to automate the control of electrical appliances, offering convenience, energy savings, and enhanced security for your home or office. Featuring dual grounded outlets and up to 10 programmable ON/OFF settings per week, this timer is versatile for various applications, including lights, sprinklers, heating, air conditioning, and hydroponic systems. Please read this manual carefully to ensure proper setup and operation.

## 2. Important Safety Information

- **Indoor Use Only:** This timer is designed for indoor use in dry locations. Do not expose to water or moisture.
- **Electrical Rating:** Do not exceed the maximum load of 15A/1800W. Overloading can cause overheating and fire.
- **Grounding:** Ensure the timer is plugged into a properly grounded 3-prong outlet.
- **Cleaning:** Disconnect from power before cleaning. Use a dry cloth only.
- **Children:** Keep out of reach of children.
- **Repairs:** Do not attempt to disassemble or repair the unit yourself. Contact qualified service personnel.

## 3. Product Overview

The Comforday Digital Programmable Timer features an LCD display, multiple control buttons, and two grounded outlets. A small red LED light indicates when the outlets are active.



*Figure 1: Front view of the Comforday Digital Programmable Timer, showing the LCD screen, control buttons, and dual grounded outlets.*

### 3.1. Components

1. **LCD Display:** Shows current time, day, program settings, and operating mode.
2. **Control Buttons:** Used for setting time, programs, and various functions.
3. **Dual Grounded Outlets:** Two outlets controlled by the same program.
4. **Red LED Indicator:** Illuminates when the timer's outlets are supplying power.

## 4. Setup

### 4.1. Initial Power-up

1. Plug the timer into a standard 120V AC electrical outlet.
2. The LCD display will illuminate. If the display is blank, allow the internal battery to charge for approximately 15 minutes.

### 4.2. Setting Current Time and Day

1. Press the 'CLOCK' button once. The hour digits will flash.
2. Use the 'HOUR' button to set the current hour (12-hour format with AM/PM).
3. Press the 'MINUTE' button to set the current minute.
4. Press the 'WEEK' button to select the current day of the week.
5. Press the 'CLOCK' button again to confirm and exit time setting mode.

## 5. Operating Instructions

### 5.1. Programming ON/OFF Times

The timer allows for up to 10 distinct ON/OFF programs. Each program consists of an ON time and an OFF time.

1. Press the 'PROG' button. The display will show '1 ON' and the hour digits will flash.
2. Use the 'HOUR', 'MINUTE', and 'WEEK' buttons to set the desired ON time and day(s) for Program 1. You can select individual days, weekdays, weekends, or all 7 days.

3. Press 'PROG' again. The display will show '1 OFF'.
4. Use the 'HOUR', 'MINUTE', and 'WEEK' buttons to set the desired OFF time and day(s) for Program 1.
5. Repeat steps 1-4 for additional programs (up to 10). Press 'PROG' to cycle through '2 ON', '2 OFF', etc.
6. After setting all desired programs, press the 'CLOCK' button to return to normal time display.

### 5.2. Activating/Deactivating Programs

To ensure your programs run, the timer must be in 'AUTO ON' or 'AUTO OFF' mode.

- Press the 'ON/AUTO/OFF' button repeatedly to cycle through the modes:
- **ON:** Outlets are continuously ON, ignoring programs.
- **AUTO ON:** Outlets are currently ON and will follow programmed OFF times.
- **AUTO OFF:** Outlets are currently OFF and will follow programmed ON times.
- **OFF:** Outlets are continuously OFF, ignoring programs.

For programmed operation, select either 'AUTO ON' or 'AUTO OFF' depending on the current state you desire.

### 5.3. Anti-Theft Random Option

This feature randomly turns ON and OFF connected lights to simulate occupancy, enhancing security when you are away.

- To activate: Press the 'HOUR' and 'WEEK' buttons simultaneously. 'RND' will appear on the display.
- To deactivate: Press the 'HOUR' and 'WEEK' buttons simultaneously again. 'RND' will disappear.

### 5.4. Daylight Saving Time (DST) Adjustment

Easily adjust the time for Daylight Saving Time.

- To activate/deactivate: Press the 'HOUR' and 'MINUTE' buttons simultaneously. The time will adjust by one hour forward or backward.

## 6. Maintenance

### 6.1. Cleaning

To clean the timer, first unplug it from the wall outlet. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or abrasive materials.

### 6.2. Battery Backup

The timer includes an internal battery that retains your settings in case of a power outage. This battery charges automatically when the timer is plugged in. No user maintenance is required for the battery.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Timer display is blank. | No power or internal battery discharged. | Ensure timer is plugged into a live outlet. Allow 15 minutes for internal battery to charge. |
| Programs are not running. | Timer is not in AUTO mode. | Press 'ON/AUTO/OFF' button until 'AUTO ON' or 'AUTO OFF' is displayed. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Appliance does not turn ON/OFF at programmed time. | Incorrect program settings or appliance not working. | Verify program settings (time, day, ON/OFF). Test appliance by plugging it directly into a wall outlet. |
| Random function ('RND') is active unexpectedly. | Accidental activation. | Press 'HOUR' and 'WEEK' buttons simultaneously to deactivate. |

## 8. Specifications

**Model Number:** 55119

**Brand:** Comforday

**Electrical Rating:** 15A / 1800W

**Voltage:** 120V AC, 60Hz

**Programs:** Up to 10 ON/OFF settings per week

**Outlets:** 2 Grounded Outlets

**Color:** White

**UPC:** 682676001194

**Dimensions:** 20.91 x 10.51 x 6.61 inches (Package)

**Weight:** 8.98 pounds (Package)

## 9. Warranty and Support

Comforday offers a **30-day warranty guarantee** for this product. If you are not satisfied with your purchase within 30 days, please contact Comforday customer support for assistance. For technical support or warranty claims, please refer to the contact information provided with your purchase or visit the official Comforday website.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B01DBFGLN0**

More documents and user manuals: **https://manuals.plus/**