Nespresso 4192-US

Nespresso Aeroccino 4 Milk Frother Instruction Manual

Model: 4192-US

Introduction

Welcome to the Nespresso Aeroccino 4 Milk Frother instruction manual. This guide provides essential information for the safe and efficient use of your new appliance. The Aeroccino 4 is designed to create delicious hot and cold milk foam for your coffee beverages, such as latte macchiato and cappuccino. Please read these instructions carefully before first use and keep them for future reference.

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not immerse the base unit in water or other liquids.
- Ensure the voltage specified on the appliance matches your local mains voltage.
- Keep the appliance out of reach of children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only original Nespresso accessories and spare parts.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- This appliance is for household use only.

Product Overview

The Nespresso Aeroccino 4 is an automatic milk frother designed for ease of use and versatility. It consists of a jug, a whisk, and a power base with control buttons.



Image: Nespresso Aeroccino 4 milk frother and its separate power base. The frother jug is made of stainless steel with a black handle, and the base features control buttons.

Components:

- **Frother Jug:** Stainless steel jug with a non-stick coating inside.
- **Lid:** Transparent lid with a seal.
- **Whisk:** Magnetic whisk for frothing and stirring milk.
- **Power Base:** Base unit with power cord and control buttons for different frothing options.



Image: Close-up view of the whisk component, typically placed inside the frother jug for operation.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, clean the frother jug and whisk according to the "Maintenance and Cleaning" section.
3. **Position:** Place the power base on a clean, dry, and stable surface.
4. **Insert Whisk:** Ensure the whisk is correctly placed inside the frother jug on the magnetic pin.
5. **Connect Power:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

The Aeroccino 4 offers multiple options for milk preparation. Always use fresh, cold milk. Do not fill above the maximum level indicator inside the jug.

Milk Preparation Options:

- **Hot Milk Foam (Dense):** Pour milk into the jug. Press the button for dense hot foam. The indicator light will illuminate.
- **Hot Milk Foam (Light):** Pour milk into the jug. Press the button for light hot foam. The indicator light will illuminate.
- **Cold Milk Foam:** Pour milk into the jug. Press the button for cold foam. The indicator light will illuminate.
- **Hot Milk (No Foam):** Remove the whisk from the jug. Pour milk into the jug. Press the button for hot milk. The

indicator light will illuminate.

The appliance will automatically stop when the desired temperature and consistency are reached. Pour the prepared milk into your cup immediately.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your Aeroccino 4.

After Each Use:

1. **Unplug:** Disconnect the appliance from the power outlet.
2. **Rinse:** Immediately rinse the frother jug and whisk with cold water to prevent milk residue from drying.
3. **Wash:** The frother jug and whisk are dishwasher safe. Alternatively, wash them by hand with warm water and a non-abrasive sponge.
4. **Dry:** Dry all parts thoroughly with a soft cloth.

Power Base:

- Wipe the power base with a damp cloth. Do not immerse the power base in water.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not start.	No power supply.	Check if the power cord is securely plugged into a working outlet.
Milk does not froth or froths poorly.	Incorrect milk type or temperature; whisk not properly inserted; milk level too high/low.	Use fresh, cold milk (preferably semi-skimmed). Ensure whisk is correctly placed. Do not exceed MAX fill line.
Milk overflows.	Too much milk in the jug.	Do not fill milk above the maximum level indicator.
Burnt milk smell/residue.	Jug not cleaned properly after previous use.	Clean the jug thoroughly after each use.

Specifications

Brand: Nespresso

Model: 4192-US

Color: Silver

Capacity: 236.6 Milliliters

Material: Metal

Product Dimensions: 8.9 cm (Diameter) x 23 cm (Height)

Item Weight: 1.5 Kilograms

Special Features: Cold milk foam creation, Dishwasher safe jug and whisk.

Automatic Shut-off: No



Image: Diagram illustrating the dimensions of the Nespresso Aeroccino 4, showing a height of 9.1 inches (23 cm).

Warranty and Support

For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official Nespresso website. For technical support, troubleshooting assistance beyond this manual, or to order spare parts,

please contact Nespresso customer service.

Nespresso Official Website: www.nespresso.com

© 2024 Nespresso. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question