Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coolux AA59-00594A

Coolux Universal Remote Control

Model: AA59-00594A

Introduction

This manual provides essential instructions for setting up and operating your Coolux Universal Remote Control, Model AA59-00594A. Designed for compatibility with a wide range of Samsung LCD, LED, HDTV, 3D, and Smart Home Entertainment TVs, this remote offers a straightforward, no-programming-required experience.



Image: Front view of the Coolux Universal Remote Control.

Setup: Battery Installation

The Coolux Universal Remote Control requires two (2) AAA batteries (not included). No programming or pairing is necessary; simply insert the batteries, and the remote will be ready for use.

1. **Open the Battery Compartment:** Locate the battery cover on the back of the remote control. Slide the cover downwards to open the compartment.



Image: Back of the remote showing the open battery compartment.

2. **Insert Batteries:** Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.



Image: Visual guide for correct battery insertion.

3. **Close the Battery Compartment:** Slide the battery cover back into place until it clicks securely.

Once batteries are installed, the remote is ready to operate your compatible Samsung TV.

Operating Instructions

This remote control functions identically to your original Samsung TV remote, providing intuitive control over your television's features.

Basic Functions:

- **Power On/Off:** Press the **TV Power** button to turn your television on or off.
- **Volume Control:** Use the **Volume Up (+)** and **Volume Down (-)** buttons to adjust the sound level.
- **Channel Navigation:** Use the **Channel Up (CH+)** and **Channel Down (CH-)** buttons to change channels. Direct channel access is also available using the number pad.
- **Mute:** Press the **Mute** button to silence the TV audio.

- **Input/Source:** Press the Source button to cycle through available input sources (e.g., HDMI 1, HDMI 2, TV).
- **Menu/Guide:** Access your TV's main menu or program guide using the dedicatedMENU and GUIDE buttons.
- **Media Playback:** Dedicated buttons for Play/Pause, Stop, Fast Forward, Fast Back, Skip Forward, and Skip Back are provided for controlling media content.

Features

- **Universal Compatibility:** Works with most Samsung LCD, LED, HDTV, 3D, and Smart Home Entertainment TVs.
- **No Programming Required:** Ready to use directly out of the box after battery insertion.
- **Ergonomic Design:** Lightweight and comfortable to hold.
- **Comprehensive Controls:** Includes all standard TV and media playback functions.
- **Direct Channel Access:** Easily switch to any channel using the numeric keypad.

Specifications

Brand	Coolux
Model Name	AA59-00594A
Special Feature	Ergonomic, Universal
Compatible Devices	Television
Connectivity Technology	Infrared
Button Quantity	10
Controller Type	Button Control
Maximum Range	10 Meters
Battery Type	AAA
Number of Batteries Required	2 (not included)
Item Weight	0.1 Pounds

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases. Always replace both batteries at the same time with new AAA batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures. If not in use for an extended period, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from drops and impacts, which can cause internal damage.

Troubleshooting

If you encounter issues with your Coolux Universal Remote Control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with fresh AAA batteries.
  - Point the remote directly at the TV's infrared sensor. Obstructions can block the signal.
- **Limited Range or Intermittent Functionality:**
  - Check for any objects blocking the line of sight between the remote and the TV.
  - Ensure there are no strong light sources (like direct sunlight or bright fluorescent lights) interfering with the infrared signal.
  - Replace batteries, even if they seem to be working, as low power can affect range.
- **Specific Buttons Not Working:**
  - Clean the remote's surface and buttons to ensure no debris is preventing proper contact.
  - If only certain buttons are unresponsive, it might indicate a hardware issue.

If these steps do not resolve the issue, further assistance may be required.

Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the retailer's policy or contact Coolux customer service through their official channels. Keep your purchase receipt as proof of purchase.

© 2024 Coolux. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01DU67QZM

More documents and user manuals: **https://manuals.plus/**