De'Longhi 5313232961

De'Longhi 5313232961 Milk Suction Tube User Manual

Model: 5313232961 | Brand: De'Longhi

Introduction

This manual provides instructions for the installation, operation, and maintenance of the De'Longhi 5313232961 Milk Suction Tube. This component is designed as a replacement part for specific De'Longhi automatic coffee machines, facilitating the milk frothing process.

Product Overview



Figure 1: Two transparent De'Longhi milk suction tubes, model 5313232961, designed for automatic coffee machines. These tubes are essential for drawing milk into the frothing system.

The De'Longhi 5313232961 Milk Suction Tube is a transparent plastic component used in automatic coffee machines to draw milk from a container into the machine's frothing mechanism. It is sold as a set of two tubes.

Compatibility

This milk suction tube is compatible with the following De'Longhi automatic coffee machine models:

- ETAM 36.365
- ECAM28.465

- ECAM28.466
- ECAM45.366
- ECAM23.466
- ETAM 29.660
- ETAM 36.366
- ECAM45.766

Please verify your coffee machine's model number to ensure proper fit and function.

Setup (Installation)

Follow these steps to install the milk suction tube:

1. **Power Off:** Ensure your coffee machine is turned off and unplugged from the power outlet before beginning installation.
2. **Remove Old Tube (if applicable):** Carefully detach the existing milk suction tube from the milk carafe and the machine's milk frothing system.
3. **Inspect New Tube:** Examine the new De'Longhi 5313232961 tube for any signs of damage or manufacturing defects.
4. **Connect to Carafe:** Insert one end of the new suction tube firmly into the designated port on your De'Longhi milk carafe.
5. **Connect to Machine:** Connect the other end of the suction tube to the milk frothing system's inlet on your coffee machine. Ensure both connections are secure to prevent air leaks, which can affect frothing performance.
6. **Test:** Once installed, plug in and power on your coffee machine. Perform a test run of the milk frothing function to confirm proper operation.

Note: Refer to your specific coffee machine's user manual for detailed instructions on accessing and connecting milk system components.

Operating Instructions

The milk suction tube operates as an integral part of your automatic coffee machine's milk frothing system. Its function is to draw milk from the carafe into the machine for heating and frothing.

- **Milk Preparation:** Fill the milk carafe with fresh, cold milk.
- **Tube Connection:** Ensure the milk suction tube is securely connected to both the milk carafe and the coffee machine.
- **Frothing Cycle:** Select your desired milk-based beverage on your coffee machine. The machine will automatically initiate the milk frothing cycle, drawing milk through the tube.
- **Post-Use:** After each use, it is recommended to clean the milk system to prevent blockages and maintain hygiene.

Maintenance and Cleaning

Regular cleaning of the milk suction tube is crucial for optimal performance and hygiene.

1. **Daily Cleaning:** After each use of the milk frothing function, detach the milk suction tube from both the carafe and the machine. Rinse it thoroughly under warm running water to remove any milk residue.
2. **Weekly Cleaning:** For a more thorough cleaning, soak the tube in warm water with a mild detergent or a specialized milk system cleaner for approximately 15-30 minutes. Use a small brush (if available) to clean the

interior of the tube.

3. **Rinsing:** After soaking and brushing, rinse the tube extensively with clean water to ensure no detergent residue remains.
4. **Drying:** Allow the tube to air dry completely before reattaching it or storing it.
5. **Inspection:** Periodically inspect the tube for any signs of wear, cracks, or discoloration. Replace the tube if any damage is observed, as this can affect performance.

Warning: Do not use abrasive cleaners or harsh chemicals, as these can damage the plastic material of the tube.

Troubleshooting

If you encounter issues with milk frothing, consider the following common troubleshooting steps related to the suction tube:

- **No Milk Suction:**
  - Ensure the tube is securely connected at both ends.
  - Check for blockages within the tube. Clean thoroughly as per the Maintenance section.
  - Verify that the milk carafe contains sufficient milk.
- **Poor Froth Quality:**
  - Ensure the tube is clean and free of residue.
  - Check for any cracks or damage to the tube that might cause air leaks.
  - Use fresh, cold milk.
- **Leaking:**
  - Confirm the tube is correctly seated and sealed at both connection points.
  - Inspect the tube for any physical damage. Replace if necessary.

If problems persist after following these steps, consult your coffee machine's main user manual or contact De'Longhi customer support.

Specifications

Brand	De'Longhi
Model Number	5313232961
Color	Transparent
Material	Plastic
Product Dimensions (L x W x H)	2 x 1 x 5 cm (approximately 0.79 x 0.39 x 1.97 inches)
Item Weight	9.5 grams (approximately 0.34 ounces)
Special Feature	Milk frother component
Country of Origin	Italy

Warranty Information

This product is a replacement part. Warranty coverage for replacement parts typically aligns with the warranty of the original appliance or a limited period for the part itself. Please refer to the warranty documentation provided with your De'Longhi coffee machine or contact De'Longhi customer service for specific warranty details regarding replacement parts.

Support

For further assistance, technical support, or to inquire about other De'Longhi products, please visit the official De'Longhi website or contact their customer service department. Contact information can usually be found in your coffee machine's main user manual or on the De'Longhi regional website.

© 2025 De'Longhi. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question