NIXON A1058

Nixon Porter Leather A1058 Watch Instruction Manual

Model: A1058

Introduction Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides instructions for the proper use and care of your Nixon Porter Leather A1058 watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece. The Nixon Porter Leather watch combines a sleek profile with a sophisticated design, suitable for various occasions.



Figure 1: Front view of the Nixon Porter Leather A1058 watch with a gunmetal grey face and tan leather band.

2. Setup

2.1 Setting the Time

1. Locate the crown on the right side of the watch case.
2. Gently pull the crown outwards to the time-setting position. You may feel a slight click.
3. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position against the watch case. This will start the watch movement.



Figure 2: Side view of the watch, highlighting the crown used for time adjustment.

2.2 Adjusting the Leather Band

The leather band is designed for comfort and can be adjusted to fit various wrist sizes. The band features multiple holes and a buckle closure.

- Place the watch on your wrist.

- Thread the end of the band through the buckle.
- Select the hole that provides a comfortable and secure fit without being too tight or too loose.
- Secure the pin of the buckle into the chosen hole.



Figure 3: View of the watch band and buckle mechanism.

3. Operating Your Watch

Your Nixon Porter Leather A1058 watch is a simple, elegant timepiece designed for daily wear. It features a Miyota Japanese Quartz movement for accurate timekeeping.

3.1 Water Resistance

This watch is rated for 50 meters (5 ATM) water resistance. This means it is suitable for short periods of recreational swimming, but not for diving or prolonged water immersion. Avoid operating the crown while the watch is wet or submerged to prevent water intrusion.
Important: Water resistance is not a permanent condition and may decrease over time with normal wear and tear. Always ensure the crown is fully pushed in before any contact with water.

4. Maintenance

4.1 Cleaning Your Watch

- **Case and Crystal:** Wipe the watch case and crystal with a soft, dry, lint-free cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- **Leather Band:** Avoid prolonged exposure of the leather band to water, direct sunlight, and harsh chemicals. Clean the leather band with a soft, dry cloth. Specialized leather cleaners can be used sparingly if necessary, following the product's instructions.

4.2 Battery Replacement

The watch is powered by a product-specific battery (included). When the watch stops running, the battery will need to be replaced. It is recommended to have battery replacement performed by a qualified watch technician to ensure proper sealing and maintain water resistance.



Figure 4: The watch case back, which needs to be opened for battery replacement.

4.3 Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight and extreme temperatures. Keeping it in its original packaging or a watch box can help protect it from dust and scratches.

5. Troubleshooting

Problem	Possible Cause	Solution
Watch stops or runs intermittently.	Depleted battery.	Replace the battery (recommended by a professional).
Watch hands do not move after setting.	Crown not fully pushed in.	Ensure the crown is fully pushed back into the case.
Condensation under the crystal.	Water intrusion due to improper crown sealing or exceeding water resistance limits.	Immediately take the watch to a qualified service center. Do not attempt to dry it yourself.
Leather band shows wear or discoloration.	Normal wear and tear, exposure to moisture or chemicals.	Clean as per maintenance instructions. Consider replacing the band if severely worn.

6. Specifications

Model Number: A10582494-00

Movement: Miyota Japanese Quartz

Water Resistance: 50 meters / 5 ATM

Case Material: Stainless Steel

Case Diameter: 40mm

Band Material: Leather

Band Width: 20-18mm tapered

Battery: 1 Product Specific battery (included)

Product Dimensions: 5 x 4 x 4 inches; 1.6 ounces

Manufacturer: Nixon Inc.

7. Warranty & Support

For detailed warranty information and customer support, please refer to the official Nixon website or contact their customer service directly. Keep your proof of purchase for any warranty claims.
Nixon, Inc. is the manufacturer of this product.
You can visit the official Nixon store for more information:Nixon Official Store

© 2023 Nixon Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question