Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Clatronic WKR 3624

Clatronic WKR 3624 Travel Electric Kettle User Manual

Model: WKR 3624 | Brand: Clatronic

Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your Clatronic WKR 3624 Travel Electric Kettle. Please read this manual thoroughly before first use and keep it for future reference.
The Clatronic WKR 3624 is a compact electric kettle designed for travel and small households, featuring a 0.5-liter capacity and 1000W power for rapid boiling. It includes safety features such as automatic shut-off and boil-dry protection.

Important Safety Instructions

- Read all instructions before use.
- Do not immerse the kettle, power cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance matches your local power supply.
- Keep the appliance out of reach of children.
- Do not operate the kettle with a damaged cord or plug.
- Always place the kettle on a stable, flat, heat-resistant surface.
- Do not fill above the maximum fill line to prevent boiling water from overflowing.
- Do not open the lid while water is boiling.
- Unplug the kettle from the outlet when not in use and before cleaning.
- This appliance is for household use only.

Package Contents

Upon unpacking, please ensure all items are present and in good condition:

- Clatronic WKR 3624 Travel Electric Kettle
- 2 x 170 ml cups
- 1 x Spoon
- Travel/Transport bag

- User Manual (this document)



Image: The Clatronic WKR 3624 kettle, two black cups, and a silver spoon, representing the complete package contents.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water up to the maximum fill line. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the kettle on a dry, flat, and stable surface away from the edge of the countertop. Ensure the power cord is not dangling where it can be pulled or tripped over.
4. **Power Connection:** Plug the power cord into a suitable electrical outlet (110-230V AC, 50Hz).



Image: A visual representation of the kettle's compact design, highlighting its 500 ml capacity, 17 cm height, and 16 cm width, ideal for travel and small spaces.

Operating Instructions

1. **Fill the Kettle:** Open the hinged lid and fill the kettle with the desired amount of water. Do not fill below the minimum mark or above the maximum fill line (0.5 liters).
2. **Close the Lid:** Ensure the lid is securely closed before operating.
3. **Power On:** Place the kettle on its fixed base. Press the ON/OFF switch (indicated by a light) to the 'ON' position. The indicator light will illuminate, signifying that the kettle is heating.
4. **Boiling Process:** The water will begin to heat. The kettle will automatically switch off once the water has reached boiling point. The indicator light will turn off.
5. **Pouring:** Carefully lift the kettle from its base and pour the hot water using the spout. Be cautious of steam and hot water.
6. **Power Off:** If you need to stop the boiling process before it automatically shuts off, simply press the ON/OFF switch

to the 'OFF' position or unplug the kettle.



Image: A person carefully pouring hot water from the Clatronic WKR 3624 kettle into one of the included cups, demonstrating typical use.

Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your kettle.

General Cleaning:

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- The removable filter can be washed under running water.
- Do not immerse the kettle or its electrical base in water.

Descaling:

Limescale buildup can affect performance and taste. Descale your kettle regularly, especially in hard water areas.

1. Fill the kettle with a mixture of water and white vinegar (e.g., 1 part vinegar to 2 parts water) or a commercial descaling solution.
2. Boil the mixture.
3. Allow it to stand for at least 30 minutes, or longer for heavy scale.
4. Discard the mixture and rinse the kettle thoroughly with fresh water several times.
5. Boil fresh water 2-3 times and discard to remove any residual vinegar taste.



Image: A detailed view of the kettle's base, showing the integrated power cord and the ON/OFF switch, which should be kept dry during cleaning.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in. Power switch is off. No power at the outlet. Boil-dry protection activated.	Ensure the kettle is properly plugged into a working outlet. Press the ON/OFF switch to the 'ON' position. Check the circuit breaker or try another outlet. Unplug the kettle, let it cool for 15-20 minutes, then refill and restart.
Water takes too long to boil.	Limescale buildup. Overfilled kettle.	Descale the kettle as per the maintenance section. Ensure water level is within MIN/MAX indicators.
Kettle switches off before boiling.	Limescale buildup affecting sensor. Kettle was lifted from base during operation.	Descale the kettle. Ensure the kettle remains on its base until boiling is complete.

Specifications

Brand	Clatronic
Model Number	WKR 3624
Capacity	0.5 Liters (500 Milliliters)
Power	1000 Watts
Voltage	110-230 V AC
Frequency	50 Hz
Material	Stainless Steel (body), Metal
Color	Inox Schwarz (Stainless Steel/Black)
Dimensions (W x H)	16 cm x 17 cm (approximate kettle dimensions)
Weight	0.54 kg (540 grams)
Special Features	Automatic shut-off, Boil-dry protection, Overheat safety shut-off, Hinged lid (one-hand operation), Removable and washable filter, ON/OFF indicator light, Water level indicator, BPA-free components, Fixed power cord.



Image: The Clatronic WKR 3624 kettle positioned on a kitchen counter, emphasizing its 1000 Watt power for quick heating.

Warranty and Support

Clatronic offers a **1-year warranty** on this product. For warranty claims, technical support, or any questions regarding your Clatronic WKR 3624 Travel Electric Kettle, please contact Clatronic customer service.
Please retain your proof of purchase for warranty validation.
Spare parts availability: 2 Years.

Disposal

Do not dispose of this appliance with normal household waste. It should be taken to a designated collection point for recycling electrical and electronic equipment. This helps protect the environment and human health.

© 2025 Clatronic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01E0KS6JC

More documents and user manuals: **https://manuals.plus/**