VONYX MEG065

VONYX MEG065 65W Megaphone Loudhailer User Manual

Model: MEG065

Introduction

This manual provides comprehensive instructions for the safe and effective operation, maintenance, and troubleshooting of your VONYX MEG065 65W Megaphone Loudhailer. Please read this manual thoroughly before using the device to ensure optimal performance and longevity.



Image: The VONYX MEG065 Megaphone, shown with its detachable microphone and a rechargeable battery pack. The megaphone is blue and white with a grey rim, designed for clear and powerful sound projection.

Safety Instructions

Always observe the following safety precautions to prevent injury or damage to the device:

- Do not expose the megaphone to extreme temperatures, direct sunlight, or high humidity.
- Keep the device away from water and other liquids.
- Do not attempt to disassemble or modify the megaphone. Refer all servicing to qualified personnel.
- Ensure proper battery installation and charging to avoid electrical hazards.
- Avoid pointing the megaphone directly at people's ears at close range when operating at high volume to prevent hearing damage.

Parts List

The VONYX MEG065 package includes the following components:

- VONYX MEG065 Megaphone Unit
- Detachable Handheld Microphone with coiled cable
- Rechargeable Battery Pack (Lithium)
- Battery Charger
- Shoulder Strap



Image: A close-up view of the VONYX MEG065 megaphone's control panel, highlighting the AUX input, USB port, and SD card slot for connecting external devices and playing media.

Setup

1. **Battery Installation:** Open the battery compartment cover. Insert the rechargeable battery pack, ensuring correct polarity. Close the cover securely. If using standard D-cell batteries (not included), insert 8 x D-cell batteries according to the polarity markings.
2. **Charging the Battery:** Connect the provided charger to the rechargeable battery pack and plug it into a power

outlet. The indicator light on the charger will show red while charging and turn green when fully charged.

3. **Microphone Connection:** Plug the coiled cable of the handheld microphone into the designated microphone jack on the megaphone unit.
4. **Attach Shoulder Strap:** Securely attach the shoulder strap to the designated loops on the megaphone for convenient carrying.



Image: Illustration showing the battery compartment of the VONYX MEG065 megaphone and the process of inserting the rechargeable battery. An external charger is also depicted, indicating the charging method.

Operating Instructions

Basic Operation

1. **Power On/Off:** Slide the ON/OFF switch on the microphone to the "ON" position to power on the megaphone. Slide to "OFF" to power off.
2. **Volume Control:** Adjust the volume knob on the microphone to achieve the desired sound level.

3. **Speaking:** Hold the microphone close to your mouth and speak clearly into it.

Siren Function

To activate the built-in siren, press the "SIREN" button on the microphone. Press it again to deactivate the siren.



Image: A detailed view of the handheld microphone for the VONYX MEG065 megaphone, showing the "SIREN", "RECORD", and "PLAY" buttons, along with the power switch and volume control. This illustrates the various functions available directly on the microphone.

Recording and Playback

1. **To Record:** Press and hold the "RECORD" button on the microphone. Speak into the microphone. Release the button to stop recording.
2. **To Playback:** Press the "PLAY" button on the microphone to listen to your recorded message.

USB/SD Card Playback

1. Insert a USB flash drive or SD card containing MP3 audio files into the respective slot on the megaphone unit.

2. The megaphone will automatically detect and begin playing the audio files.
3. Use the controls on the megaphone (if available) or the microphone to skip tracks or pause playback.



Image: A close-up of the VONYX MEG065 megaphone's input panel, showing a USB drive and an SD card inserted into their respective slots. This illustrates the device's capability to play media directly from these storage devices.

Maintenance

- **Cleaning:** Wipe the megaphone with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the megaphone in a cool, dry place away from direct sunlight when not in use. Remove batteries if storing for extended periods.
- **Battery Care:** Fully charge the rechargeable battery before first use. Avoid completely draining the battery to prolong its lifespan.

Troubleshooting

Problem	Possible Cause	Solution
No sound output	Battery low or not installed correctly; Volume too low; Microphone not connected or faulty.	Charge or replace batteries; Increase volume; Check microphone connection.
Distorted sound	Volume too high; Microphone too close to mouth; Battery low.	Reduce volume; Hold microphone further away; Charge or replace batteries.
Siren not working	Siren button not fully pressed; Power off.	Ensure button is fully depressed; Turn on power.
Recording/Playback issues	Record/Play button not fully pressed; Insufficient battery.	Ensure buttons are fully depressed; Charge or replace batteries.

Specifications

- **Model:** MEG065
- **Output Power:** 65W
- **Dimensions:** 23 x 25 x 27 cm
- **Weight:** 1.6 kg
- **Power Source:** Rechargeable Lithium Battery (included) or 8x D-cell batteries (not included)
- **Features:** Siren, Record/Playback, USB/SD Card Playback, AUX input
- **Material:** Acrylonitrile Butadiene Styrene

Warranty and Support

For warranty information and technical support, please refer to the manufacturer's official website or contact your retailer. Keep your proof of purchase for any warranty claims.
Manufacturer: Tronios B.V.

© 2024 VONYX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question