LG BPM35

LG BPM35 BP350 Blu-Ray Disc Player User Manual

Model: BPM35 | Brand: LG

Introduction

This manual provides instructions for the safe and efficient operation of your LG BPM35 BP350 Blu-Ray Disc Player. This player offers Full HD 1080p Blu-ray playback, DVD upscaling, and built-in Wi-Fi for access to streaming services and Music Flow compatibility. Please read this manual thoroughly before using the product and retain it for future reference.

Package Contents

Verify that all components are present in the package:

- LG BPM35 BP350 Blu-Ray Disc Player
- Remote Control
- AC Adapter
- User Manual (this document)

Note: HDMI cables are not typically included and must be purchased separately.

Setup

1. **Placement:** Place the Blu-Ray player on a stable, flat surface near your television. Ensure adequate ventilation around the unit.
2. **Connect to TV:** Connect an HDMI cable (not included) from the HDMI OUT port on the Blu-Ray player to an HDMI input port on your television.



Figure 1: Front view of the LG BPM35 BP350 Blu-Ray Disc Player. The disc tray is visible on the left, and USB port on the right.

3. **Power Connection:** Connect the AC adapter to the DC IN port on the player and then plug the adapter into a wall outlet.
4. **Initial Power On:** Turn on your television and select the correct HDMI input source. Press the Power button on the Blu-Ray player or its remote control. Follow the on-screen instructions for initial setup, including language selection and network configuration.
5. **Wi-Fi Setup:** During the initial setup or via the settings menu, connect the player to your home Wi-Fi network. This enables access to streaming apps and firmware updates.

Operating Instructions

Remote Control

Insert two AAA batteries (not included) into the remote control. The remote allows full control over the player's functions, including power, disc playback, menu navigation, and smart app access.



Figure 2: LG BPM35 BP350 Blu-Ray Disc Player shown with its remote control.

Disc Playback

1. **Loading a Disc:** Press the **OPEN/CLOSE** button on the player or remote to open the disc tray. Place a Blu-ray disc or DVD gently into the tray with the label side facing up. Press **OPEN/CLOSE** again to close the tray.

2. **Starting Playback:** The player will typically begin playback automatically. If not, select the disc icon from the home menu and press **PLAY**.
3. **Controls:** Use the **PLAY**, **PAUSE**, **STOP**, **FAST FORWARD**, and **REWIND** buttons on the remote for disc control.
4. **Ejecting a Disc:** Press the **OPEN/CLOSE** button to eject the disc.

Smart TV Features and Apps

With built-in Wi-Fi, the LG BPM35 BP350 provides access to various streaming services. Ensure your player is connected to the internet.

- **Accessing Apps:** From the player's home screen, navigate to the "Smart World" or "Apps" section. Select your desired streaming service (e.g., Netflix, Hulu, YouTube).
- **Account Login:** You may need to log in with your existing account credentials for each service.
- **Music Flow Compatibility:** The player can send CD/USB audio wirelessly to compatible LG Music Flow speakers within your home network. Refer to your Music Flow speaker manual for pairing instructions.

USB Playback

Connect a USB storage device to the USB port on the front of the player to play compatible media files (e.g., photos, music, videos). Navigate to the USB input source from the home menu to browse content.

Maintenance

- **Cleaning the Unit:** Wipe the exterior of the player with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Disc Care:** Handle discs by their edges. Clean discs with a soft, lint-free cloth, wiping from the center outwards. Avoid touching the playback surface.
- **Ventilation:** Ensure the player's ventilation openings are not blocked to prevent overheating.

Troubleshooting

Problem	Possible Cause	Solution
No picture or sound (No Signal)	◦ Incorrect HDMI input selected on TV. ◦ Loose or faulty HDMI cable. ◦ Player not powered on.	◦ Select the correct HDMI input on your TV. ◦ Check HDMI cable connections; try a different cable if necessary. ◦ Ensure the player is powered on.
Disc does not play or load	◦ Disc is dirty or scratched. ◦ Disc inserted incorrectly. ◦ Incompatible disc format.	◦ Clean the disc with a soft cloth. ◦ Ensure the disc is inserted label-side up. ◦ Verify the disc is a compatible Blu-ray or DVD format.

Problem	Possible Cause	Solution
Remote control not working	◦ Batteries are dead or inserted incorrectly. ◦ Obstruction between remote and player.	◦ Replace batteries with new AAA batteries, ensuring correct polarity. ◦ Remove any obstructions and point the remote directly at the player.
Cannot connect to Wi-Fi	◦ Incorrect Wi-Fi password. ◦ Router is too far or signal is weak. ◦ Network settings issue.	◦ Re-enter the Wi-Fi password carefully. ◦ Move the player closer to the router or use a Wi-Fi extender. ◦ Restart your router and the Blu-Ray player. Check network settings in the player's menu.
Player freezes or becomes unresponsive	◦ Temporary software glitch. ◦ Overheating.	◦ Unplug the player from the power outlet, wait 30 seconds, then plug it back in. ◦ Ensure proper ventilation around the unit.

Specifications

Model Number	BPM35
Brand	LG
Product Dimensions	18.5 x 3.5 x 15.51 inches
Item Weight	2.7 pounds
Media Type	Blu-Ray Disc, CD, DVD
Resolution	1920x1080 (Full HD)
Connectivity Technology	HDMI, USB, Wi-Fi
Connector Type	HDMI
Total HDMI Ports	1
Special Feature	Wireless (Built-in Wi-Fi)

Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official LG website. For technical support, product registration, or service inquiries, please contact LG customer support through their official channels. Keep your purchase receipt for warranty claims.
LG Customer Support: www.lg.com/us/support

© 2024 LG Electronics. All rights reserved.