Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vinturi V9046

Vinturi Electric Rechargeable Wine Opener with Base and Foil Cutter Instruction Manual

Model: V9046

1. Product Overview

The Vinturi Electric Rechargeable Wine Opener is designed for effortless removal of natural and synthetic corks. It features a sleek design, a charging base, and an integrated foil cutter for convenience.





Image: Vinturi Electric Rechargeable Wine Opener with its charging base and included foil cutter.

2. Package Contents

- Vinturi Electric Rechargeable Wine Opener
- Charging Base
- Foil Cutter
- Power Adaptor

3. Setup

3.1 Initial Charging

1. Place the Vinturi Electric Rechargeable Wine Opener onto its charging base.
2. Connect the power adaptor to the charging base and plug it into a standard electrical outlet.
3. The blue LED light on the charging base will illuminate, indicating that the unit is charging.
4. Allow the unit to charge for at least 8-10 hours before first use to ensure optimal battery performance.



Image: The Vinturi Electric Rechargeable Wine Opener placed on its charging base, connected to the power adapter, with the foil cutter visible.

3.2 Foil Cutter Usage

The included foil cutter is stored conveniently within the charging base. To use:

1. Remove the foil cutter from its slot in the charging base.
2. Place the foil cutter on top of the wine bottle, gripping it firmly.
3. Rotate the bottle or the cutter a full 360 degrees to cleanly cut and remove the foil.



Image: Close-up view of the Vinturi charging base, showing the slot for the foil cutter.

4. Operating Instructions

4.1 Opening a Wine Bottle

1. Ensure the wine opener is fully charged.
2. Use the foil cutter to remove the foil seal from the wine bottle.
3. Place the wine opener vertically on top of the wine bottle, ensuring it is centered over the cork.
4. Hold the bottle firmly with one hand and the opener with the other.
5. Press and hold the 'Down' button (lower button). The corkscrew will automatically rotate and penetrate the cork,

then pull it out of the bottle. The blue LED light will illuminate during operation.

6. Once the cork is fully removed from the bottle, lift the opener away.
7. To release the cork from the opener, press and hold the 'Up' button (upper button). The corkscrew will rotate in the opposite direction, releasing the cork.





Image: The Vinturi Electric Rechargeable Wine Opener placed on top of a wine bottle, ready for cork removal.



Image: A close-up view showing the corkscrew mechanism of the Vinturi Electric Rechargeable Wine Opener engaging with a cork.

4.2 Instructional Video

Your browser does not support the video tag.

Video: A demonstration of the Vinturi Electric Rechargeable Wine Opener in use, showing how to remove foil and extract a cork from a wine bottle.

5. Maintenance

5.1 Cleaning

- Wipe the exterior of the wine opener and charging base with a soft, damp cloth.
- Do not immerse the wine opener or charging base in water or other liquids.
- The corkscrew mechanism can be cleaned by gently wiping it with a damp cloth. Ensure it is dry before storage.

5.2 Storage

Store the Vinturi Electric Rechargeable Wine Opener on its charging base when not in use to keep it charged and ready. Store in a cool, dry place away from direct sunlight.

6. Troubleshooting

Problem	Possible Cause	Solution
Opener does not turn on.	Battery is depleted.	Place the opener on the charging base and ensure it is plugged in. Allow sufficient time for charging.
Cork does not come out.	Opener not centered on the bottle.	Ensure the opener is placed vertically and centered over the cork.
Cork does not come out.	Battery is low.	Recharge the unit.
Cork is stuck in the opener.	Cork not fully released.	Press and hold the 'Up' button to fully release the cork.

7. Specifications

- **Model Number:** V9046
- **Material:** Plastic, Stainless Steel
- **Color:** Silver
- **Item Weight:** 2 Pounds
- **Product Dimensions:** 4.65"L x 5.63"W x 10.70"H (approximate, based on feature bullets)
- **Power Source:** Rechargeable Battery (via included charging base and power adaptor)

8. Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01EUSYEZO

More documents and user manuals: **https://manuals.plus/**