DEWALT DWV9390

DEWALT DWV9390 Dust Bag for DCP580 Cordless Planer Instruction Manual

1. Introduction

This manual provides essential instructions for the proper use and maintenance of the DEWALT DWV9390 Dust Bag. Adhering to these guidelines will ensure optimal performance and longevity of the product.

The DEWALT DWV9390 Dust Bag is specifically designed for efficient dust and chip collection when used with the DEWALT DCP580 cordless planer. It features a secure twist-lock connection to the planer's chip deflector, allowing for quick attachment, detachment, and emptying. The bag is also AirLock compatible, enhancing its dust collection capabilities.

2. Product Overview

The DEWALT DWV9390 Dust Bag is an accessory for the DCP580 cordless planer, designed to manage wood chip and dust output during planing operations. It consists of a durable black fabric bag with the prominent yellow DEWALT logo, connected to a clear plastic twist-lock mechanism. This design ensures robust construction and ease of use.



The DEWALT DWV9390 Dust Bag, featuring a black fabric bag with the yellow DEWALT logo and a clear plastic twist-lock connector, designed for dust collection.

3. Setup Instructions

1. **Power Off Planer:** Ensure the DEWALT DCP580 cordless planer is powered off and its battery pack is removed before attempting to attach the dust bag.
2. **Locate Port:** Identify the chip deflector port on the DEWALT DCP580 planer.
3. **Align Connector:** Align the twist-lock connection of the DWV9390 Dust Bag with the chip deflector port on the planer.
4. **Secure Attachment:** Twist the dust bag connector clockwise until it securely locks into place. Verify that the connection is firm and stable to prevent dust leakage during operation.

4. Operating Instructions

1. **Pre-Operation Check:** Before commencing planing, confirm that the dust bag is securely attached and empty.
2. **Dust Collection:** As the DEWALT DCP580 planer is operated, the dust bag will automatically collect wood chips and dust generated.
3. **Monitor Fill Level:** Regularly observe the dust bag's fill level. For optimal dust collection efficiency and to prevent potential clogging, empty the dust bag when it appears full.
4. **Emptying the Bag:** To empty the collected debris, twist the dust bag connector counter-clockwise to detach it from the planer. Dispose of the contents responsibly.
5. **Reattachment:** Reattach the dust bag securely following the setup instructions before resuming any planing tasks.

5. Maintenance

- **Inspection:** Periodically inspect the dust bag for any signs of wear, tears, or damage. A damaged bag may compromise dust collection efficiency. Replace the bag if significant damage is observed.

- **Cleaning:** After emptying, the fabric portion of the dust bag can be gently shaken or brushed to remove fine dust particles. *Do not wash the bag with water*, as this may degrade the material and affect its filtration properties.
- **Connector Care:** Ensure the twist-lock mechanism on the connector is kept free of debris to maintain a secure and reliable attachment to the planer.

6. Troubleshooting

- **Dust Leakage:** If dust is leaking, ensure the dust bag is fully and securely attached to the planer's chip deflector. Check the twist-lock connection for proper engagement. Inspect the fabric bag for any tears or holes that may require repair or replacement.
- **Reduced Dust Collection:** If the dust bag is not collecting effectively, check if it is full and requires emptying. Also, inspect the planer's chip deflector and the bag's inlet for any blockages that might be impeding airflow.

7. Specifications

- **Model Number:** DWV9390
- **Compatibility:** DEWALT DCP580 Cordless Planer
- **Connection Type:** Twist-lock, AirLock compatible
- **Material:** Plastic (connector), Fabric (bag)
- **Item Weight:** 8.2 ounces
- **Product Dimensions:** 1.85 x 11.1 x 10.63 inches

8. Warranty and Support

For detailed warranty information, technical assistance, or to inquire about replacement parts, please refer to the documentation included with your DEWALT DCP580 cordless planer or visit the official DEWALT website. DEWALT customer support is available to assist with any product-related queries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question