Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dyson 214744-01

Dyson V8 Absolute Cordless Vacuum

Model: 214744-01

Product Overview

The Dyson V8 Absolute Cordless Vacuum is engineered for powerful, versatile, and convenient cleaning. Its cord-free design allows for effortless maneuverability throughout your home, tackling dirt and fine dust on both hard floors and carpets. The lightweight construction makes it easy to carry and use for extended periods, while its advanced filtration system captures allergens for cleaner expelled air.

Key Features:

- Cord-free and hassle-free operation for ultimate convenience.
- Powerful suction, driven by the Dyson digital motor V8.
- Up to 40 minutes of fade-free run time with non-motorized tools.
- Lightweight and versatile design for easy home cleaning.
- Instant release trigger to conserve battery power.
- Whole-machine HEPA filtration captures allergens.
- Includes Direct Drive cleaner head and Soft Roller cleaner head for various floor types.

Included Components



Image: All components of the Dyson V8 Absolute Cordless Vacuum, including the main unit, wand, cleaner heads, and various tools.

Setup & Assembly

Before first use, ensure the battery is fully charged. A minimum of 4 hours charging time is recommended. The vacuum comes with a wall-mounted docking station for convenient storage and charging. Assemble the main unit, wand, and desired cleaner head by clicking them securely into place.

Your browser does not support the video tag.

Video: A quick tour and demonstration of the Dyson Cordless Vacuum System, showing how to assemble and disassemble its various parts.

Operating Instructions

The Dyson V8 Absolute is designed for ease of use. Simply press the instant release trigger to begin vacuuming. It features two power modes: 'High Suction' for extended run time on everyday cleaning, and 'Max Mode' for tougher tasks requiring maximum suction power. The lightweight design and swivel head allow for easy navigation around furniture and into tight spaces.



Image: The Dyson V8 Absolute Cordless Vacuum in action, demonstrating its maneuverability on a hard floor surface.

Your browser does not support the video tag.

Video: A demonstration highlighting the powerful suction and lightweight nature of the Dyson V8 Absolute, showcasing its effectiveness on various floor types.

Maintenance

Regular maintenance ensures optimal performance of your Dyson V8 Absolute. The clear bin allows you to see when it needs emptying. To empty, simply pull the red lever on the top of the main unit to release the bottom flap and empty debris directly into a trash bin. The whole-machine HEPA filter is washable and should be rinsed with cold water monthly to maintain filtration efficiency. Allow the filter to air dry completely before reinserting.

Your browser does not support the video tag.

Video: A user demonstrates how to empty the dustbin and clean the filter of the Dyson V8 Absolute, emphasizing its ease of maintenance.

Troubleshooting

- **Reduced Suction:** Check the dustbin for fullness and empty if necessary. Ensure the filter is clean and properly reinserted. Check for any blockages in the cleaner head or wand.
- **Short Run Time:** Ensure the battery is fully charged before use. Max mode consumes battery faster; use High Suction mode for longer cleaning sessions.
- **Vacuum Not Turning On:** Verify the vacuum is fully charged. Ensure the trigger is pressed firmly.

For more detailed troubleshooting, please refer to the full user manual or contact Dyson customer support.

Specifications

Feature	Detail
Brand	Dyson
Model Number	214744-01
Special Feature	Bagless
Filter Type	HEPA Filter
Is Cordless?	Yes
Capacity	0.54 Liters
Wattage	350 watts
Runtime	Up to 40 minutes
Maximum Suction	115 AW
Item Weight	5.74 pounds
Product Dimensions	48.97"L x 8.81"W x 9.84"H

Warranty & Support

The Dyson V8 Absolute Cordless Vacuum comes with a manufacturer's warranty. For specific warranty details, registration, or technical support, please visit the official Dyson website or contact their customer service directly.

For additional resources and product information, you may visit theDyson Store on Amazon.

© 2025 Dyson. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01EX9D3UW

More documents and user manuals: **https://manuals.plus/**