Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi ECAM45760B

De'Longhi Eletta Digital Super Automatic Espresso Machine User Manual

Model: ECAM45760B
Brand: De'Longhi

Product Overview

The De'Longhi Eletta Digital Super Automatic Espresso Machine is designed to deliver barista-quality espresso drinks with one-touch convenience. It features an integrated Latte Crema System for rich, thick, and long-lasting foam, suitable for cappuccinos, lattes, and Italian macchiatos. The machine is equipped with a 15-bar pressure brewing system for consistent results and an extractable, washable brewing unit for easy maintenance. Its intuitive touch display simplifies operation, allowing users to customize and save their preferred drink settings.



Figure 1: Front view of the De'Longhi Eletta Digital Super Automatic Espresso Machine.

Setup Instructions

1. **Unpacking:** Carefully remove all packaging materials and ensure all components are present. Place the machine on a stable, flat surface away from heat sources and water.
2. **Water Tank Installation:** Fill the 1.8-liter water tank with fresh, cold water. Insert the water tank firmly into its designated slot, typically on the side of the machine.
3. **Bean Hopper:** Open the bean hopper lid and fill it with whole coffee beans. Ensure the lid is securely closed to maintain bean freshness.
4. **Initial Rinse Cycle:** Before first use, perform an initial rinse cycle as instructed by the machine's display. This primes the system and cleans internal components.
5. **Milk Container (Latte Crema System):** For milk-based beverages, fill the integrated milk container with desired milk. Attach it to the machine as per the instructions. The container is detachable for refrigeration.



Figure 2: The machine's water tank and bean hopper are easily accessible for refilling.

Operating Instructions

The De'Longhi Eletta Digital offers a user-friendly experience through its intuitive touch display and dedicated function buttons.

- **Power On:** Press the power button to turn on the machine. It will perform a brief self-check and heating cycle.
- **Selecting a Beverage:** Use the touch display to navigate through the available drink options, such as Espresso, Cappuccino, Latte, and Long Coffee.
- **Customization:** For personalized drinks, adjust settings like coffee strength, temperature, and milk texture directly on the display. Your preferred settings can be saved to the digital menu for future one-touch access.
- **Latte Crema System:** For milk-based drinks, ensure the milk container is attached and filled. The system automatically froths milk to the desired consistency.
- **Long Coffee Function:** Utilize the dedicated "Long Coffee" button for a drip-style coffee experience, brewed via a different process for a consistent cup.
- **Hot Milk Setting:** The hot milk setting provides barista-style steamed milk, perfect for matcha, hot chocolate, or other

beverages.



Figure 3: The Latte Crema System ensures perfectly frothed milk for your beverages.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your De'Longhi Eletta Digital machine.

- **Brewing Unit Cleaning:** The brewing unit is extractable and washable under tap water. It does not require additional grease.

Clean it regularly as indicated by the machine or at least once a week.

- **Grounds Container:** Empty the expended grounds container when prompted by the machine. This prevents overflow and ensures proper operation.
- **Drip Tray:** Regularly empty and clean the drip tray to prevent water overflow and maintain hygiene.
- **Latte Crema System Auto-Clean:** The integrated milk container includes an auto-clean function. Utilize this feature after each use of milk-based beverages to prevent milk residue buildup.
- **Descaling:** The machine will indicate when descaling is required. Use only the official De'Longhi descaling solution to avoid damaging the machine. Follow the on-screen instructions for the descaling process.



Figure 4: The easily removable coffee grounds container for convenient disposal.

Troubleshooting

This section provides general guidance for common issues. For detailed troubleshooting, refer to the official user manual.

- **No Coffee Dispensed:** Check if the water tank is full and correctly inserted. Ensure the bean hopper has enough beans. Verify

that the brewing unit is properly seated.

- **Weak Coffee:** Adjust the coffee strength setting to a higher level. Ensure fresh beans are used and the grind setting is appropriate (finer grind for stronger coffee).
- **Milk Not Frothing:** Ensure the milk container is clean and properly assembled. Use fresh, cold milk. Check if the milk frothing nozzle is clear of blockages.
- **Machine Displaying Error:** Consult the specific error code or message in the comprehensive user manual for detailed steps. Often, this requires cleaning a component or refilling a reservoir.

For comprehensive troubleshooting and error code explanations, please refer to the official User Manual (PDF).

Specifications

Feature	Detail
Brand	De'Longhi
Model Number	ECAM45760B
Color	Black
Product Dimensions	10.2"D x 18.36"W x 14.16"H
Item Weight	24.5 pounds
Coffee Maker Type	Espresso Machine
Filter Type	Reusable
Operation Mode	Fully Automatic
Human Interface Input	Touchscreen
Included Components	Milk Frother, Canister
UPC	044387457613



Figure 5: Product dimensions for placement consideration.

Warranty and Support

For warranty information, product registration, and direct support, please visit the official De'Longhi website or refer to the warranty card included with your purchase.

An official User Manual in PDF format is available for download: De'Longhi Eletta User Manual.

For additional assistance, you may contact De'Longhi customer service or visit their official brand store on Amazon: De'Longhi Store.

© 2024 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01F4WT8XS

More documents and user manuals: **https://manuals.plus/**