Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj EPX9

Bajaj Majesty EPX9 5-Litre Electric Pressure Cooker User Manual

Model: EPX9

Introduction

Thank you for purchasing the Bajaj Majesty EPX9 5-Litre Electric Pressure Cooker. This manual provides essential information for the safe and efficient operation, maintenance, and care of your appliance. Please read all instructions carefully before first use and retain this manual for future reference.

Important Safety Instructions

- Always ensure the lid is properly closed and locked before operating.
- Do not touch hot surfaces. Use handles or knobs.
- Supervise children closely when the appliance is in use.
- Do not immerse the appliance body, cord, or plug in water or other liquids.
- Unplug from outlet when not in use and before cleaning. Allow to cool before adding or removing parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- This appliance is not dishwasher safe.

Product Overview

The Bajaj Majesty EPX9 is a 5-litre electric pressure cooker designed for efficient and safe cooking. It features a stainless steel body and lid, a non-stick coated inner pan, and multiple safety mechanisms.



Image: The Bajaj Majesty EPX9 Electric Pressure Cooker, showcasing its stainless steel exterior and control panel, alongside a prepared meal.

Components:

- **Main Unit:** Stainless steel body housing the heating element and controls.
- **Lid:** Stainless steel outer lid with safety valve and handle.
- **Inner Pot:** 5-litre capacity, non-stick coated pan.
- **Control Panel:** Features a dial for cooking time/mode selection and indicator lights.
- **Safety Valve:** Regulates internal pressure.
- **Thermostat:** Regulates temperature.
- **Thermal Fuse:** Additional safety mechanism.



Image: A close-up view of the pressure cooker's lid, handle, and safety valve, highlighting the outer lid closure mechanism.

Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials and inspect the cooker for any damage.
2. **Initial Cleaning:** Before first use, wash the inner pot, lid, and any accessories with warm soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the pressure cooker on a stable, flat, heat-resistant surface, away from walls and cabinets to allow for proper ventilation.
4. **Power Connection:** Ensure the power cord is securely plugged into the cooker and then into a grounded electrical outlet.

Operating Instructions

Cooking Process:

1. **Add Ingredients:** Place the desired ingredients and liquid into the non-stick inner pot. Do not fill above the MAX fill line.
2. **Close Lid:** Place the lid on the cooker, aligning it correctly, and rotate the handle to lock it securely. Ensure the safety valve is in the correct position for pressure cooking.
3. **Select Cooking Mode:** Use the control dial to select the desired cooking time or program (e.g., rice, chicken, meat, soup, steam). The cooker operates automatically based on the selected setting.
4. **Start Cooking:** The cooker will begin to heat up and build pressure. The "Heat/Pressure" indicator light will illuminate.
5. **Pressure Release:** Once cooking is complete, the cooker will automatically switch to "Warm" mode. Allow the pressure to release naturally, or carefully use the pressure release method specified in the cooker's detailed instructions (if applicable, usually a valve). Do not force open the lid until all pressure has been released.
6. **Open Lid:** Once pressure is fully released, unlock and open the lid carefully, away from your face, to avoid steam burns.



Image: A detailed view of the control panel on the Bajaj Majesty EPX9, showing the dial for selecting cooking modes like chicken, rice, meat, soup, and steam, along with the 'Heat/Pressure' and 'Warm' indicators.



Image: A closer look at the control dial of the Bajaj Majesty EPX9, emphasizing the minute markings for pressure cooking and specific settings for various food types.

Automatic Keep Warm Function:

After the cooking cycle is complete, the cooker will automatically switch to the "Warm" mode to keep your food at an optimal serving temperature. The "Warm" indicator light will be illuminated.

Cleaning and Maintenance

Regular cleaning ensures the longevity and safe operation of your pressure cooker.

1. **Unplug and Cool:** Always unplug the cooker from the power outlet and allow it to cool completely before cleaning.
2. **Inner Pot:** The non-stick inner pot can be washed with warm soapy water and a soft sponge. Avoid abrasive cleaners or scouring pads to protect the non-stick coating. Rinse thoroughly and dry.
3. **Lid:** Wash the lid, including the sealing gasket and safety valve components, with warm soapy water. Ensure all food particles are removed from the safety valve mechanism. Rinse and dry completely.
4. **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Storage:** Store the cleaned and dried pressure cooker in a dry place.

Important: This appliance is not dishwasher safe.

Troubleshooting

Problem	Possible Cause	Solution
Cooker does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; verify power supply; try a different outlet.
Pressure not building.	Lid not properly closed/locked; sealing gasket not seated correctly; safety valve open.	Ensure lid is securely locked; check and adjust sealing gasket; ensure safety valve is in pressure cooking position.

Problem	Possible Cause	Solution
Steam leaking from lid.	Sealing gasket dirty or damaged; lid not properly closed.	Clean or replace sealing gasket; ensure lid is correctly aligned and locked.
Food undercooked/overcooked.	Incorrect cooking time/liquid amount; power fluctuation.	Adjust cooking time and liquid according to recipe; ensure stable power supply.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

- **Model:** EPX9
- **Brand:** Bajaj
- **Capacity:** 5 Litres
- **Power:** 900 Watts
- **Body Material:** Stainless Steel
- **Inner Pot:** Non-stick coated
- **Control Method:** Push Button (Dial)
- **Operation Mode:** Automatic
- **Safety Features:** Safety Valve, Thermostat, Thermal Fuse
- **Dishwasher Safe:** No

Warranty Information

This Bajaj Majesty EPX9 Electric Pressure Cooker comes with a**1-year warranty on the product** from the date of purchase. Please retain your purchase receipt for warranty claims. The warranty covers manufacturing defects under normal household use. It does not cover damage resulting from misuse, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For any queries, service requests, or technical assistance regarding your Bajaj Majesty EPX9 Electric Pressure Cooker, please contact Bajaj customer service. Refer to the warranty card or Bajaj's official website for contact details.

Please have your model number (EPX9) and purchase details ready when contacting support.

© 2023 Bajaj. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01G1YWALA

More documents and user manuals: **https://manuals.plus/**