Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Luminox FP-3050-20-BPL

Luminox 3050 Series Black Rubber Watch Strap

Model: FP-3050-20-BPL

Introduction

This manual provides instructions for the installation, usage, and maintenance of your Luminox 3050 Series Black Rubber Watch Strap. This strap is designed as a direct replacement for compatible Luminox 3050 series watches, ensuring a secure and comfortable fit.

Installation

Proper installation is crucial for the secure attachment of your watch strap. It is recommended to use a spring bar tool for this process to prevent damage to your watch or the strap.

Tools Required:

- Spring Bar Tool
- Soft Cloth (for protecting watch surface)

Steps for Installation:

1. **Prepare Your Workspace:** Place your watch face down on a soft, clean cloth to prevent scratches.
2. **Remove the Old Strap (if applicable):** Locate the spring bars connecting the old strap to the watch lugs. Using the fork end of the spring bar tool, gently compress one end of the spring bar and pull the strap away from the watch lug. Repeat for the other side of the strap and the second spring bar.
3. **Insert Spring Bars into New Strap:** If your new strap did not come with spring bars already inserted, carefully slide the spring bars into the channels at the ends of the new rubber strap.
4. **Attach the New Strap:** Insert one end of a spring bar into a lug hole on the watch case. Using the spring bar tool, compress the other end of the spring bar and guide it into the opposite lug hole. Ensure both ends of the spring bar are securely seated in the lug holes. Gently tug on the strap to confirm it is firmly attached.
5. **Repeat for Second Strap Piece:** Follow the same procedure to attach the second piece of the rubber strap to the other set of watch lugs.



Image: The Luminox 3050 Black Rubber Watch Strap, showcasing its design and tang buckle. This image represents the product being installed.

Operating and Usage

The Luminox 3050 Series Black Rubber Watch Strap features a classic tang buckle closure for secure wearing.

Wearing Your Watch:

1. **Position the Watch:** Place the watch on your wrist, ensuring the watch case is centered on the top of your wrist.
2. **Fasten the Buckle:** Thread the longer end of the strap through the tang buckle. Insert the tang (pin) into the desired hole on the strap.
3. **Secure the Keepers:** Slide the excess strap through the two strap keepers to hold it in place.
4. **Adjust for Comfort:** The strap should be snug enough to prevent the watch from sliding freely on your wrist, but not so tight as to cause discomfort or restrict circulation. Adjust the buckle hole as needed to find your ideal fit.

Maintenance

Proper care will extend the life and appearance of your Luminox rubber watch strap.

Cleaning:

- Clean the strap regularly with mild soap and lukewarm water.
- Use a soft cloth or brush to gently scrub away dirt and grime.
- Rinse thoroughly with clean water and pat dry with a soft, lint-free cloth.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the rubber material.

Storage:

- Store your watch and strap in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid prolonged exposure to chemicals, oils, and perfumes, which can degrade the rubber over time.

Water Resistance:

The strap material is water resistant. However, regular exposure to saltwater or chlorinated water should be followed by a rinse with fresh water to prevent material degradation.

Troubleshooting

If you encounter issues with your watch strap, consider the following common solutions:

- **Strap Not Fitting:** Ensure the strap width (23mm) matches your watch's lug width. Verify that the spring bars are correctly seated in the lug holes.
- **Discomfort on Wrist:** Adjust the strap to a looser or tighter hole. Ensure the strap is not too tight, which can cause irritation, or too loose, which can cause the watch to move excessively.
- **Strap Degradation:** Rubber straps can show signs of wear over time, especially with frequent use or exposure to harsh conditions. If the strap shows significant cracking, tearing, or discoloration, it may be time for a replacement.

Specifications

Brand	Luminox
Model Number	FP-3050-20-BPL
Material	Rubber
Color	Black
Band Width	23 millimeters
Clasp Type	Tang Buckle
Special Features	Wear Resistant, Water Resistant
Item Weight	0.28 g
Manufacturer	Luminox

Warranty and Support

For warranty information regarding your Luminox product, please refer to the official Luminox warranty documentation or visit the Luminox website. Specific warranty details may vary by region and purchase date.
If you require further assistance, have questions about your product, or need to initiate a warranty claim, please contact Luminox customer support directly. Contact information can typically be found on the official Luminox website or within your watch's original packaging.
For general product inquiries, you may also refer to theLuminox Brand Store on Amazon.

© 2023 Luminox. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01G6LVVFE

More documents and user manuals: **https://manuals.plus/**