Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Victrola V50-200 Red

Victrola Haley Retro Bluetooth Record Player & Multimedia Center User Manual

Model: V50-200 Red

1. Introduction

Thank you for choosing the Victrola Haley Retro Bluetooth Record Player & Multimedia Center. This versatile unit combines classic retro aesthetics with modern audio technology, allowing you to enjoy your favorite music from various sources. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

The Victrola Haley features a 3-speed belt-driven turntable, a CD player, an AM/FM radio, 3.5mm auxiliary input, and Bluetooth connectivity for wireless music streaming. Its built-in speakers deliver clear sound, making it a complete audio solution without requiring additional equipment.



Image 1.1: The Victrola Haley Retro Bluetooth Record Player in its vibrant red finish, showcasing its classic design with a record playing on the turntable.

2. Safety Information

Please read all safety and operating instructions carefully before using this product. Keep these instructions for future reference.

- **Power Source:** Operate this product only from the type of power source indicated on the marking label.
- **Water and Moisture:** Do not use this product near water (e.g., near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool).
- **Ventilation:** Slots and openings in the cabinet are provided for ventilation. Do not block or cover these openings.
- **Heat:** Locate the product away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.
- **Cleaning:** Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners.

- **Object and Liquid Entry:** Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
- **Damage Requiring Service:** Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

  1. When the power-supply cord or plug is damaged.
  2. If liquid has been spilled, or objects have fallen into the product.
  3. If the product has been exposed to rain or water.
  4. If the product does not operate normally by following the operating instructions.
  5. If the product has been dropped or damaged in any way.

3. What's in the Box

Upon opening your Victrola Haley Retro Bluetooth Record Player & Multimedia Center, please ensure all the following components are present:

- Victrola Haley Retro Bluetooth Record Player
- Instruction Manual
- Warranty (located on the back of the manual)
- 45 RPM Adapter

If any items are missing or damaged, please contact customer support immediately.

4. Product Overview

4.1. Components and Controls

Familiarize yourself with the various parts and controls of your Victrola Haley unit:

VICTROLA™

The Original Revolution in Sound



Image 4.1: Close-up of the front panel, showing the volume knob, tuning knob, function buttons, and digital display.

- **Turntable:** Located under the hinged dust cover, for playing vinyl records.
- **Tone Arm:** Holds the stylus (needle) for playing records.
- **Spindle:** Center post for placing records.
- **45 RPM Adapter:** Used for playing 7-inch records with a large center hole.
- **Dust Cover:** Protects the turntable from dust.
- **Volume Knob:** Controls the overall sound output level.
- **Tuning Knob:** Used to tune AM/FM radio stations.
- **Function Button:** Selects between PHONO (Turntable), CD, FM, AM, AUX, and Bluetooth modes.
- **Digital Display:** Shows current mode, radio frequency, and CD track information.
- **CD Player:** Front-loading tray for compact discs.
- **Control Buttons (CD):** Play/Pause, Stop, Skip Forward, Skip Backward, Open/Close.
- **Built-in Speakers:** Integrated speakers for audio output.
- **Auxiliary Input (3.5mm):** For connecting external audio devices.
- **Headphone Jack:** For private listening.

4.2. Dimensions

The compact design of the Victrola Haley allows for flexible placement in your home or office.



Image 4.2: Diagram illustrating the product dimensions: approximately 13 inches (width) x 7 inches (height) x 15 inches (depth).

5. Setup Guide

1. **Unpacking:** Carefully remove the unit from its packaging. Retain the packaging materials for future transport or storage.
2. **Placement:** Place the unit on a flat, stable surface away from direct sunlight, heat sources, and excessive dust or moisture. Ensure adequate ventilation around the unit.
3. **Power Connection:** Plug the AC power cord into a wall outlet.
4. **Initial Power On:** Press the POWER button to turn on the unit. The digital display will illuminate.

6. Operating Instructions

6.1. Playing Records

1. Lift the dust cover.
2. Place a record on the turntable platter. If playing a 7-inch single, place the 45 RPM adapter on the spindle first.
3. Select the appropriate speed (33 1/3, 45, or 78 RPM) using the speed selector switch.
4. Gently lift the tone arm using the cueing lever and position the stylus over the desired track of the record.
5. Lower the tone arm slowly onto the record using the cueing lever. The record will begin to play.
6. Adjust the volume using the VOLUME knob.
7. When the record finishes, the tone arm will automatically return to its rest (auto-stop function). To stop playback manually, lift the tone arm and return it to its rest.

6.2. Using the CD Player

1. Press the FUNCTION button to select CD mode.
2. Press the OPEN/CLOSE button to open the CD tray.
3. Place a CD with the label side facing up into the tray.
4. Press the OPEN/CLOSE button again to close the tray. The unit will read the disc.
5. Press the PLAY/PAUSE button to start playback.
6. Use the SKIP buttons to navigate between tracks.
7. Press the STOP button to stop playback.



Image 6.1: The front-loading CD tray extended, ready for disc insertion.

6.3. Listening to AM/FM Radio

1. Press the FUNCTION button to select FM or AM mode.
2. Extend the FM wire antenna fully for better reception. For AM, rotate the unit for optimal reception.
3. Use the TUNING knob to tune to your desired radio station. The frequency will be displayed on the digital screen.

6.4. Bluetooth Streaming

The Victrola Haley allows you to wirelessly stream music from your Bluetooth-enabled devices.



Image 6.2: A black Victrola Haley unit with a smartphone icon and Bluetooth symbol, indicating wireless music streaming capability.

1. Press the FUNCTION button to select Bluetooth mode. The display will show "BT" and flash, indicating it's in pairing mode.
2. Enable Bluetooth on your external device (e.g., smartphone, tablet).
3. Search for "VICTROLA" in your device's Bluetooth list and select it to pair.
4. Once paired, the "BT" indicator on the unit's display will stop flashing and remain solid.
5. You can now play music from your external device, and the audio will be streamed through the Victrola Haley's speakers.

6.5. Using the Auxiliary Input

1. Connect one end of a 3.5mm audio cable (not included) to the AUX IN jack on the front of the unit.
2. Connect the other end of the cable to the headphone jack or audio output of your external audio device (e.g., MP3 player, smartphone).
3. Press the FUNCTION button to select AUX mode.
4. Play music from your external device. The audio will be played through the Victrola Haley's speakers.

7. Maintenance and Care

- **Cleaning the Unit:** Wipe the exterior of the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Dust Cover:** Keep the dust cover closed when not in use to prevent dust accumulation on the turntable.
- **Stylus Care:** The stylus is delicate. Avoid touching it with your fingers. Clean the stylus periodically with a soft brush, brushing from back to front.
- **Record Care:** Keep your records clean and free of dust to ensure optimal sound quality and prolong stylus life.

8. Troubleshooting

Problem	Possible Cause	Solution
No power	Unit not plugged in; Power outlet not active.	Ensure power cord is securely plugged into a working outlet.
No sound	Volume too low; Incorrect function mode selected.	Increase volume. Press FUNCTION button to select correct mode (PHONO, CD, FM, AM, AUX, BT).
Turntable not spinning	Unit not in PHONO mode; Tone arm not positioned correctly.	Select PHONO mode. Ensure tone arm is lifted and positioned over the record.
Bluetooth not connecting	Unit not in BT mode; Device not in pairing mode; Already connected to another device.	Select BT mode. Ensure your device's Bluetooth is on and searching. Disconnect from other devices.
Poor radio reception	Antenna not extended/positioned correctly.	Fully extend the FM wire antenna. Rotate the unit for better AM reception.

9. Technical Specifications

- **Model Name:** 50's Retro
- **Model Number:** V50-200 Red
- **Product Dimensions:** 13 x 7 x 15 inches
- **Item Weight:** 8.65 pounds
- **Brand:** Victrola
- **Manufacturer:** Innovative Technology
- **Connectivity Technology:** Auxiliary, Bluetooth
- **Maximum Rotational Speed:** 78 RPM (supports 33 1/3, 45, 78 RPM)
- **Material:** Plastic
- **Special Features:** AUX Input, Built-in Speaker

- **Power Consumption (On-mode):** 19 watts

10. Warranty and Support

Your Victrola Haley Retro Bluetooth Record Player & Multimedia Center comes with a manufacturer's warranty. Please refer to the warranty information provided on the back of this instruction manual for details regarding coverage and terms.

For technical support, troubleshooting assistance, or inquiries about replacement parts, please visit the official Victrola website or contact their customer service department. You may also find additional resources and FAQs on their support page.

An official User Manual in PDF format is available for download at:
https://manuals.plus/m/b97b39d69125e12a147f9de990920f40a82e8e1ea7b627ede64d720a70a20f08

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question