Makita M0600B

Makita M0600B AC Drill User Manual

Model: M0600B | Brand: Makita

1. Introduction

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Makita M0600B AC Drill. Please read this manual thoroughly before using the tool to ensure optimal performance and user safety.
The Makita M0600B is a high-performance AC drill designed for various drilling applications. Key features include:

- High performance and durability at less expense.
- Powerful 350 W motor for continuous operation.
- In-line positive grip design maximises power thrust.
- Compact and lightweight for reduced operator fatigue.
- Recessed lock-on button for continuous use.

2. Safety Instructions

Always observe basic safety precautions to reduce the risk of fire, electric shock, and personal injury. Keep this manual for future reference.

- **Work Area Safety:** Keep your work area clean and well-lit. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- **Electrical Safety:** Power tool plugs must match the outlet. Never modify the plug in any way. Avoid body contact with earthed or grounded surfaces. Do not expose power tools to rain or wet conditions.
- **Personal Safety:** Always wear eye protection, hearing protection, and appropriate clothing. Do not overreach. Stay alert and use common sense when operating a power tool.
- **Tool Use and Care:** Do not force the power tool. Use the correct power tool for your application. Disconnect the plug from the power source before making any adjustments, changing accessories, or storing power tools.
- **Service:** Have your power tool serviced by a qualified repair person using only identical replacement parts.

3. Product Components

Familiarize yourself with the parts of your Makita M0600B AC Drill.



Figure 3.1: Overview of the Makita M0600B AC Drill, showing the main body, chuck, ventilation slots, trigger, and ergonomic handle.



Figure 3.2: Detail of the drill's handle and trigger mechanism, highlighting the recessed lock-on button for continuous operation.



Figure 3.3: The included depth gauge accessory, used to control drilling depth for precise applications.

4. Setup

4.1 Attaching the Side Handle (if applicable)

The side handle provides additional control and stability. Loosen the handle grip, slide it over the chuck and onto the drill body, then tighten it securely in the desired position.

4.2 Installing the Depth Gauge

Insert the depth gauge into the hole on the side handle. Adjust its position to set the desired drilling depth. Ensure it is firmly secured before operation.

4.3 Installing or Removing Drill Bits

1. Ensure the drill is unplugged from the power source.
2. Open the chuck jaws by rotating the chuck key (if applicable) or by hand for keyless chucks.
3. Insert the drill bit fully into the chuck.
4. Tighten the chuck jaws firmly around the drill bit using the chuck key or by hand. Ensure the bit is centered and secure.
5. To remove, reverse the process.

4.4 Power Connection

Connect the drill's power cord to a suitable 220V AC power outlet. Ensure the power outlet is grounded and in good

condition.

5. Operating the Drill

Always wear appropriate personal protective equipment (PPE) including safety glasses and hearing protection before operating the drill.



Figure 5.1: The Makita M0600B drill being used to drill into a metal surface, demonstrating its application.

5.1 Turning On/Off

- To start the drill, press the trigger switch.
- To stop, release the trigger switch.
- For continuous operation, press the trigger switch and then press the lock-on button. To release, press the trigger switch again.

5.2 Variable Speed Control

The drill features variable speed control, allowing you to adjust the drilling speed based on the material and application. The speed is controlled by the pressure applied to the trigger switch. More pressure results in higher speed.

5.3 Drilling Techniques

- **General Drilling:** Apply steady, even pressure. Do not force the drill. Allow the drill bit to do the work.
- **Starting a Hole:** For smooth surfaces, use a center punch to create a small indentation to prevent the drill bit from wandering.
- **Drilling Metal:** Use appropriate drill bits for metal. Apply cutting oil to cool the bit and improve drilling efficiency.
- **Drilling Wood:** Use wood-specific drill bits. Clear chips frequently to prevent clogging.

6. Maintenance

Regular maintenance ensures the longevity and safe operation of your drill.

6.1 Cleaning

- Always unplug the drill before cleaning.
- Use a soft cloth to wipe down the exterior of the tool.
- Keep the ventilation openings clear to prevent overheating. Use compressed air if necessary to blow out dust from the vents.

6.2 Storage

- Store the drill in a clean, dry place, out of reach of children.
- Protect the power cord from damage. Do not wrap it tightly around the tool.

6.3 Power Cord Inspection

Periodically inspect the power cord for any signs of damage, cuts, or fraying. If damaged, have it repaired by a qualified service center to avoid electrical hazards.

7. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Drill does not start.	No power supply; damaged cord; faulty switch.	Check power outlet and cord. If still not working, seek professional service.
Drill bit wobbles.	Bit not properly secured; bent drill bit.	Re-insert and tighten bit. Replace bent bits.
Overheating during use.	Blocked ventilation; excessive load.	Clear vents. Reduce pressure and allow tool to cool.
Reduced drilling performance.	Dull drill bit; incorrect bit for material.	Replace or sharpen drill bit. Use appropriate bit for the material.

If the problem persists after attempting these solutions, please contact a qualified service technician.

8. Specifications

Technical specifications for the Makita M0600B AC Drill:

Model:	M0600B
Power Source:	Corded Electric
Voltage:	220 Volts
Wattage:	350 Watts
Maximum Speed:	3000 RPM
Weight:	1.2 Kilograms
Dimensions (L x W x H):	17.6 x 6.6 x 23 cm
Material:	Plastic, Aluminum, Rubber
Included Components:	1 x AC Drill
Special Features:	Variable Speed

9. Warranty and Support

For information regarding warranty coverage, service centers, or technical support for your Makita M0600B AC Drill, please refer to the warranty card included with your purchase or visit the official Makita website. Keep your proof of purchase for warranty claims.
For further assistance, you may contact Makita customer service directly.

© 2024 Makita. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question