2BOOM 4326553574

2BOOM Boom Go Wireless Bluetooth Portable Speaker

User Manual

Model: 4326553574

Introduction

Thank you for purchasing the 2BOOM Boom Go Wireless Bluetooth Portable Speaker. This manual provides important information regarding the setup, operation, and maintenance of your speaker. Please read it thoroughly before use and retain it for future reference.



The 2BOOM Boom Go speaker in black, showcasing its compact, pill-shaped design.

Key Features:

- Equipped with Bluetooth 2.1 Technology for wireless connectivity.
- Compatible with Bluetooth-enabled devices such as smartphones, notebooks, tablets, and MP3 players.
- Up to 4 hours of wireless play on a single charge.
- Delivers incredible sound quality with rich bass.
- Solid, rubberized, rugged, durable, and ultra-portable construction for indoor and outdoor use.
- Built-in microphone for hands-free calls and voice assistant commands.
- Multiple connectivity options: Bluetooth, USB, and Auxiliary (AUX).

Package Contents

Before you begin, please check the package for the following items:



The image displays the 2BOOM Boom Go speaker, an AUX cable, a USB charging cable, and the user manual, which are all included in the product package.

- 2BOOM Boom Go Portable Bluetooth Speaker
- USB Charging Cable
- Auxiliary (AUX) Cable
- User Manual (this document)

Product Overview

Familiarize yourself with the various parts and controls of your 2BOOM Boom Go speaker:



This diagram illustrates the top and rear view of the speaker, labeling key components: Hands-Free Microphone, Charging Port, USB Port, AUX Port, Power On/Off button, Play/Pause/Switch Music Mode button, Volume Down/Previous Track button, and Volume Up/Next Song button.

- **Power On/Off Button:** Located on the side, used to turn the speaker on or off.
- **Play/Pause/Switch Music Mode Button:** Controls playback and switches between input modes (Bluetooth, USB, AUX).
- **Volume Down / Previous Track Button:** Decreases volume or skips to the previous song.
- **Volume Up / Next Song Button:** Increases volume or skips to the next song.
- **Charging Port:** Micro USB port for charging the speaker's internal battery.
- **USB Port:** For playing music directly from a USB drive.
- **AUX Port:** 3.5mm audio input for connecting devices via an auxiliary cable.
- **Hands-Free Microphone:** For making and receiving phone calls.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB charging cable to the speaker's Charging Port and

the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will illuminate during charging and turn off when fully charged.
Note: The speaker can be used while charging.

2. Powering On/Off

To turn the speaker **ON**, press and hold the Power On/Off button until you hear an audible prompt or see an indicator light. To turn the speaker **OFF**, press and hold the Power On/Off button again.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode. The speaker will typically enter pairing mode automatically when powered on for the first time or if no device is connected. An indicator light may flash to show it's ready to pair.
2. On your Bluetooth-enabled device (smartphone, tablet, etc.), go to the Bluetooth settings and enable Bluetooth.
3. Search for available devices. You should see "2BOOM Boom Go" or a similar name in the list.
4. Select "2BOOM Boom Go" to connect. Once successfully paired, you will hear a confirmation sound, and the indicator light will become solid.
5. If prompted for a password, enter "0000".

Note: The speaker will automatically attempt to reconnect to the last paired device when powered on.

4. Connecting via AUX Input

To play audio from a device without Bluetooth, use the supplied 3.5mm auxiliary cable. Connect one end of the cable to the AUX Port on the speaker and the other end to the headphone jack or audio output of your device. The speaker will automatically switch to AUX mode, or you may need to press the Play/Pause/Switch Music Mode button to cycle to AUX mode.

5. Connecting via USB Input

To play audio from a USB flash drive, insert the USB drive into the USB Port on the speaker. The speaker will automatically switch to USB mode and begin playing compatible audio files, or you may need to press the Play/Pause/Switch Music Mode button to cycle to USB mode.

Operating Instructions

Music Playback:

- **Play/Pause:** Press the Play/Pause/Switch Music Mode button once to play or pause the current track.
- **Next Track:** Press the Volume Up / Next Song button once to skip to the next track.
- **Previous Track:** Press the Volume Down / Previous Track button once to go to the beginning of the current track, or press twice to go to the previous track.
- **Volume Up:** Press and hold the Volume Up / Next Song button to increase the volume.
- **Volume Down:** Press and hold the Volume Down / Previous Track button to decrease the volume.

Hands-Free Calling:

When connected via Bluetooth to your smartphone, the speaker's built-in microphone allows for hands-free calling.

- **Answer Call:** Press the Play/Pause/Switch Music Mode button once to answer an incoming call.
- **End Call:** Press the Play/Pause/Switch Music Mode button once during a call to end it.
- **Reject Call:** Press and hold the Play/Pause/Switch Music Mode button to reject an incoming call.

- **Redial Last Number:** Double-press the Play/Pause/Switch Music Mode button to redial the last dialed number.

Switching Modes:

To switch between Bluetooth, USB, and AUX input modes, short press the Play/Pause/Switch Music Mode button. The speaker will announce the current mode or indicate it via an LED.

Maintenance

Cleaning:

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. Avoid exposing the speaker to excessive dust or dirt.

Storage:

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to fully charge the battery every few months to maintain its lifespan.

Battery Care:

To prolong the battery life, avoid fully discharging the speaker frequently. Charge the speaker regularly, even if not in constant use. Do not expose the battery to high temperatures or attempt to disassemble it.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker using the supplied USB cable.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; Device Bluetooth is off; Speaker is already connected to another device; Device is too far from speaker.	Ensure speaker is in pairing mode; Turn on Bluetooth on your device; Disconnect from other devices; Move device closer to speaker (within 10 meters).
No sound from speaker.	Volume is too low; Incorrect input mode selected; Device is not playing audio.	Increase speaker and device volume; Press Play/Pause/Switch Music Mode button to cycle through modes; Ensure audio is playing on your connected device.
Poor audio quality.	Device is too far from speaker; Obstructions between device and speaker; Low battery.	Move device closer; Remove obstructions; Charge the speaker.

Specifications

Feature	Detail
Model	4326553574
Brand	2BOOM

Feature	Detail
Speaker Type	Portable, Outdoor
Connectivity Technology	Bluetooth, USB, Auxiliary
Bluetooth Version	2.1
Battery Life	Up to 4 hours
Color	Black
Control Type	Button
Max Speaker Output Power	3 Watts
Audio Output Mode	Stereo
Product Dimensions	25.15 x 18.03 x 6.6 cm (9.9 x 7.1 x 2.6 inches)
Item Weight	439.98 g (0.97 lbs)

Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product packaging or visit the official 2BOOM website. Keep your purchase receipt as proof of purchase for any warranty claims.
If you encounter any issues not covered in this manual or require further assistance, please contact 2BOOM customer support through their official channels. Contact information can typically be found on the product packaging or the manufacturer's website.

© 2024 2BOOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question