iPro 0714000000000

iPro Mini Cell Phone User Manual

Model: 0714000000000
Brand: iPro

Introduction

This manual provides comprehensive instructions for the operation and maintenance of your iPro Mini Cell Phone. Designed for ease of use, this 2G GSM phone is factory unlocked and features dual SIM capability, a keyboard, camera, flashlight, and an SD card slot, making it suitable as a budget or backup phone for various users.
Please read this manual carefully before using your device to ensure proper function and longevity.

What's in the Box

Upon opening the package, please verify that all the following items are included:

- iPro Mini Cell Phone x 1
- Charger (American type: 5V, 500mAh) x 1
- USB Cable (L=0.8 M) x 1
- User Manual x 1
- Battery (BL-4C 800mAh) x 1
- Box x 1



Image: The iPro Mini Cell Phone, its charger, USB cable, and packaging box, illustrating the complete contents of the product package.

Setup

1. Battery Installation

1. Remove the back cover of the phone by gently prying it open from the notch.
2. Insert the BL-4C 800mAh battery into the battery compartment, ensuring the gold contacts align with the phone's terminals.
3. **Important:** Before first use, ensure you have removed the insulating film from the top of the battery.
4. Replace the back cover, pressing firmly until it clicks into place.

2. SIM Card and SD Card Installation

The iPro Mini supports dual standard SIM cards and an external memory card (not included).

1. With the back cover and battery removed, locate the SIM card slots (SIM1 and SIM2) and the SD card slot.
2. Carefully insert your standard SIM cards into the designated slots. Ensure the cut corner of the SIM card aligns with the slot's orientation.
3. If desired, insert a compatible external memory card into the SD card slot.
4. Reinstall the battery and back cover.



Image: The rear of the phone with the battery cover open, revealing the two standard SIM card slots and the memory card slot for expansion.

3. Charging the Battery

1. Connect the small end of the USB cable to the Micro USB port at the bottom of the phone.
2. Connect the larger end of the USB cable to the charger adapter.
3. Plug the charger adapter into a power outlet.
4. Allow the phone to charge fully before first use. The charging indicator on the screen will show the charging status.



Image: A close-up of the phone's bottom edge, highlighting the Micro USB port for charging and data transfer, and the 3.5mm headphone jack.

4. Powering On/Off

- To power on: Press and hold the Power/End Call button (usually marked with a red phone icon or power symbol) until the screen lights up.
- To power off: Press and hold the Power/End Call button until the power-off options appear on the screen. Select "Power off" and confirm.

Operating Instructions

Basic Phone Functions

- **Making a Call:** Enter the phone number using the keypad and press the Call button (green phone icon).
- **Answering a Call:** When the phone rings, press the Call button.
- **Ending a Call:** Press the End Call button (red phone icon).
- **Adjusting Volume:** Use the navigation keys (up/down) during a call or when playing media to adjust volume.

Messaging (SMS)

- Navigate to the "Messages" menu from the main screen.
- Select "Write message" or "New SMS".
- Enter the recipient's number and type your message using the keypad.
- Press "Send" to dispatch the message.

Camera Usage

The phone is equipped with a 0.08MP main camera.

- Access the camera application from the main menu.
- Frame your shot using the screen as a viewfinder.
- Press the center navigation key or a designated camera button to capture a photo.



Image: The front of the iPro Mini phone, displaying its screen and physical keypad, with the rear camera lens visible on the pink back cover.

FM Radio

The iPro Mini includes an FM radio function. You may need to connect a 3.5mm earphone (not included) to act as an antenna for optimal reception.

- Navigate to the "FM Radio" application in the menu.
- Connect earphones if prompted or if reception is poor.
- Use the navigation keys to scan for stations or tune manually.

Flashlight

The phone features a built-in flashlight.

- To activate/deactivate the flashlight, typically press and hold the center navigation key or a dedicated flashlight button (refer to phone's on-screen prompts).



Image: A close-up of the top edge of the phone, clearly showing the small, circular flashlight LED.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid using liquid cleaners or aerosols.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Do not expose the battery to high temperatures or dispose of it in fire. Recycle batteries responsibly.
- **Water Resistance:** This phone is not water-resistant. Avoid exposure to liquids.

Troubleshooting

Problem	Possible Cause / Solution
Phone does not power on.	Battery may be depleted. Charge the phone for at least 30 minutes. Ensure the insulating film has been removed from the battery terminals.
Cannot make or receive calls.	Check if SIM card is properly inserted. Verify network signal strength. Contact your service provider if issues persist.
Poor call quality.	Move to an area with better network coverage. Check for obstructions.

Problem	Possible Cause / Solution
Battery drains quickly.	Excessive use of features like flashlight or prolonged calls. Reduce screen brightness.
Cannot connect to network.	Ensure you are within 2G GSM 850/900/1800/1900 MHz coverage. Check SIM card status.

Specifications

Feature	Detail
Brand	iPro
Model	iPro I3185 (0714000000000)
Display	1.77 inches, 128x160 resolution
Network	2G GSM 850/900/1800/1900 MHz
SIM	Dual Standard SIM
Camera	Main Camera: 0.08MP FF
Memory	32MB RAM + 32MB ROM, External memory support (SD card)
Connectivity	Bluetooth 3.0, USB 2.0, Micro USB, 3.5mm Audio Jack
Battery	BL-4C 800mAh
Dimensions	111.5 x 50 x 13.6 mm
Other Functions	FM Radio, Flashlight, Handsfree Speaker
Languages	English (default), Portuguese, Spanish



Image: A composite image showing the iPro Mini phone from the front, its slim profile from the side, and the textured back cover, providing a complete visual overview of the device.

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact iPro customer service. While software updates are not guaranteed for this model, the manufacturer strives to provide reliable performance.
Please retain your proof of purchase for any warranty claims.

© 2024 iPro. All rights reserved.