Hamzer 2089

Hamzer 61 Key Beginner Electronic Keyboard Piano Instruction Manual

Model: 2089

1. Product Overview

The Hamzer 61 Key Electronic Keyboard Piano is designed for beginner to intermediate musicians. It features 61 standard keys, built-in speakers, and a variety of sounds and rhythms to enhance the learning and playing experience. This portable digital piano includes a microphone and keynote stickers to assist with musical development.



Image: Top-down view of the Hamzer 61 Key Electronic Keyboard Piano, showcasing its keys, control panel, built-in speakers, and an attached music stand. The display shows '120'.

2. What's in the Box

- Electronic Keyboard
- Microphone with 4' cord
- Sheet Music Stand
- DC 9V/AC Power Adapter
- Owner's Manual

3. Setup Guide

3.1 Power Connection

The keyboard can be powered in two ways:

- **AC Adapter:** Connect the provided DC 9V/AC adapter to the keyboard's power input jack and then plug it into a standard US wall outlet.
- **Batteries:** For portable use, insert 6 AA batteries (not included) into the battery compartment located on the underside of the keyboard. Ensure correct polarity.

3.2 Microphone Connection

Connect the microphone's 3.5mm jack into the dedicated microphone input port on the keyboard. This allows for vocal accompaniment while playing.



Image: A black microphone with its cord and 3.5mm jack, indicating its inclusion with the keyboard.

3.3 Keynote Sticker Application

The keyboard includes a complete set of transparent stickers to label the piano keys. These stickers can simplify and accelerate piano mastery for beginners by visually indicating note names.



Image: A close-up view of the white keys on the keyboard with transparent stickers applied, displaying musical notes and corresponding letter names (e.g., C, D, E).

3.4 Music Stand Attachment

Insert the included sheet music stand into the designated slots on the top of the keyboard. This provides a stable platform for holding sheet music or a tablet.

4. Operating Instructions

4.1 Power On/Off and Volume Control

- **Power:** Press the 'POWER' button to turn the keyboard on or off.
- **Master Volume:** Use the 'MASTER VOL' controls (usually '+' and '-') to adjust the overall volume of the keyboard.
- **Accompanying Volume:** Adjust the volume of the accompaniment tracks using the 'ACCOMP VOL' controls.

4.2 Selecting Timbres (Sounds)

The keyboard offers 255 different Timbres (instrument sounds). Use the 'TIMBRE' selection buttons and the numeric keypad to select your desired sound. Refer to the list printed on the keyboard for corresponding numbers.

4.3 Selecting Rhythms

Choose from 255 built-in rhythms. Use the 'RHYTHM' selection buttons and the numeric keypad to select a rhythm. Refer to the list printed on the keyboard for corresponding numbers.

4.4 Playing Demonstration Songs

The keyboard includes 24 demonstration songs. Press the 'DEMO' button to cycle through and play these pre-recorded melodies.

4.5 Using Effects and Controls

- **Vibrato:** Adds a pulsating effect to the sound.
- **Sustain:** Lengthens the decay of notes.
- **Ensemble:** Creates a richer, fuller sound.
- **Rhythm Sync and Fill-in:** Synchronize the rhythm start with your playing or add short rhythmic fills.
- **Tempo:** Adjust the speed of rhythms and demonstration songs using the 'TEMPO' controls.

4.6 Record & Playback

The keyboard features a record and playback function, allowing you to record your performances and listen back for self-assessment and improvement.

- **Record:** Press the 'REC' button to start recording your playing.
- **Playback:** Press the 'PLAY' button to listen to your recorded performance.

4.7 Headphone Use

For private practice, connect headphones to the 3.5mm headphone jack. This mutes the built-in speakers, allowing for discreet playing.

4.8 Integrated Learning System

The keyboard is designed with an integrated learning system, including features like keynote stickers and teaching modes (refer to the specific buttons on the control panel) to guide beginners through piano mastery.



Image: A hand adjusting the controls on the keyboard, highlighting the various buttons for customizing sounds and rhythms.

5. Maintenance

- **Cleaning:** Wipe the keyboard surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

- **Battery Care:** If using batteries, remove them if the keyboard will not be used for an extended period to prevent leakage.

6. Troubleshooting

- **No Sound:** Ensure the keyboard is powered on and the master volume is turned up. Check headphone connection if applicable.
- **Distorted Sound:** Lower the volume. Ensure the power adapter is correctly connected or batteries are fresh.
- **Keyboard Not Responding:** Turn the power off and then on again. If using batteries, replace them.

7. Specifications

Feature	Detail
Model Name	2089-BLACK
Number of Keys	61
Dimensions	33.5"D x 13"W x 4"H
Item Weight	7 pounds
Power Source	Battery Powered (6 AA batteries), Corded Electric (DC 9V/AC adapter)
Connectivity Technology	Auxiliary
Headphones Jack	3.5mm Jack
Skill Level	Beginner, Intermediate, Student
Body Material	Plastic

8. Warranty and Support

For warranty information, product support, or to purchase replacement parts, please refer to the contact details provided in your purchase documentation or visit the official Hamzer website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is the Hamzer 61 Key Beginner Electronic Keyboard Piano (Model 2089) not making sound, despite trying everything in the manual and using other apps?

Based on the Hamzer 61 Key Beginner Electronic Keyboard Piano (Model 2089) instruction manual, if your device is not making sound, please check the following troubleshooting steps: Power and Volume: Ensure the keyboard is...

Read full answer