iJoy 43156

iJoy Bluetooth Headphones User Manual

Model: 43156 | Brand: iJoy

Introduction

Thank you for choosing iJoy Bluetooth Headphones. This manual provides detailed instructions to help you set up, operate, and maintain your new headphones. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Image: The iJoy Bluetooth Headphones in pink, showcasing their over-ear design, foldable headband, and included charging and auxiliary cables.

Key Features

- **Versatile Connectivity:** Enjoy seamless audio with ultra-fast Bluetooth connection or use the included auxiliary cable for wired listening.
- **Extended Playtime:** Up to 20 hours of wireless playback on a single charge, with a quick 2-hour charging time.
- **Integrated Functions:** Built-in microphone for hands-free calling, FM radio receiver, and a Micro SD card slot for direct music playback.
- **Comfort & Portability:** Features memory protein ear cups for noise isolation, an adjustable headband for a comfortable fit, and a foldable design for easy storage and transport.
- **Intuitive Controls:** A 5-button panel allows for easy control of playback, volume, equalization, and mode switching.

Vibrant Sound & Noise Isolation



Image: A close-up view of the headphone's ear cup, illustrating the vibrant sound quality and deep bass response. Icons for Bluetooth, FM radio, auxiliary input, and Micro SD card are visible.



Image: A woman wearing the headphones in a busy office environment, demonstrating the noise-cancelling design that helps block out distractions.

Adjustable Fit & Compact Design



Image: A diagram highlighting the adjustable headband, snug pad, and memory-protein earmuffs for a comfortable and customizable fit.



Image: The headphones folded into a compact size, placed next to a gym bag and weights, illustrating their portability and space-saving design.

Official Product Video

Video: An official product video from iJoy showcasing the features and design of the headphones.

Setup

Charging the Headphones

Before first use, fully charge your headphones. A full charge takes approximately 2 hours.

1. Connect the charging cable (Type-C to USB) to the charging port on the headphone.
2. Connect the USB end of the cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
3. The indicator light will illuminate during charging and turn off when fully charged.

Bluetooth Pairing

1. Ensure the headphones are fully charged.
2. Slide the power switch to the 'ON' position. The indicator light will flash, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "iJoy Headphones" from the list of found devices.
5. Once connected, the indicator light will stop flashing or change to a solid color (refer to indicator light section for details).

Wired Connection (Auxiliary Cable)

Use the auxiliary cable for a direct wired connection, especially when the battery is low or for devices without Bluetooth.

1. Plug one end of the 3.5mm auxiliary cable into the AUX port on the headphone.
2. Plug the other end of the cable into the 3.5mm audio jack of your device.
3. The headphones will automatically switch to wired mode. Note: Button controls on the headphones may not function in wired mode.

Operating Instructions



Image: A detailed diagram showing the location and function of each button and port on the headphone's control panel.

Button Panel Functions

- **Play/Pause/Answer/Hangup Button:** Press once to play/pause music. Press once to answer an incoming call. Press once during a call to hang up.
- **Equalizer (EQ) Button:** Press to cycle through different equalizer presets (e.g., bass boost, vocal, normal).
- **Next Track/Volume Up (+):** Press once to skip to the next track. Press and hold to increase volume.
- **Previous Track/Volume Down (-):** Press once to go to the previous track. Press and hold to decrease volume.
- **Bluetooth/FM Mode (M):** Press to switch between Bluetooth mode and FM radio mode.

FM Radio Mode

1. Switch to FM mode using the 'M' button.
2. Press and hold the Play/Pause button to auto-scan and save available FM stations.
3. Use the Next Track (+) and Previous Track (-) buttons to navigate between saved stations.

Micro SD Card Playback

1. Insert a Micro SD card with pre-loaded music into the Micro SD card slot.
2. The headphones will automatically switch to Micro SD playback mode.
3. Use the Play/Pause, Next Track (+), and Previous Track (-) buttons to control playback.

Maintenance

- **Cleaning:** Wipe the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, fold the headphones and store them in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, charge the headphones regularly, even if not used for extended periods. Avoid fully discharging the battery frequently.

Troubleshooting

Problem	Possible Cause	Solution
Headphones won't turn on	Low battery	Charge the headphones fully.
Cannot pair via Bluetooth	Headphones not in pairing mode / Device Bluetooth off / Too far from device	Ensure headphones are in pairing mode (flashing indicator). Turn device Bluetooth on/off. Move headphones closer to device.
No sound in wired mode	Auxiliary cable not fully inserted / Cable damaged / Device volume low	Ensure cable is fully inserted. Try a different auxiliary cable. Increase device volume.
FM radio static or poor reception	Weak signal / Interference	Move to an open area. Re-scan for stations.
Short battery life	Battery degradation / High volume usage	Ensure full charge. Reduce volume. Consider battery replacement if degradation is significant.

Specifications

Feature	Detail
Model Number	43156
Connectivity	Bluetooth, Wired (3.5mm AUX)
Wireless Communication Technology	Bluetooth
Battery Life	Up to 20 hours
Charging Time	2 hours

Feature	Detail
Headphones Jack	3.5 mm Jack
Built-in Features	Microphone, FM Radio, Micro SD Card Slot
Control Type	Volume Control, Track Skip, Mode Switch, Equalizer
Earpiece Shape	Over Ear
Noise Control	Sound Isolation
Product Dimensions	5.98 x 5.91 x 3.31 inches
Item Weight	9.6 ounces
UPC	811924023927, 646412563247

Warranty and Support

These iJoy headphones come with a 6-month exchange warranty provided by Pranx, the seller. If your headset breaks or is damaged for any reason within this period, Pranx will provide a free replacement.
For any support inquiries, troubleshooting assistance beyond this manual, or warranty claims, please contact the seller directly through your purchase platform.

© 2025 iJoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question