Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy FBA_FGE-PRE-AVT

iJoy Bluetooth Headphones Instruction Manual

Model: FBA_FGE-PRE-AVT

Product Overview

The iJoy Bluetooth Headphones are versatile over-ear headphones designed for both wireless and wired use. They feature Bluetooth connectivity, a built-in microphone for hands-free calling, FM radio, and a Micro SD card slot for direct music playback. The foldable design enhances portability, and the memory protein ear cups provide comfort for extended wear.



Front view of the iJoy Bluetooth Headphones, showcasing their over-ear design and blue color.

What's in the Box

- Wireless headphones
- Auxiliary cable
- Charging cable

Setup

Charging the Headphones

Before first use, fully charge your iJoy headphones.
Connect the included charging cable to the USB-C port on the headphone ear cup.

Connect the other end of the charging cable to a compatible USB power source.
The indicator light will show charging status. A full charge typically takes 2 hours.



This image highlights the various input ports on the headphone's ear cup, including the Micro SD card slot, USB-C charging port, and 3.5mm auxiliary input.

Powering On/Off

To power on, slide the power button located on the ear cup. The indicator light will illuminate.
To power off, slide the power button back to its original position.

Bluetooth Pairing

Ensure the headphones are powered on and in Bluetooth mode (indicated by a flashing blue/red light).
On your device (smartphone, tablet, laptop), enable Bluetooth and search for "iJoy Headphones" in the list of available devices.
Select "iJoy Headphones" to pair. Once connected, the indicator light will turn solid blue.

Operating Instructions

Basic Controls

The headphones feature a 5-button control panel on the ear cup for easy management of audio and calls.

- **Play/Pause/Answer/Hangup:** Press the central button.
- **Equalizer (EQ):** Press the EQ button to cycle through sound profiles.
- **Next Track/Volume Up:** Press the '+' button for next track, hold for volume up.
- **Previous Track/Volume Down:** Press the '-' button for previous track, hold for volume down.
- **Mode (M):** Press the 'M' button to switch between Bluetooth and FM radio modes.



This diagram illustrates the layout and function of the control buttons on the headphone's ear cup, providing a visual guide for operation.

FM Radio Mode

Press the 'M' button to switch to FM radio mode.
Use the '+' and '-' buttons to scan through available FM stations.

Micro SD Card Playback

Insert a Micro SD card with audio files into the designated slot.
The headphones will automatically switch to Micro SD card playback mode.

Wired Connection

Connect the auxiliary cable to the 3.5mm jack on the headphones and to your audio device.
This allows for wired listening even if the battery is depleted.

Maintenance

Cleaning

Wipe the headphones with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
For ear cups, gently wipe with a damp cloth and allow to air dry completely before use.

Storage

When not in use, fold the headphones for compact storage.
Store in a cool, dry place away from direct sunlight and extreme temperatures.



This image shows the headphones in their folded, compact state, highlighting their portability and ease of storage in a bag.

Troubleshooting

No Power

- Ensure the headphones are fully charged.
- Check the charging cable and power source for proper connection.

Cannot Pair via Bluetooth

- Ensure headphones are in pairing mode (flashing blue/red light).
- Make sure Bluetooth is enabled on your device.
- Move headphones closer to your device.
- Forget "iJoy Headphones" from your device's Bluetooth list and try pairing again.

No Sound

- Check volume levels on both headphones and your connected device.
- Ensure headphones are correctly paired or auxiliary cable is fully inserted.
- If using Micro SD card, ensure audio files are compatible.

Static in FM Radio

- Move to an open area for better signal reception.
- Adjust the position of the headphones to improve reception.

Specifications

Feature	Detail
Model Name	FBA_FGE-PRE-AVT
Connectivity Technology	Wireless, Wired (Bluetooth)
Battery Life	Up to 20 hours (Wireless)
Charging Time	2 hours
Headphones Jack	3.5 mm Jack
Special Features	Built-in Microphone, FM Radio, Micro SD Card Slot, Foldable Design
Item Weight	8.2 ounces
Product Dimensions	5.98 x 5.91 x 3.31 inches

Warranty and Support

This product comes with a 6-month exchange warranty. If your headset breaks or is damaged for any reason, Pranx will provide a FREE replacement.
For further assistance or support, please refer to the contact information provided with your purchase or visit the official iJoy website.

© 2024 iJoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I get the FM radio to work on my iJoy FBA_FGE-PRE-AVT Bluetooth Headphones?

To use the FM radio on your iJoy Bluetooth headphones, follow these steps: Switch to FM Mode: Press the 'M' (Mode) button on the ear cup control panel to cycle through modes until you...

Read full answer

Open the live page

https://manuals.plus/asin/B01HDUTJC4

More documents and user manuals: **https://manuals.plus/**