**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## iJoy 43155

# iJoy Bluetooth Headphones User Manual

Model: 43155 | Brand: iJoy

## Introduction

Thank you for choosing iJoy Bluetooth Headphones. This manual provides detailed instructions to help you set up, operate, and maintain your headphones for optimal performance. These versatile headphones offer both wireless Bluetooth and wired connectivity, a built-in microphone for hands-free calling, FM radio, and a Micro SD card slot for expanded music playback.




Figure 1: iJoy Bluetooth Headphones (Violet) with auxiliary and charging cables.

## Key Features

- **Bluetooth Connection:** Ultra-fast pairing with extended frequency range for wireless audio.
- **Built-in Microphone:** Enables hands-free calling.
- **Multi-Mode Playback:** Supports Micro SD card plug-in and FM radio receiver.
- **Easy Control Panel:** Intuitive 5-button layout for playback, volume, equalizer, and mode selection.
- **Ultimate Comfort:** Memory protein ear cups and adjustable headband for extended wear.
- **Foldable Design:** Compact for easy portability and storage.
- **Long-Lasting Battery:** Up to 20 hours of wireless connection playtime.

## Setup

### 1. Unboxing and Initial Charge

Upon opening the box, you will find the wireless headphones, an auxiliary cable, and a charging cable. Before first use, fully charge your headphones.

1. Connect the charging cable to the charging port on the headphone (typically a USB-C or Micro-USB port).
2. Connect the other end of the charging cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
3. The indicator light will illuminate during charging and turn off or change color when fully charged. A full charge typically takes approximately 2 hours for up to 20 hours of playtime.




Figure 2: Headphone ports for charging, auxiliary connection, and Micro SD card.

## 2. Bluetooth Pairing

1. Ensure the headphones are charged and powered off.
2. Slide the power button to the ON position. The indicator light will flash, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "iJoy Headphones" (or similar name) from the list.

5. Once connected, the indicator light will typically stop flashing or change to a solid color.




Figure 3: Bluetooth connectivity and multi-mode options.

### 3. Wired Connection (AUX Mode)

For devices without Bluetooth or when the headphone battery is low, use the auxiliary cable.

1. Plug one end of the auxiliary cable into the 3.5mm audio jack on the headphones.
2. Plug the other end into the audio output jack of your device.
3. The headphones will automatically switch to wired mode. Note that some controls on the headphones may not function in wired mode.

## Operating Instructions

### 1. Control Panel Overview

The headphones feature a 5-button control panel on the earcup for easy management of your audio and calls.

| Button/Function | Description |
|---|---|
| **Play/Pause/Answer/Hangup** | Press to play or pause music. Press to answer or end a phone call. |
| **Equalizer (EQ)** | Press to cycle through different equalizer presets (e.g., Bass Boost, Normal). |
| **Next Track/Volume Up (+)** | Short press for next track. Long press to increase volume. |
| **Previous Track/Volume Down (-)** | Short press for previous track. Long press to decrease volume. |
| **Mode (M)** | Press to switch between Bluetooth, FM radio, and Micro SD card modes. |




Figure 4: Easy-to-use control panel for enhanced convenience.

## 2. Micro SD Card Playback

Insert a Micro SD card loaded with MP3 audio files into the designated slot on the headphone. The headphones will automatically switch to Micro SD card mode and begin playback. Use the control panel to manage tracks and volume.

### 3. FM Radio Function

To activate FM radio mode, press the 'M' (Mode) button until you hear the FM radio. Use the '+' and '-' buttons to scan through radio stations. Signal strength may vary based on location.

### 4. Call Handling

When connected via Bluetooth, the built-in microphone allows for hands-free calls.

- **Answer/End Call:** Press the Play/Pause button.
- **Reject Call:** Long press the Play/Pause button.
- **Redial Last Number:** Double-press the Play/Pause button.

## Maintenance

### 1. Cleaning and Storage

To ensure the longevity of your headphones:

- Wipe the earcups and headband with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- Utilize the foldable design to store them compactly when not in use.




Figure 5: Compact and foldable design for easy storage and travel.

### 2. Battery Care

To maximize battery life:

- Avoid completely draining the battery regularly.
- Charge the headphones when the battery low indicator appears.
- If storing for an extended period, charge the headphones to about 50% every few months to prevent deep discharge.

## Troubleshooting

| Problem | Solution |
| --- | --- |

| Problem | Solution |
| --- | --- |
| **Headphones won't turn on.** | Ensure the battery is charged. Connect to a power source and try again. |
| **Cannot pair via Bluetooth.** | Ensure headphones are in pairing mode (flashing indicator light). Turn off and on Bluetooth on your device. Move headphones closer to the device. Forget the device on your phone and re-pair. |
| **No sound or low volume.** | Check volume levels on both headphones and your connected device. Ensure the auxiliary cable is fully inserted if using wired mode. |
| **Charging port is damaged.** | This can occur from improper insertion or excessive force. If the port is physically broken, contact customer support for warranty options. |
| **Poor FM radio reception.** | Move to an open area or near a window. FM reception can be affected by indoor environments and geographical location. |

## Specifications

**Model Number:** 43155

**Connectivity Technology:** Wireless (Bluetooth), Wired (3.5 mm Jack)

**Wireless Communication Technology:** Bluetooth 5.0

**Bluetooth Range:** 10 Meters

**Battery Life:** Up to 20 hours playtime (approx. 2 hours charging time)

**Earpiece Shape:** Over Ear

**Noise Control:** Sound Isolation

**Included Components:** Wireless headphones, auxiliary cable, charging cable

**Item Weight:** 10.2 Ounces

**Product Dimensions:** 5.98 x 5.91 x 3.31 inches

## Warranty and Support

Pranx provides a 6-month exchange warranty. If your headset breaks or is damaged for any reason within this period, Pranx will provide you with a FREE replacement.
For further assistance or support, please visit the official iJoy Store on Amazon or contact their customer service directly.
iJoy Store: https://www.amazon.com/stores/iJoyBrand/page/7273288A-FED9-4D24-B8C9-467F977357B1

© 2025 iJoy. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B01HDUTJII**

More documents and user manuals: **https://manuals.plus/**