Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Starfrit 024400-002-0001

Starfrit The Rock Electric Skillet User Manual

Brand: Starfrit

Model: 024400-002-0001

1. Introduction

Thank you for choosing the Starfrit The Rock Electric Skillet. This appliance is designed for efficient and convenient cooking, featuring a 1200-watt heating system and a heavy-duty, extra-thick base for consistent heat distribution across its 12" x 12" cooking surface. The patented Rock.Tec surface treatment ensures superior non-stick performance, simplifying both cooking and cleanup. With its removable temperature controller, cool-touch handles, and tempered glass lid, this electric skillet offers precise control, safety, and convenience for a wide range of meals.

Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse the temperature control probe, cord, or plug in water or other liquid. The skillet itself is not immersible.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then

remove plug from wall outlet.

- Do not use appliance for other than intended use.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. Components

Your Starfrit The Rock Electric Skillet comes with the following main components:

- Electric Skillet Base with Rock.Tec Non-Stick Surface
- Tempered Glass Lid with Steam Vent
- Removable Temperature Control Probe
- Cool-Touch Handles



Image: The Starfrit The Rock Electric Skillet with its tempered glass lid, viewed from the side. This image illustrates the main components including the skillet body, lid, and cool-touch handles.

4. Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials and labels from the electric skillet.
2. **Initial Cleaning:** Before first use, wash the skillet and lid in warm, soapy water. Rinse thoroughly and dry completely. The temperature control probe should only be wiped clean with a damp cloth; do not immerse it in water.
3. **Assembly:** Insert the removable temperature control probe firmly into the receptacle on the side of the skillet. Ensure it is fully seated.
4. **Placement:** Place the electric skillet on a stable, heat-resistant, and dry surface, away from the edge of the counter. Ensure there is adequate ventilation around the unit.
5. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet.

5. Operating Instructions

Temperature Control

The Starfrit The Rock Electric Skillet features a removable and adjustable temperature controller, allowing for precise heat adjustments for various cooking needs. The dial typically ranges from "Warm" to "Max" or specific temperature settings.

1. **Setting Temperature:** Turn the temperature control dial to your desired setting. An indicator light will illuminate, signaling that the skillet is heating.
2. **Preheating:** Allow the skillet to preheat for 5-10 minutes, or until the indicator light turns off, indicating the desired temperature has been reached. The light will cycle on and off during cooking to maintain the set temperature.
3. **Cooking:** Add food to the preheated skillet. The Rock.Tec non-stick surface requires minimal oil or butter for cooking.
4. **Using the Lid:** The tempered glass lid helps to retain heat and moisture, speeding up cooking and enhancing flavors. Use it when simmering, braising, or keeping food warm.
5. **Keeping Warm:** For keeping food warm after cooking, set the temperature dial to the "Warm" setting.
6. **Turning Off:** After cooking, turn the temperature control dial to the "Off" position and unplug the unit from the wall outlet. Allow the skillet to cool completely before cleaning.



Image: The Starfrit The Rock Electric Skillet in use, cooking salmon fillets and various vegetables. This demonstrates the spacious cooking surface and its versatility.

6. Care and Maintenance

Cleaning

Proper cleaning ensures the longevity and performance of your electric skillet.

1. **Disconnect Power:** Always unplug the skillet and remove the temperature control probe before cleaning.
2. **Cool Down:** Allow the skillet to cool completely before attempting to clean it.
3. **Skillet Body:** The Rock.Tec non-stick surface makes cleaning easy. Wash the skillet body and lid with warm, soapy water using a soft sponge or cloth. Avoid abrasive cleaners, scouring pads, or metal utensils, as these can damage the non-stick coating.
4. **Temperature Control Probe:** Wipe the temperature control probe with a damp cloth.**DO NOT immerse the probe, cord, or plug in water or any other liquid.**
5. **Drying:** Dry all parts thoroughly before storing.

Storage

Store the clean and dry electric skillet in a safe, dry place. You may store the temperature control probe separately or attached to the skillet, ensuring the cord is neatly wrapped and not kinked.

7. Troubleshooting

Problem	Possible Cause	Solution
Skillet does not heat up.	Not plugged in. Temperature control probe not fully inserted. Power outlet malfunction.	Ensure the unit is securely plugged into a working electrical outlet. Push the temperature control probe firmly into the skillet's receptacle until it clicks into place. Test the outlet with another appliance.
Food sticks to the surface.	Insufficient preheating. Surface not clean. Damage to non-stick coating.	Allow the skillet to fully preheat before adding food. Ensure the cooking surface is clean and free of residue before use. Avoid using metal utensils or abrasive cleaners that can scratch the coating.
Uneven heating.	Temperature control probe not properly seated. Skillet not on a flat surface.	Re-insert the temperature control probe firmly. Ensure the skillet is placed on a flat, stable surface.

8. Specifications

Feature	Detail
Model Number	024400-002-0001
Power	1200 Watts
Voltage	120V AC
Cooking Surface Dimensions	12" x 12"
Product Dimensions (Overall)	16.93"D x 11.81"W x 6.7"H

Feature	Detail
Item Weight	5.03 Pounds
Material	Ceramic (Non-Stick Coating), Cast Aluminum (Base)
Special Features	Cool Touch Handles, Keep Warm Setting, Rock.Tec Non-Stick Coating, Removable Temperature Control



Image: The Starfrit The Rock Electric Skillet with its key dimensions (length, width, height) clearly indicated.

9. Warranty and Support

This Starfrit The Rock Electric Skillet comes with a Limited Warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty information provided with your purchase or visit the official Starfrit website.

For product support, troubleshooting assistance beyond this manual, or to make a warranty claim, please contact Starfrit customer service directly. Contact information can typically be found on the manufacturer's website or on the product packaging.

Manufacturer: Starfrit

© 2024 Starfrit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01HJ7BJRE

More documents and user manuals: **https://manuals.plus/**