Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy LGE-PRE-STL

iJoy Bluetooth Headphones Over Ear User Manual

Model: LGE-PRE-STL

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your iJoy Bluetooth Over-Ear Headphones. Please read this manual thoroughly before using the product to ensure proper function and longevity.

The iJoy Bluetooth Headphones offer a versatile audio experience with both wireless Bluetooth and wired connectivity options. They feature a built-in microphone for hands-free calling, a micro SD card slot for direct music playback, and an FM radio receiver. Designed for comfort, these headphones include memory protein ear cups and an adjustable headband, making them suitable for extended use.

Package Contents

Ensure all items are present in the package:

- iJoy Bluetooth Over-Ear Headphones
- Auxiliary Cable
- Charging Cable (Type-C to USB)



Image: Contents of the iJoy Bluetooth Headphones package, including the headphones, auxiliary cable, and charging cable.

Product Overview

Familiarize yourself with the various components and controls of your iJoy Bluetooth Headphones.



Image: Detailed diagram illustrating the control buttons (Play/Pause, EQ, Next/Volume Up, Previous/Volume Down, Mode), Micro SD Card slot, Type-C charging port, AUX input, and microphone on the iJoy headphones.

Control Panel Functions:

- **Play/Pause/Answer/Hangup:** Central button for media playback control and call management.
- **Equalizer (EQ):** Adjusts sound profiles.
- **Next Track/Volume Up:** Short press for next track, long press for volume increase.
- **Previous Track/Volume Down:** Short press for previous track, long press for volume decrease.
- **Bluetooth/FM Mode (M):** Switches between Bluetooth and FM radio modes.
- **Indicator Light:** Provides status information (e.g., charging, pairing).
- **Microphone:** Built-in for hands-free calling.
- **Micro SD Card Slot:** For direct playback from a Micro SD card.
- **Type-C to USB Port:** For charging the headphones.
- **AUX Cable Port:** For wired audio connection.

Setup

Charging the Headphones:

1. Connect the provided charging cable to the Type-C port on the headphones.
2. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The indicator light will illuminate during charging and turn off when fully charged. A full charge takes approximately 2 hours.
4. Ensure the headphones are fully charged before first use for optimal battery life.



Image: The headphones offer up to 20 hours of playtime on a 2-hour charge.

Adjusting the Fit:

For optimal comfort and sound isolation, adjust the headband to fit your head size. The memory protein ear cups are designed to provide a snug fit over your ears.



Image: The adjustable headband and soft memory protein earmuffs ensure a comfortable and secure fit for various head shapes.

Operating Instructions

Power On/Off:

- To power on, slide the On/Off switch located on the ear cup. The indicator light will flash.
- To power off, slide the On/Off switch back to the off position.



Image: Location of the On/Off switch on the headphone ear cup.

Bluetooth Connection:

1. Ensure the headphones are powered on and in Bluetooth mode (indicator light flashing).
2. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "iJoy Headphones" from the list of found devices.
4. Once paired, the indicator light will stop flashing and remain solid.

Wired Connection (AUX Mode):

1. Insert one end of the provided auxiliary cable into the AUX port on the headphones.
2. Insert the other end into the 3.5mm audio jack of your device.
3. The headphones will automatically switch to wired mode.

Micro SD Card Playback:

1. Insert a Micro SD card with audio files into the Micro SD card slot.

2. The headphones will automatically detect the card and begin playback.
3. Use the Play/Pause, Next Track, and Previous Track buttons to control playback.

FM Radio Mode:

1. Press the "M" (Mode) button to switch to FM radio mode.
2. The headphones will automatically scan and save available radio stations.
3. Use the Next Track and Previous Track buttons to navigate between saved stations.

Call Management:

- **Answer/End Call:** Press the Play/Pause/Answer/Hangup button once.
- **Reject Call:** Press and hold the Play/Pause/Answer/Hangup button.
- **Redial Last Number:** Double-press the Play/Pause/Answer/Hangup button.

Maintenance

- Clean the headphones regularly with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Store the headphones in a cool, dry place when not in use. The foldable design allows for easy storage and portability.
- Do not attempt to disassemble or repair the headphones yourself, as this will void the warranty.

Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; too far from device.	Ensure headphones are in Bluetooth mode (flashing indicator). Turn device Bluetooth off and on. Move headphones closer to device (within 10 meters).
No sound in Bluetooth mode.	Volume too low; not properly paired; incorrect audio output selected on device.	Increase headphone and device volume. Re-pair the headphones. Check device's audio output settings.
No sound in wired (AUX) mode.	AUX cable not fully inserted; faulty cable; device volume too low.	Ensure AUX cable is securely connected at both ends. Try a different AUX cable. Increase device volume.
Poor FM radio reception.	Weak signal; environmental interference.	Move to an area with better signal. Try re-scanning stations.

Specifications

Model Name:	LGE-PRE-STL
Connectivity Technology:	Wireless (Bluetooth), Wired (3.5mm Jack)
Wireless Communication:	Bluetooth 4.1
Bluetooth Range:	Up to 10 meters (33 feet)
Battery Life:	Up to 20 hours playtime
Charging Time:	Approximately 2 hours
Ear Placement:	Over Ear
Noise Control:	Sound Isolation
Built-in Microphone:	Yes
Micro SD Card Slot:	Yes
FM Radio:	Yes
Item Weight:	8.2 ounces
Product Dimensions:	6 x 5.9 x 3.3 inches

Warranty and Support

iJoy provides a 6-month exchange warranty for this product. If your headset breaks or is damaged for any reason within this period, Pranx (the seller) will provide a FREE replacement.
For further assistance or warranty claims, please contact Pranx customer support via their Amazon seller page: Pranx Seller Page.

© 2024 iJoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01HNMTCE2

More documents and user manuals: **https://manuals.plus/**