Oreck CC1600+TB+PKBB12DW

Oreck BB880-AD Super-Deluxe Compact Canister Vac Bundle Instruction Manual

Model: CC1600+TB+PKBB12DW

1. Introduction

Welcome to the Oreck BB880-AD Super-Deluxe Compact Canister Vac Bundle instruction manual. This guide provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new Oreck vacuum cleaner. Please read this manual thoroughly before using the appliance and retain it for future reference.

2. Important Safety Information

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using this vacuum cleaner.
- To reduce the risk of electric shock, do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust bag and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.

3. Package Contents

Your Oreck BB880-AD Super-Deluxe Compact Canister Vac Bundle includes the following components:



Image: The Oreck BB880-AD compact canister vacuum, along with its hose, extension wands, floor nozzle, crevice tool, dusting brush, and a pack of disposable dust bags.

- Oreck Compact Canister Vacuum Unit
- Flexible Hose
- Extension Wands (typically 2)
- Floor Nozzle
- Crevice Tool

- Dusting Brush
- Pet Hair Turbo Brush
- Disposable Dust Bags (8 included)
- Shoulder Strap

4. Setup

Follow these steps to set up your Oreck compact canister vacuum for first use:



Image: The Oreck compact canister vacuum with its flexible hose and dusting brush attached, ready for use.

1. **Unpack:** Carefully remove all components from the packaging.
2. **Insert Dust Bag:** Open the dust bag compartment (refer to the diagram inside the compartment if available) and insert one of the provided disposable dust bags. Ensure it is securely seated to prevent dust leakage.
3. **Attach Hose:** Connect the flexible hose to the suction port on the front of the vacuum unit. Twist or push firmly until it clicks into place.
4. **Attach Accessories:** Select the desired cleaning attachment (e.g., dusting brush, crevice tool, or floor nozzle) and attach it directly to the end of the hose. For extended reach, connect the extension wands between the hose and the attachment.
5. **Attach Shoulder Strap (Optional):** If you wish to carry the vacuum, attach the shoulder strap to the designated anchor points on the unit. This allows for easy portability during cleaning.

5. Operating Instructions

5.1. Powering On/Off

To turn the vacuum on, plug the power cord into a suitable electrical outlet. Locate the power switch on the top of the unit and press it to the 'ON' position. To turn off, press the switch to the 'OFF' position and unplug the unit from the outlet.

5.2. Using Attachments

The Oreck BB880-AD comes with a variety of attachments designed for different cleaning tasks:



Image: The Oreck compact canister vacuum displayed with its full set of attachments, including the pet hair turbo brush, crevice tool, dusting brush, and floor nozzle.

- **Floor Nozzle:** Ideal for cleaning carpets and hard floors. Attach directly to the hose or extension wands.
- **Crevice Tool:** Perfect for narrow spaces, corners, and along edges.
- **Dusting Brush:** Use for delicate surfaces, blinds, upholstery, and shelves.
- **Pet Hair Turbo Brush:** Specifically designed for effective removal of pet hair from upholstery, stairs, and small

carpeted areas.



Image: The Oreck vacuum with an extension wand and dusting brush, demonstrating its use for cleaning high ceilings and window blinds.

5.3. Cleaning Surfaces

The Oreck BB880-AD is suitable for both carpet and hard floor surfaces. Its powerful suction ensures effective cleaning.



Image: A graphic illustrating the powerful suction of the Oreck vacuum, with arrows pointing towards the brush head, indicating strong airflow for debris collection.

For optimal performance, move the vacuum attachment slowly and steadily over the surface. For heavily soiled areas, multiple passes may be required. The lightweight design allows for easy maneuverability and carrying over your shoulder for extended cleaning tasks.



Image: A hand holding the Oreck BB880-AD vacuum by its handle, emphasizing its lightweight and portable design.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Oreck vacuum.

6.1. Emptying the Dust Bag

The dust bag should be emptied or replaced when it is approximately 50-70% full, or when suction power noticeably diminishes. Overfilling the bag can reduce airflow and cleaning efficiency.



Image: The Oreck compact canister vacuum displayed alongside a pack of 8 Oreck sanitary hypoallergenic disposable dust bags, highlighting the included accessories for maintenance.

1. Unplug the vacuum cleaner from the power outlet.
2. Open the dust bag compartment.
3. Carefully remove the full dust bag, ensuring the opening is sealed to prevent dust escape.
4. Dispose of the full bag and insert a new Oreck disposable dust bag, ensuring it is properly seated.
5. Close the dust bag compartment securely.

6.2. Filter Maintenance

This model uses a cartridge filter system. While the disposable bags act as the primary filter, inspect the internal filter (if accessible) periodically for excessive dust buildup. Clean or replace as per manufacturer recommendations to maintain optimal filtration and motor protection.

6.3. Cleaning the Unit

Wipe the exterior of the vacuum with a soft, damp cloth. Do not use harsh cleaners or solvents. Ensure the unit is

unplugged before cleaning.

7. Troubleshooting

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	Not plugged in; Power outlet not working; Power switch off; Thermal protector activated.	Ensure plug is fully inserted; Check circuit breaker/fuse; Turn power switch to 'ON'; Unplug, allow to cool for 30 minutes, then restart.
Loss of suction	Dust bag full; Hose/attachment clogged; Filter dirty.	Replace/empty dust bag; Clear any blockages from hose/attachments; Clean or replace filter.
Unusual noise	Obstruction in fan/motor area; Damaged motor.	Turn off and unplug. Check for and remove obstructions. If noise persists, contact customer support.
Dust escaping from unit	Dust bag not installed correctly; Dust bag torn; Filter missing/damaged.	Reinstall dust bag securely; Replace torn dust bag; Check and replace filter if necessary.

8. Specifications

Feature	Detail
Brand	Oreck
Model Name	CC1600+TB+PKBB12DW
Form Factor	Handheld / Canister
Special Feature	Bagged (uses disposable bags)
Filter Type	Cartridge
Capacity	5 Pounds (approximate dust bag capacity)
Item Weight	5 pounds
Noise Level	70 dB
Recommended Uses	Carpet, Hard Floor, Multi-surface
Control Method	Push Button
Power Source	Corded Electric
Package Dimensions	19.5 x 11 x 9.8 inches

9. Warranty and Support

For warranty information, product registration, or technical support, please refer to the documentation included with your purchase or visit the official Oreck website. You can also find more information and contact details on the Oreck Store on Amazon.
Please have your model number (CC1600+TB+PKBB12DW) and purchase date ready when contacting support.

© 2024 Oreck. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question