Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hitachi 339818

Hitachi 339818 Parallel Bracket Assembly Replacement Part User Manual

1. Introduction

This manual provides essential information for the proper installation, maintenance, and understanding of the Hitachi 339818 Parallel Bracket Assembly Replacement Part. This component is designed to meet the high standards of Hitachi (now Metabo HPT) power tools, ensuring performance and durability.

2. Product Overview

The Hitachi 339818 Parallel Bracket Assembly is a critical replacement component for specific Hitachi power tools. Its function is to provide structural support and ensure precise alignment within the tool's mechanism. Regular inspection and timely replacement of worn or damaged parts are crucial for maintaining tool performance and safety.



Image 1: A collection of Hitachi replacement parts. This image displays various components, including the Hitachi 339818 Parallel Bracket Assembly (the T-shaped metal piece), an electronic component with a heat sink and wires, a beige plastic bushing, a black air regulator-like component, and four carbon brushes with springs. These are common replacement parts for Hitachi power tools.

3. Compatibility

The 339818 Parallel Bracket Assembly is specifically designed for use with certain Hitachi power tool models. Users must verify compatibility with their specific tool's model number and part requirements before installation. Refer to your tool's original manual or consult a qualified service technician to confirm suitability.

4. Installation

Installation of replacement parts should only be performed by individuals with appropriate technical knowledge and experience. Always prioritize safety by following these general guidelines:

1. **Safety First:** Ensure the power tool is disconnected from its power source (unplugged or battery removed) before beginning any disassembly or installation.
2. **Refer to Tool Manual:** Consult the specific service manual for your power tool model for detailed disassembly

and reassembly instructions.

3. **Disassembly:** Carefully disassemble the tool to access the existing parallel bracket assembly. Note the position and orientation of all components.
4. **Remove Old Part:** Detach and remove the old or damaged parallel bracket assembly.
5. **Install New Part:** Position the new Hitachi 339818 Parallel Bracket Assembly in its correct location. Ensure all mounting points align properly.
6. **Secure Components:** Reattach any fasteners, screws, or clips that secure the bracket. Do not overtighten.
7. **Reassembly:** Carefully reassemble the power tool, ensuring all components are correctly seated and secured.
8. **Functionality Check:** After reassembly, perform a manual check of the tool's moving parts to ensure smooth operation before connecting to power.
9. **Test Operation:** Connect the tool to power and perform a brief test run in a safe environment to confirm proper function.

If you are unsure about any step, seek assistance from a qualified service technician.

5. Maintenance

The Hitachi 339818 Parallel Bracket Assembly is designed for durability. However, regular maintenance of the power tool it is installed in will contribute to its longevity:

- **Cleanliness:** Keep the tool and its internal components free from dust, debris, and excessive build-up.
- **Lubrication:** Follow your tool's specific maintenance schedule for lubrication of moving parts, if applicable.
- **Inspection:** Periodically inspect the parallel bracket assembly for signs of wear, damage, or deformation. Replace if necessary.

6. Troubleshooting

If you experience issues after replacing the parallel bracket assembly, consider the following:

- **Incorrect Installation:** Re-verify that the bracket is installed correctly and securely, following all steps in your tool's service manual.
- **Incorrect Part:** Ensure that the 339818 part is indeed the correct replacement for your specific tool model.
- **Other Components:** Issues might stem from other worn or damaged components within the tool, not necessarily the newly installed bracket. Inspect surrounding parts.
- **Professional Assistance:** If problems persist, discontinue use of the tool and consult a certified service center or qualified technician.

7. Specifications

Specification	Detail
Part Number	339818
Item Model Number	339818
Brand	Hitachi (now Metabo HPT)
Manufacturer	Koki Holdings America, Ltd

Specification	Detail
Item Weight	1 pounds
Product Dimensions	1 x 1 x 1 inches
Item Package Quantity	1
Measurement System	Metric
Batteries Required?	No
Date First Available	June 30, 2016

8. Warranty and Support

Hitachi replacement parts are manufactured to high-quality standards. For specific warranty information regarding this replacement part, please refer to the documentation provided with your original power tool or contact Hitachi (Metabo HPT) customer support directly.

For further assistance, product information, or to explore other genuine Hitachi replacement parts, please visit the official Hitachi Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01HRUQA04

More documents and user manuals: **https://manuals.plus/**