Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SATECHI ST-ALTSS

Satechi Lightweight Aluminum Portable Laptop Stand User Manual

Model: ST-ALTSS

1. Introduction

This user manual provides comprehensive instructions for the Satechi Lightweight Aluminum Portable Laptop Stand, Model ST-ALTSS. It covers product features, setup, operation, maintenance, troubleshooting, and specifications. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.
The Satechi Lightweight Aluminum Portable Laptop Stand is designed to elevate your laptop or tablet, improving ergonomics and airflow. Its collapsible design makes it highly portable, while its robust aluminum construction ensures stability and durability.

2. Product Features

- **Easel-style stand:** Facilitates easy viewing and interaction with your laptop or tablet in both portrait and landscape orientations.
- **Lightweight, collapsible design:** Features an integrated handle and a foldable structure for enhanced portability.
- **Cable management:** Allows for neat routing of cables through the rear opening, preventing tangles.
- **No-slip rubber grip:** Equipped with rubber grips on the base to secure both the stand and your device, and to protect your workspace from scratches.
- **Premium aluminum construction:** Constructed from sleek aluminum for long-lasting quality and available in various finishes including silver.



Figure 2.1: The Satechi Lightweight Aluminum Portable Laptop Stand in silver, showcasing its easel-style design and aluminum construction.

3. Package Contents

Upon opening the package, verify that all components are present and undamaged. The standard package includes:

- 1 x Satechi Lightweight Aluminum Portable Laptop Stand (Model: ST-ALTSS)

4. Setup

The Satechi Laptop Stand requires minimal setup. Follow these steps to prepare your stand for use:

1. **Unfold the Stand:** Gently unfold the stand from its collapsed position until it forms a stable easel shape. Ensure the hinge mechanism locks securely into place.
2. **Position on a Flat Surface:** Place the stand on a stable, flat surface such as a desk or table. The rubber grips on the base will help prevent slipping.
3. **Place Your Device:** Carefully place your laptop or tablet onto the stand. The rubber pads on the stand's surface will hold your device securely and prevent scratches.



Figure 4.1: The Satechi Laptop Stand in its folded, portable configuration.



Figure 4.2: Top-down view of the Satechi Laptop Stand, showing the rubber grips and overall design.

5. Operating Instructions

The Satechi Laptop Stand is designed for straightforward use. Once set up, it provides an elevated and angled platform for your device.

- **Ergonomic Positioning:** The stand elevates your laptop screen to a more comfortable viewing height, which can help reduce neck and eye strain during prolonged use.
- **Improved Airflow:** By lifting your laptop off the desk, the stand allows for better air circulation around the device, aiding in heat dissipation and preventing overheating.
- **Cable Management:** Utilize the opening at the back of the stand to route charging cables, external display cables, or other peripherals, keeping your workspace tidy.



Figure 5.1: A laptop positioned on the Satechi stand, demonstrating the elevated viewing angle.



Figure 5.2: Side view of the Satechi stand supporting a laptop, highlighting the space for improved airflow.



Figure 5.3: The Satechi stand also effectively supports tablets, providing an ergonomic viewing angle.

6. Maintenance

To ensure the longevity and optimal performance of your Satechi Laptop Stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid using abrasive cleaners or solvents, as these can damage the aluminum finish and rubber grips.
- **Storage:** When not in use, fold the stand into its compact form for easy storage. Store it in a dry place away from extreme temperatures.
- **Inspection:** Periodically check the hinge mechanism and rubber grips for any signs of wear or damage.

7. Troubleshooting

If you encounter any issues with your Satechi Laptop Stand, refer to the following common problems and their solutions:

Problem	Possible Cause	Solution
Stand is unstable or wobbles.	Not fully unfolded or placed on an uneven surface.	Ensure the stand is fully extended and locked into position. Place the stand on a flat, stable surface.

Problem	Possible Cause	Solution
Device slides on the stand.	Rubber grips are dirty or worn.	Clean the rubber grips with a damp cloth to remove dust or debris. If grips are worn, contact Satechi support.
Stand does not fold easily.	Hinge mechanism may be stiff or obstructed.	Apply gentle, even pressure when folding. Ensure no debris is caught in the hinge. Do not force the mechanism.

If the issue persists after attempting these solutions, please contact Satechi customer support for further assistance.

8. Specifications

Attribute	Detail
Brand	SATECHI
Model	ST-ALTSS
Material	Aluminum
Color	Silver
Product Dimensions	23 x 22.5 x 0.4 cm (folded)
Item Weight	483 Grams
Special Features	Foldable, Cable Management, No-slip Rubber Grip
Compatible Devices	Universal (Laptops, Tablets)
UPC	879961006549

9. Warranty and Support

Satechi products are designed for quality and durability. For information regarding warranty coverage, product registration, or technical support, please visit the official Satechi website or contact their customer service department.
Satechi Official Website: www.satechi.net
For direct support, refer to the contact information provided on the Satechi website or within your product packaging.

© 2024 Satechi. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01I407FXW

More documents and user manuals: **https://manuals.plus/**