De'Longhi EO241250M

De'Longhi Livenza Digital True European Convection Oven

Model: EO241250M

Introduction

The De'Longhi Livenza 0.8 cu ft. Stainless Steel Digital True European Convection Oven is engineered to provide consistent, even heat for a variety of dishes. This versatile countertop appliance simplifies cooking and entertaining with its ability to toast, roast, broil, and bake. Featuring a Heat Lock System for efficient temperature retention and an internal light for monitoring, it offers convenience and precision. With True European Convection, it cooks faster and more evenly than conventional ovens. Its non-stick interior and removable crumb tray ensure easy cleanup, while the LED digital display and auto shutoff feature enhance usability and safety.



Image: The De'Longhi Livenza Convection Oven, showcasing its sleek stainless steel design and digital control panel.

Important Safety Information

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

What's in the Box

Your De'Longhi Livenza Convection Oven comes with the following components:

- De'Longhi Livenza Convection Oven Unit
- Pizza Tray
- Baking Tray
- Wire Rack
- Air Fry Basket
- Removable Crumb Tray



Image: Included accessories for the De'Longhi Livenza Convection Oven.

Setup

1. **Unpack the Oven:** Carefully remove the oven and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the oven on a stable, level, heat-resistant surface. Ensure there is adequate clearance (at least 4 inches) on all sides and above the oven for proper ventilation.
3. **Initial Cleaning:** Before first use, wipe down the exterior of the oven with a damp cloth. Wash all accessories (pizza tray, baking tray, wire rack, air fry basket, crumb tray) with warm, soapy water, rinse thoroughly, and dry completely.
4. **Insert Crumb Tray:** Slide the removable crumb tray into the lowest slot at the bottom of the oven.
5. **Install Accessories:** Insert the desired rack or tray into the appropriate rack position based on your cooking needs. The oven features four adjustable rack positions for multi-level cooking.

Your browser does not support the video tag.

Video: Official product overview demonstrating the oven's features and setup.

Operating Instructions

Control Panel Overview

The De'Longhi Livenza oven features an intuitive digital control panel with three main dials and a clear LED display:

- **Top Dial (Toast Color/Time):** Adjusts toast shade or cooking time for various functions.
- **Middle Dial (Temperature/Pizza Size/Slices/Tray):** Controls temperature or specific settings for pizza and toast.
- **Bottom Dial (Function):** Selects the desired cooking mode.
- **Start/Stop Button:** Initiates or pauses the cooking process.



Image: Digital control panel with function selection and temperature/time dials.

Cooking Functions

Rotate the Function dial to select from the following modes:

- **Toast:** For perfect toast, bagels, or waffles. Adjust toast color and number of slices.

- **Bake:** Ideal for cakes, casseroles, and other baked goods. Set desired temperature and time.
- **Convection:** Circulates hot air for faster and more even cooking, perfect for roasting meats or baking multiple items.
- **Broil/Grill:** For browning, grilling, or melting cheese. Use with the wire rack and baking tray.
- **Defrost:** Gently thaws frozen foods.
- **Pizza:** Optimized setting for baking pizzas. Select pizza size (e.g., 10-inch).
- **Cookies:** Pre-programmed setting for baking cookies.
- **Keep Warm:** Maintains food at a warm serving temperature.
- **Reheat:** For warming up leftovers.

Key Features for Enhanced Cooking

- **True European Convection:** The oven utilizes a powerful fan to circulate hot air, ensuring up to 40% faster and more even cooking. This also allows for up to 60% faster preheating compared to full-sized conventional ovens.
- **Heat Lock System:** Advanced thermal insulation and a double-glass door maintain the internal temperature efficiently, emitting up to 50% less heat off the glass door. This keeps your kitchen cooler and improves energy efficiency.
- **Multi-level Cooking:** With four adjustable rack positions, you can maximize cooking space and prepare multiple dishes simultaneously.
- **Internal Light:** The interior light allows you to easily monitor the cooking progress without opening the door.
- **Auto Shutoff:** For safety and convenience, the oven automatically shuts off after the cooking cycle is complete.



Image: Illustration of the True European Convection system for even heat distribution.



Image: The Heat Lock System, highlighting the double glass door and thermal insulation.

Maintenance and Cleaning

Regular cleaning will ensure the longevity and optimal performance of your De'Longhi Livenza oven:

- **Before Cleaning:** Always unplug the oven from the power outlet and allow it to cool completely before cleaning.
- **Non-Stick Interior:** The oven features a non-stick interior for easy cleanup. Wipe the interior with a damp cloth and mild detergent. Avoid abrasive cleaners or scouring pads that could damage the non-stick coating.
- **Removable Crumb Tray:** The crumb tray should be emptied and cleaned regularly to prevent grease buildup and potential fire hazards. Pull out the tray, discard crumbs, and wash with warm, soapy water. Rinse and dry thoroughly before reinserting.
- **Accessories:** All included accessories (pizza tray, baking tray, wire rack, air fry basket) are dishwasher safe for convenient cleaning.
- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.



Image: Dishwasher-safe accessories for easy cleaning.

Troubleshooting

If you encounter any issues with your De'Longhi Livenza oven, please refer to the following common troubleshooting tips:

- **Oven Not Turning On:** Ensure the power cord is securely plugged into a working electrical outlet. Check your household's circuit breaker.
- **Food Not Cooking Evenly:** Ensure proper rack placement for the selected function. For convection cooking, ensure adequate space around food for air circulation.
- **Excessive Smoke:** This may be due to food residue or grease buildup. Clean the interior and crumb tray thoroughly. Avoid overfilling the oven.
- **Digital Display Not Working:** Unplug the oven for a few minutes, then plug it back in to reset the system.
- **Unusual Noises:** A slight fan noise is normal during convection operation. If noises are loud or unusual, discontinue use and contact customer support.

For more detailed troubleshooting or issues not listed here, please consult the full user manual or contact De'Longhi customer support.

Specifications

Feature	Detail
Brand	De'Longhi
Model Name	Convection Toaster Oven for Countertop, Digital with Internal light, XL

Model Number	EO241250M
Capacity	24L / 0.8 cu. ft.
Color	Stainless Steel
Product Dimensions	12"D x 19"W x 12"H
Power Source	AC adapter
Wattage	2000 W
Oven Power	1800 W
Control Type	Digital
Special Features	True European Convection, Heat Lock System, Multi-level cooking, Eight preset programs, Non-stick interior
Included Components	Convection countertop oven, Pizza tray, Baking tray, Wire rack, Air fry basket, Removable crumb tray

Warranty and Support

For detailed warranty information and customer support, please refer to the official user manual or visit the De'Longhi store:

- **User Manual (PDF):** Download Here
- **De'Longhi Store:** Visit Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question