Bosch TWK6A014

Bosch ComfortLine TWK6A014 Cordless Kettle User Manual

Model: TWK6A014

Introduction

Thank you for choosing the Bosch ComfortLine TWK6A014 Cordless Kettle. This manual provides important information regarding the safe operation, maintenance, and care of your new appliance. Please read these instructions carefully before first use and keep them for future reference.

Safety Instructions

Always observe the following safety precautions to prevent injury or damage to the appliance:

- **Electrical Safety:** Ensure the voltage indicated on the rating plate matches your mains supply. Do not immerse the kettle or its base in water or other liquids. Do not operate the kettle with a damaged cord or plug.
- **Overheat and Boil-Dry Protection:** The kettle is equipped with automatic shut-off, overheat protection, and boil-dry protection. If the kettle is accidentally switched on without water, it will automatically switch off. Allow it to cool down before refilling.
- **Hot Surfaces:** The kettle body becomes hot during operation. Always use the handle to carry the kettle. Avoid contact with steam escaping from the spout or lid.
- **Children and Vulnerable Persons:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- **Intended Use:** This kettle is designed for boiling water only. Do not use it for heating milk, coffee, or other liquids.

Product Overview

Familiarize yourself with the components of your Bosch ComfortLine TWK6A014 kettle:



This image shows the Bosch ComfortLine TWK6A014 cordless kettle. The kettle is red with dark grey accents, featuring a water level indicator on the side of the handle and a power switch at the base. A cup of tea and breakfast items are visible in the background.

- **Lid:** Opens with a push-button for easy filling.
- **Handle:** Ergonomically designed for comfortable grip.
- **Water Level Indicator:** Clearly marked for precise filling (0.3L to 1.7L).
- **On/Off Switch:** Located at the base of the handle.
- **Removable Limescale Filter:** Located behind the spout for cleaner water.
- **Power Base:** Cordless 360° rotational base for easy placement.

Setup

1. **Unpack:** Remove all packaging materials and dispose of them responsibly.
2. **Initial Cleaning:** Before first use, fill the kettle with water to the maximum mark, boil it, and then discard the water. Repeat this process twice to remove any manufacturing residues.

3. **Placement:** Place the power base on a stable, flat, heat-resistant surface, away from the edge of the countertop and out of reach of children.
4. **Connect:** Plug the power base into a grounded wall socket.

Operating Instructions

Follow these steps to operate your kettle:



This image provides a close-up view of the kettle's handle and the transparent water level indicator, showing markings from 0.3L to 1.7L. The lid release button is visible on top of the handle.

1. **Fill the Kettle:** Press the lid release button on the handle to open the lid. Fill the kettle with the desired amount of fresh water, observing the minimum (0.3L) and maximum (1.7L) fill lines on the water level indicator. Close the lid securely until it clicks.
2. **Place on Base:** Place the kettle firmly onto its power base.
3. **Switch On:** Press the On/Off switch downwards. The indicator light will illuminate, signifying that the kettle is heating.
4. **Automatic Shut-off:** The kettle will automatically switch off once the water has boiled, and the indicator light will extinguish.

5. **Pouring:** Carefully lift the kettle from the base and pour the hot water.
6. **Single-Cup Function:** For boiling a single cup of water, fill to the 0.3L mark. This function helps save energy and time.

Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your kettle:

- **Before Cleaning:** Always unplug the power base from the mains and allow the kettle to cool completely before cleaning.
- **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaning agents or harsh chemicals.
- **Interior Cleaning:** The large 90° opening allows for easy access to the interior for cleaning.
- **Limescale Filter:** The removable limescale filter can be detached for cleaning. Rinse it under running water and gently brush away any deposits. Reinsert it correctly after cleaning.
- **Descaling:** Depending on water hardness, descale the kettle regularly (e.g., monthly). Use a commercially available descaling agent suitable for kettles, following the manufacturer's instructions. After descaling, rinse the kettle thoroughly several times with fresh water.

Troubleshooting

If you encounter issues with your kettle, refer to the following common problems and solutions:

- **Kettle does not heat:**
  - Ensure the power base is plugged in and the wall socket is active.
  - Check if the On/Off switch is fully pressed down.
  - Verify the kettle is correctly seated on the power base.
- **Kettle switches off before boiling:**
  - This may indicate limescale buildup. Descale the kettle as per the maintenance instructions.
  - Ensure the kettle is not overfilled, as this can cause premature shut-off.
- **Water tastes unusual:**
  - Perform the initial cleaning steps (boil and discard water) again.
  - Ensure the kettle is regularly descaled and cleaned.

If the problem persists, contact Bosch customer support.

Specifications

Model Number	TWK6A014
Capacity	1.7 Liters (7 Cups)
Power	2400 Watts
Voltage	240 Volts
Material	Plastic

Color	Red
Dimensions (L x W x H)	22.6 x 16.5 x 26.2 cm
Weight	1.4 Kilograms
Special Features	Automatic shut-off, Push-button lid, Removable filter, Overheat protection, Boil-dry protection, Cordless, One-hand operation

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Bosch website. Keep your proof of purchase for any warranty claims.
For further assistance, you may contact Bosch customer service through their official channels. You can often find contact details on the Bosch website or by searching for "Bosch customer support" in your region.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question