Haul Master 5828913

Haul Master 600 lb. Capacity Appliance Hand Truck User Manual

Model: 5828913

Introduction

The Haul Master 600 lb. Capacity Appliance Hand Truck is designed for safe and efficient transport of large and heavy appliances. Its robust construction, including an all-welded heavy gauge steel frame and solid rubber wheels, ensures durability and stability. This manual provides essential information for the proper assembly, operation, maintenance, and troubleshooting of your hand truck.

Safety Information

Always prioritize safety when operating the hand truck. Failure to follow these instructions may result in injury or damage to property.

- **Load Capacity:** Do not exceed the maximum load capacity of 600 lbs. Overloading can cause instability and damage.
- **Secure Loads:** Always use the double-stitched webbed strap with buckle to firmly secure appliances to the hand truck before moving.
- **Proper Lifting Technique:** Bend your knees, not your back, when loading or unloading. Use the hand truck to do the lifting, not your body.
- **Stability:** Ensure the load is balanced and centered on the toe plate. Avoid sudden movements or turns, especially on inclines.
- **Stair Climbing:** When using the stair climbers, proceed slowly and maintain a firm grip on the handles. Be aware of your surroundings.
- **Footwear:** Wear appropriate safety footwear when operating the hand truck.
- **Obstacles:** Be aware of obstacles, uneven surfaces, and inclines. Clear your path before moving.
- **Storage:** Store the hand truck in a dry, secure location when not in use.

Components and Features

Familiarize yourself with the key components of your Haul Master Appliance Hand Truck:

- **Heavy Gauge Steel Frame:** All-welded construction for maximum durability.
- **Solid Rubber Wheels:** 6-inch non-marring wheels that will not puncture or go flat.
- **Double-Stitched Webbed Strap with Buckle:** For securely fastening loads.
- **Fold-Out Box Lifter:** Extends the toe plate to accommodate oversized cartons.
- **Stair Climbers:** Designed to assist in moving loads up and down stairs.
- **Steel Toe Plate:** Measures 22 inches x 5-1/2 inches for stable load support.



Figure 1: The Haul Master 600 lb. Capacity Appliance Hand Truck, showing its blue frame, black handles, and white solid rubber wheels. The webbed strap and fold-out box lifter are visible.

Setup

The Haul Master Appliance Hand Truck typically comes pre-assembled. However, inspect all components upon receipt to ensure they are securely fastened and free from damage.

1. **Unpacking:** Carefully remove the hand truck from its packaging.
2. **Inspection:** Check all welds, bolts, and moving parts (wheels, fold-out lifter, strap mechanism) for any signs of damage or loose connections.
3. **Strap Check:** Ensure the double-stitched webbed strap is properly attached and the buckle operates smoothly.
4. **Wheel Check:** Verify that the solid rubber wheels spin freely and are securely mounted.
5. **Toe Plate:** Confirm the steel toe plate is firmly attached and the fold-out box lifter extends and retracts without obstruction.

If any components are damaged or missing, do not use the hand truck. Contact customer support for assistance.

Operating Instructions

Follow these steps for safe and effective use of your appliance hand truck:

1. **Prepare the Load:** Ensure the appliance or item to be moved is stable and free of loose parts.
2. **Position the Hand Truck:** Tilt the hand truck slightly backward and slide the toe plate fully under the base of the

appliance. For oversized cartons, extend the fold-out box lifter to provide additional support.

3. **Secure the Load:** Wrap the double-stitched webbed strap around the appliance and secure it tightly with the buckle. The load must be firmly attached to prevent shifting during transport.
4. **Tilt and Balance:** With a firm grip on the handles, slowly tilt the hand truck backward until the load is balanced over the wheels. Ensure the weight is evenly distributed.
5. **Moving the Load:**
    - **On Flat Surfaces:** Push or pull the hand truck slowly and steadily.
    - **On Stairs (using stair climbers):** Position the hand truck at the edge of the step. Slowly pull or push the hand truck, allowing the stair climbers to assist in navigating the steps. Maintain control and a secure grip at all times. It is recommended to have assistance when moving heavy loads on stairs.
6. **Unloading:** Once at the destination, slowly tilt the hand truck forward until the appliance rests on the ground. Release the strap and carefully slide the hand truck away from the appliance.

Maintenance

Regular maintenance will extend the life and ensure the safe operation of your hand truck.

- **Cleaning:** Wipe down the steel frame and wheels with a damp cloth after use to remove dirt and debris.
- **Lubrication:** Periodically apply a light lubricant to the wheel axles and any pivot points (like the fold-out box lifter mechanism) to ensure smooth operation.
- **Strap Inspection:** Regularly inspect the webbed strap for fraying, cuts, or damage. Check the buckle for proper function. Replace the strap if any damage is found.
- **Wheel Inspection:** Check the solid rubber wheels for wear or damage. Ensure they are securely attached and spin freely.
- **Frame and Welds:** Inspect the steel frame and all welded joints for cracks, bends, or signs of stress. Do not use if structural damage is present.
- **Storage:** Store the hand truck in a dry environment to prevent rust and corrosion.

Troubleshooting

Problem	Possible Cause	Solution
Wheels not spinning freely	Dirt/debris in axle, lack of lubrication, damaged wheel bearing.	Clean axles, apply lubricant. If still stiff, inspect for damage and replace wheel if necessary.
Strap not holding load securely	Strap is worn/damaged, buckle is faulty, load not positioned correctly.	Inspect strap and buckle for damage; replace if necessary. Ensure load is centered and strap is tightened properly.
Hand truck feels unstable	Overloaded, load not balanced, damaged frame/wheels.	Reduce load weight. Re-position load to be centered. Inspect frame and wheels for damage.
Fold-out box lifter sticks	Dirt/debris in mechanism, lack of lubrication, bent component.	Clean mechanism, apply lubricant. Inspect for bends and gently straighten if possible, or contact support.

Specifications



Figure 2: Dimensions of the Haul Master Appliance Hand Truck, showing a height of 60 inches, width of 22 inches, and depth of 11 inches.

Attribute	Detail
Brand	Haul Master
Model Number	5828913
Material	Alloy Steel
Color	Blue, Black
Item Weight	37 Pounds
Style	Heavy Duty
Product Dimensions (L x W x H)	11" x 22" x 60"

Attribute	Detail
Wheel Type	Solid Rubber, Nonmarring
Load Capacity	600 Pounds
Number of Wheels	2
Toe Plate Dimensions	22 in. x 5-1/2 in.

Warranty and Support

For warranty information or technical support, please refer to the original purchase documentation or contact Haul Master customer service. Keep your purchase receipt for warranty claims.
For further assistance, visit the official Haul Master website or contact their customer support line.

© 2023 Haul Master. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question