Makita XNB02Z

Makita XNB02Z 18V LXT Straight Finish Nailer Instruction Manual

Model: XNB02Z | 16 Gauge, 2-1/2" Finish Nailer

Introduction

This manual provides essential instructions for the safe operation, setup, maintenance, and troubleshooting of your Makita XNB02Z 18V LXT Straight Finish Nailer. Please read this manual thoroughly before using the tool to ensure proper function and to prevent injury or damage.
The Makita XNB02Z is a cordless 16-gauge straight finish nailer designed for various woodworking applications, including trim work, baseboard, crown molding installation, and flooring. It is compatible with standard 16 gauge straight finish nails ranging from 1 inch to 2-1/2 inches in length.

Safety Information

Always observe basic safety precautions to reduce the risk of fire, electric shock, and personal injury when operating power tools. Keep this manual for future reference.

- **Work Area Safety:** Keep the work area clean and well-lit. Cluttered or dark areas invite accidents. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- **Electrical Safety:** Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges, and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- **Personal Safety:** Always wear eye protection (safety glasses or goggles) and hearing protection. Use a dust mask in dusty conditions. Dress properly; avoid loose clothing or jewelry that can get caught in moving parts.
- **Tool Use and Care:** Do not force the tool. Use the correct tool for your application. Disconnect the battery pack from the tool before making any adjustments, changing accessories, or storing power tools. Store idle tools out of the reach of children.
- **Battery Tool Use and Care:** Recharge only with the charger specified by the manufacturer. Use power tools only with specifically designated battery packs.

Product Overview

Familiarize yourself with the components of your Makita XNB02Z Finish Nailer before operation.



Figure 1: Makita XNB02Z Finish Nailer Components. This diagram illustrates key features including the ergonomically designed handle, trigger lock button, reversible belt clip, 2-mode selective actuation switch, built-in L.E.D. light, "tool-less" quick clear nose design, nail length markings, rear lock-and-load magazine, and anti-dry fire mechanism.

- **Ergonomically Designed Handle:** Features a rubberized soft grip for comfort and control.
- **Trigger Lock Button:** Prevents accidental firing.
- **Reversible Belt Clip:** Allows convenient carrying and access.
- **2-Mode Selective Actuation Switch:** For sequential or contact actuation modes.
- **Built-in L.E.D. Light:** Illuminates the work area for improved visibility.
- **"Tool-less" Quick Clear Nose Design:** Facilitates easy clearing of jammed nails.
- **Nail Length Markings:** Indicates compatible nail sizes.
- **Rear Lock-and-Load Magazine:** For efficient nail loading.
- **Anti-Dry Fire Mechanism:** Helps prevent driving blanks and protects the work surface.

Setup

1. Battery Installation

The Makita XNB02Z operates on an 18V LXT Lithium-Ion battery (sold separately).

1. Ensure the tool is switched off and the trigger lock is engaged.
2. Align the battery pack with the battery housing on the tool.
3. Slide the battery into the housing until it clicks securely into place.
4. To remove, press the release button on the battery and slide it out.



Figure 2: Battery Insertion Area. This image shows the side profile of the nailer, highlighting the area where the 18V LXT battery slides into the tool's housing.

2. Loading Nails

The nailer uses standard 16 gauge straight finish nails from 1" to 2-1/2" in length.

1. Ensure the tool is switched off and the battery is removed.
2. Pull the magazine pusher back until it locks into place.
3. Insert a strip of nails into the magazine with the nail points facing down.

4. Release the magazine pusher, allowing it to push the nails forward until they are seated correctly.



Figure 3: Nail Magazine. A close-up view of the nail magazine, showing the slot where 16 gauge finish nails are loaded.

3. Adjusting Depth

The XNB02Z features a "tool-less" depth adjustment for precise flush and countersink finishes.

1. Locate the depth adjustment dial or lever near the nose of the tool.
2. Rotate the dial or move the lever to increase or decrease the nail driving depth. Test on a scrap piece of material to achieve the desired depth.

Operating Instructions

1. Powering On/Off and Trigger Lock

To power on the tool, ensure a charged battery is inserted. The tool does not have a separate power switch; it activates when the trigger is pulled (after disengaging the trigger lock).

- **Engage Trigger Lock:** Push the trigger lock button to the locked position to prevent accidental firing.
- **Disengage Trigger Lock:** Push the trigger lock button to the unlocked position to enable operation.



Figure 4: Trigger Lock Button. A close-up of the trigger lock button, which must be disengaged before the tool can fire.

2. Selecting Actuation Mode

The 2-mode selective actuation switch allows you to choose between sequential and contact actuation.

- **Sequential Actuation:** For precise nail placement. The contact arm must be pressed against the workpiece, and then the trigger pulled to fire a single nail.

- **Contact Actuation:** For rapid nailing. Hold the trigger, then press the contact arm against the workpiece to fire a nail. Nails will fire as long as the trigger is held and the contact arm is depressed.

3. Nailing Procedure

1. Ensure the battery is charged and nails are loaded.
2. Disengage the trigger lock.
3. Select the desired actuation mode.
4. Place the nose of the nailer firmly against the workpiece at the desired nailing location.
5. Pull the trigger to drive the nail. The built-in LED light will illuminate the work area.
6. Release the trigger and lift the tool from the workpiece.



Figure 5: Built-in LED Light. A close-up view showing the integrated LED light, which provides illumination to the work surface during operation.

4. Anti-Dry Fire Mechanism

The anti-dry fire mechanism prevents the tool from firing when the nail magazine is empty or nearly empty. This protects the tool and prevents damage to the workpiece from blank firing. Reload nails when the mechanism engages.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your tool.

- **Cleaning:** Keep the tool clean and free of dust and debris. Use a dry cloth to wipe down the exterior. Do not use harsh chemicals or solvents.
- **Nose Clearing:** If a nail jam occurs, utilize the "tool-less" quick clear nose design. Ensure the battery is removed before attempting to clear any jams. Open the nose assembly, remove the jammed nail, and close securely.
- **Battery Care:** Store batteries in a cool, dry place. Do not store fully discharged batteries for extended periods.
- **Inspection:** Periodically inspect the tool for any signs of damage, loose screws, or worn parts. Contact an authorized service center for repairs.

Troubleshooting

Refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Nailer does not fire.	Battery not inserted correctly or discharged. Trigger lock engaged. Nail magazine empty (anti-dry fire engaged). Nail jam.	Ensure battery is fully charged and properly seated. Disengage the trigger lock. Reload nails into the magazine. Clear any nail jams using the "tool-less" nose design.
Nails not sinking fully or inconsistent depth.	Depth adjustment set too shallow. Battery charge low. Incorrect nail type or length for material. Nose piece not pressed firmly against workpiece.	Adjust the depth setting deeper. Recharge or replace the battery. Ensure nails are appropriate for the material and tool. Apply firm, consistent pressure to the nose of the tool.
Nail jams frequently.	Damaged or incorrect nails. Worn driver blade or nose piece. Debris in the magazine or nose.	Use only high-quality, compatible nails. Inspect and replace worn parts if necessary (contact service). Clean the magazine and nose area thoroughly.

Specifications

Feature	Detail
Model Number	XNB02Z

Feature	Detail
Power Source	Battery Powered (18V LXT Lithium-Ion)
Nail Gauge	16 Gauge
Nail Length Capacity	1" to 2-1/2"
Magazine Capacity	Up to 110 nails
Item Weight	7.17 pounds
Product Dimensions	4.33 x 15.67 x 12.68 inches
Material	Rubber, Alloy Steel, Urethane, Plastic
Included Components	(2) No-Mar Tip (424440-2), Belt Clip, Safety Glasses
Batteries Included	No (Tool Only)
Voltage	18 Volts

Warranty and Support

The Makita XNB02Z 18V LXT Straight Finish Nailer comes with a**3-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
For warranty claims, technical support, or service inquiries, please contact Makita customer service or visit an authorized Makita service center. Refer to your product packaging or the official Makita website for the most current contact information.
Important: Use of non-genuine ("knock-off") Makita Lithium-Ion batteries may void your warranty and poses a risk of fire, personal injury, or property damage. Always use genuine Makita batteries and chargers.

© 2025 Makita Corporation. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question