Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool WFO 3T123 PF X

Whirlpool WFO 3T123 PF X Dishwasher User Manual

Model: WFO 3T123 PF X

1. Introduction

This manual provides essential information for the safe and efficient operation of your Whirlpool WFO 3T123 PF X Dishwasher. Please read these instructions carefully before using the appliance for the first time and keep them for future reference.

Your new dishwasher features advanced technologies such as 6th Sense Technology and the Power Clean system, designed to optimize washing performance and efficiency.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury to persons.

- Ensure the dishwasher is properly grounded.
- Do not operate the dishwasher if it is damaged or malfunctioning.
- Keep children away from the dishwasher, especially when it is operating.
- Use only detergents and rinse aids specifically designed for automatic dishwashers.
- Avoid opening the door during operation, as hot water and steam may escape.
- Sharp items should be loaded with points down to prevent injury.
- Disconnect the appliance from the power supply before any cleaning or maintenance.

3. Product Overview

The Whirlpool WFO 3T123 PF X is a freestanding dishwasher designed for efficient dish cleaning. It offers 14 place settings and 10 wash programs to accommodate various needs.



Figure 1: Front view of the Whirlpool WFO 3T123 PF X Dishwasher with its door partially open. The silver exterior and the black control panel with digital display and buttons are visible. The interior shows the upper and lower racks, ready for loading dishes.

Key Features:

- **6th Sense Technology:** This intelligent technology automatically adjusts the washing cycle based on the soil level of the dishes, optimizing water, energy, and time consumption by up to 50%.
- **Power Clean System:** Powerful jets located at the back of the lower rack target heavily soiled pots, pans, and baking trays, eliminating the need for pre-soaking or hand pre-washing.
- **14 Place Settings:** Ample capacity to wash a large volume of dishes in a single cycle.
- **10 Programs:** A variety of wash cycles to suit different types of loads and soil levels.
- **Extra Rack:** Provides additional space and flexibility for loading smaller items or cutlery.
- **Digital Countdown Indicator:** Displays the remaining time for the current wash cycle.
- **Salt Light Indicator:** Alerts you when the salt reservoir needs refilling.
- **Start Delay:** Allows you to postpone the start of a wash cycle by up to 24 hours.

4. Setup

4.1 Installation

The Whirlpool WFO 3T123 PF X is a freestanding dishwasher. For proper installation, it is recommended to consult a qualified technician. Ensure the appliance is connected to appropriate water supply, drainage, and electrical outlets according to local regulations.

- Position the dishwasher on a level surface.
- Connect the water inlet hose to a cold water tap.
- Connect the drain hose to a suitable drain pipe.
- Plug the power cord into a grounded electrical outlet.

4.2 Initial Use

Before the first wash cycle, perform the following steps:

1. **Fill the Salt Reservoir:** Unscrew the cap of the salt reservoir (usually located at the bottom of the dishwasher tub). Using the provided funnel, pour dishwasher salt until the reservoir is full. Add water until it overflows. Replace the cap securely.
2. **Fill the Rinse Aid Dispenser:** Open the rinse aid dispenser cap (located on the inner side of the door). Fill with rinse aid up to the maximum level indicator. Close the cap firmly.
3. **Run an Empty Cycle:** Select a short program without dishes to flush out any manufacturing residues.

5. Operating Instructions

5.1 Loading the Dishwasher

Proper loading ensures optimal cleaning results and prevents damage to dishes.

- Scrape off large food particles from dishes before loading.
- Place glasses, cups, and smaller items in the upper rack.
- Arrange plates, bowls, and larger items in the lower rack.
- Utilize the Extra Rack for cutlery or small utensils.
- Ensure that items do not block the spray arms from rotating freely.

5.2 Adding Detergent

Open the detergent dispenser and add the appropriate amount of dishwasher detergent. Close the dispenser lid firmly until it clicks.

5.3 Selecting a Program

Your dishwasher offers 10 programs. Refer to the control panel for program options. Common programs include:

- **Eco Program:** Energy-efficient program for normally soiled dishes.
- **Intensive Program:** For heavily soiled pots and pans.
- **Daily Program:** For everyday loads.
- **6th Sense Program:** Automatically detects soil level and adjusts settings.

To select a program, press the program selection button until the desired program indicator lights up.

5.4 Starting a Cycle

After selecting the program, press the Start button. The digital countdown indicator will show the remaining time.

5.5 Delay Start Function

To delay the start of a cycle, press the Delay Start button repeatedly to set the desired delay time (up to 24 hours). Then press the Start button.

6. Maintenance and Care

Regular maintenance ensures the longevity and optimal performance of your dishwasher.

6.1 Cleaning the Filters

The filter system should be cleaned regularly to prevent blockages and ensure efficient washing. Locate the filter assembly at the bottom of the dishwasher tub, twist to unlock, and remove. Rinse under running water to remove food particles. Reassemble and secure firmly.

6.2 Refilling Salt and Rinse Aid

Monitor the salt light indicator and rinse aid level. Refill as needed to ensure proper water softening and drying performance.

6.3 Cleaning the Interior and Exterior

Wipe the exterior surfaces with a soft, damp cloth. For the interior, periodically run a dishwasher cleaner or a hot cycle with a cup of white vinegar to remove grease and odors.

7. Troubleshooting

Before contacting service, check the following common issues:

Problem	Possible Cause	Solution
Dishes not clean	Improper loading, clogged filters, insufficient detergent, incorrect program.	Reload dishes correctly, clean filters, use adequate detergent, select appropriate program.
Water not draining	Clogged drain hose or filter, drain pump issue.	Clean filters, check drain hose for kinks or blockages.
Dishwasher not starting	Door not closed properly, power supply issue, delay start active.	Ensure door is latched, check power connection, cancel delay start.
Excessive noise	Improperly loaded dishes, foreign object in pump, spray arm hitting items.	Rearrange dishes, check for obstructions.

8. Specifications

Technical specifications for the Whirlpool WFO 3T123 PF X Dishwasher:

Feature	Specification
Model Name	WFO3T123PFX
Brand	Whirlpool
Installation Type	Freestanding

Feature	Specification
Place Settings	14
Number of Programs	10
Water Consumption	9.5 Liters (per cycle)
Energy Class	A++
Cleaning Performance	A
Drying Performance	A
Voltage	230 Volts (AC)
Item Weight	47 Kilograms
Product Dimensions (WxDxH)	60 x 60 x 85 cm
Material Type	Metal
Color	Silver
Controls Type	Push Button
Special Features	Digital Display

9. Warranty and Support

Your Whirlpool WFO 3T123 PF X Dishwasher comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions.

For technical assistance, spare parts, or to schedule a service appointment, please contact Whirlpool customer support. Contact details can typically be found on the Whirlpool official website or in the documentation provided with your appliance.

© 2023 Whirlpool Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01KJRNOGA

More documents and user manuals: **https://manuals.plus/**