Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Adesso CYBERTABLET_T12

Adesso CyberTablet T12HD User Manual

Model: CyberTablet T12

Introduction

The Adesso CyberTablet T12HD is an advanced graphic tablet designed for precise cursor control and enhanced productivity across various applications, including art, business, presentations, and projects. It features high pressure sensitivity and programmable hotkeys to streamline your workflow. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your CyberTablet T12HD.



Image: The Adesso CyberTablet T12HD graphic tablet with its accompanying digital pen, viewed from an angle, showcasing its sleek black design

and the pen resting on its surface.

Setup

1. Package Contents

Before beginning, ensure all items are present in the package:

- CyberTablet T12HD Graphic Tablet
- Digital Pen (requires 2 AAA batteries, included)
- Software CD
- Quick Start Guide (QSG)



Image: The retail packaging for the Adesso CyberTablet T12HD, displaying the product image and key features on the box.

2. Connecting the Tablet

1. Locate the USB cable attached to the CyberTablet T12HD.
2. Plug the USB connector into an available USB 2.0 port on your computer (PC or Mac).
3. The tablet is designed for a secure fit, ensuring stable connection.

3. Installing Drivers and Software

For optimal performance and access to all features, driver installation is required.

1. Insert the provided Software CD into your computer's CD/DVD drive.
2. Follow the on-screen instructions to install the necessary drivers and bundled software (e.g., ArtRage Lite).
3. If your computer does not have a CD/DVD drive, or for the latest drivers, visit the official Adesso support website.

4. Restart your computer after installation is complete to ensure drivers are properly loaded.

Operating Instructions

1. Digital Pen Usage

The digital pen is your primary input device for the CyberTablet T12HD. It offers 2048 levels of pressure sensitivity, allowing for nuanced control over line thickness and opacity in compatible software.

- **Holding the Pen:** Hold the digital pen as you would a regular pen or pencil for comfortable and natural drawing or writing.
- **Pressure Sensitivity:** Apply varying pressure to the pen tip on the tablet surface to achieve different effects, mimicking traditional art tools.
- **Programmable Buttons:** The pen features programmable buttons for quick access to common functions. Refer to the driver software settings to customize these buttons.



Image: Components of the digital pen and its stand, including the pen itself and the base for holding it, along with replacement nibs.



Image: A close-up view of the digital pen, highlighting its two programmable buttons located on the side of the barrel.

2. Tablet Working Area and Hotkeys

The CyberTablet T12HD features a 10" x 6" widescreen drawing area that automatically adjusts to your monitor's aspect ratio, providing ample space for detailed work.

- **Active Area:** The designated 10" x 6" area on the tablet is where pen input is recognized.
- **8 Programmable Hotkeys:** Located on the side of the tablet, these hotkeys provide quick access to frequently used functions such as open, cut, paste, save, undo, redo, and print. These keys can be customized through the tablet's driver software to suit your specific needs.



Image: An angled view of the Adesso CyberTablet T12HD, emphasizing the row of eight programmable hotkeys along the left side of the tablet.

3. Software Compatibility

The CyberTablet T12HD is compatible with various graphic design and office software. It supports functions like document annotation, freehand illustrations, graphic design, whiteboard presentations, digital signatures, and handwritten emails. The bundled ArtRage Lite software enhances drawing capabilities.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and capabilities of the Adesso CyberTablet T12HD, including its pressure sensitivity, resolution, and use in various artistic and design applications.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the tablet surface and digital pen. Avoid abrasive cleaners or solvents.
- **Pen Nib Replacement:** Over time, the pen nib may wear down. Replace it with a new nib from the included accessories. Gently pull out the old nib and insert the new one firmly.
- **Battery Replacement:** The digital pen requires 2 AAA batteries. Replace them when the pen's responsiveness decreases.

- **Storage:** When not in use, store the tablet and pen in a clean, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Tablet not responding:

- Ensure the USB cable is securely connected to both the tablet and the computer.
- Try connecting to a different USB port.
- Verify that the drivers are correctly installed. Reinstall if necessary.
- Check if the digital pen batteries are properly inserted and have sufficient charge.

Pen pressure sensitivity not working:

- Confirm that the software you are using supports pressure sensitivity.
- Check the tablet driver settings to ensure pressure sensitivity is enabled and calibrated.
- Ensure the pen nib is not excessively worn. Replace if needed.

Hotkeys not functioning:

- Ensure the tablet drivers are installed.
- Access the tablet's control panel or driver settings to configure or reset the hotkey assignments.

Cursor jumps or is inaccurate:

- Ensure the tablet surface is clean and free of debris.
- Recalibrate the tablet and pen through the driver software.
- Avoid placing the tablet near strong electromagnetic fields.

Specifications

Feature	Detail
Brand	Adesso
Model Name	CyberTablet T12
Item Model Number	CYBERTABLET_T12
Working Area	10" x 6" Widescreen
Pressure Sensitivity	2048 Levels
Resolution	5080 LPI (Lines Per Inch)
Report Rate	230 RPS (Reports Per Second)
Hotkeys	8 Programmable Hotkeys
Connectivity	USB 2.0
Dimensions (LxWxH)	14 x 8.25 x 0.25 inches
Item Weight	2.5 pounds

Feature	Detail
Pen Batteries	2 AAA batteries (included)
Color	Black

Warranty and Support

Adesso products are designed for reliability and performance. For information regarding warranty coverage, technical support, or to download the latest drivers and software, please visit the official Adesso website or contact their customer service department.
Official Website: www.adesso.com
Please retain your proof of purchase for warranty claims.

© 2024 Adesso Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01KJXVHCM

More documents and user manuals: **https://manuals.plus/**