Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CalExotics SE-0077-20-3

CalExotics Silicone Remote Ridged G Vibrator Instruction Manual

Model: SE-0077-20-3

Introduction

This manual provides essential information for the safe and effective use of your CalExotics Silicone Remote Ridged G Vibrator. Please read these instructions thoroughly before first use and retain for future reference.
The CalExotics Remote Silicone Ridged G Vibrator is a wireless personal massager featuring a curved, ridged tip designed for targeted stimulation. It offers 12 functions of vibration, pulsation, and escalation, controlled by a remote. The device is made from silicone and is waterproof.

Safety Information

- This device is intended for adult use as a non-medical pleasure device only. It is not for medical use.
- Discontinue use immediately if you experience any discomfort, pain, or irritation. Consult a healthcare professional if symptoms persist.
- Do not share the device with others to maintain hygiene.
- Keep out of reach of children.
- Ensure the battery compartments are securely closed before use, especially when using in water.
- Do not attempt to disassemble or modify the device, as this may void the warranty and pose safety risks.
- Use only with water-based lubricants. Oil-based lubricants can damage silicone products.

Package Contents

Your package should contain the following items:

- 1 x CalExotics Silicone Remote Ridged G Vibrator
- 1 x Wireless Remote Control



Image: The CalExotics Silicone Remote Ridged G Vibrator and its remote control displayed in their retail packaging.

Setup: Battery Installation

The device requires 2 AAA batteries for the vibrator and 1 AAA battery for the remote control (batteries not included).

Vibrator Battery Installation:

1. Gently twist off the cap at the base of the vibrator to open the battery compartment.
2. Insert 2 AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
3. Securely twist the cap back onto the vibrator until it is fully closed to ensure waterproof sealing.

Remote Control Battery Installation:

1. Locate the battery cover on the back of the remote control.

2. Carefully remove the battery cover.
3. Insert 1 AAA battery, observing the correct polarity (+/-).
4. Replace the battery cover securely.



Image: Detailed view of how to open the battery compartments for both the vibrator and the remote control to insert AAA batteries.

Operating Instructions

The CalExotics Silicone Remote Ridged G Vibrator features 12 functions of vibration, pulsation, and escalation, controlled wirelessly.

Power On/Off:

- To turn the vibrator **ON**, press and hold the power button on the remote control for approximately 3 seconds. The vibrator will start.
- To turn the vibrator **OFF**, press and hold the power button on the remote control for approximately 3 seconds again.

Changing Functions:

- Once the vibrator is on, short press the function button on the remote control to cycle through the 12 different vibration patterns and intensities.

SILICONE REMOTE
RIDGED G



HYGIENICALLY **SUPERIOR SILICONE**

EASY TO USE PUSH BUTTON CONTROL; **HOLD** FOR **3 SECONDS** TO TURN **OFF**

12 FUNCTIONS OF INTENSE VIBRATION, PULSATION, AND ESCALATION

- **COMPACT** AND **DISCREET REMOTE**
- USE ALONE OR **WITH A PARTNER**
- **EASY RETRIEVAL** CORD
- **INSTRUCTIONS** INCLUDED
- **WATERPROOF** STIMULATOR MAY BE USED **IN** OR **OUT** OF THE WATER

32.75'/10M RANGE

USES STANDARD
AAA BATTERIES
(NOT INCLUDED)

SE-0077-20-3

06.2016

©2016 California Exotic Novelties, LLC, Ontario, CA. Made in China. Product Registration: vibetronics.com Material: Silicone (stimulator), ABS with PU Cote (controller, décor), ABS with Silver Plating (button). All rights reserved. The shape and appearance of this packaging is a trademark and trade dress of California Exotic Novelties, LLC. Wash before and after each use. Use with water-based lubricant. Do not immerse controller in water. For adult use as a non-medical pleasure device only. Not for medical use. Discontinue use in the event of any medical condition or pain. EC-R+TTE certificate included. CE 0700 radio transmitting frequency 433 MHz conforms to FCC



Image: A close-up view of the remote control, highlighting the power/function button.



Image: A hand demonstrating the comfortable grip and size of the CalExotics Silicone Remote Ridged G Vibrator.

Maintenance

Cleaning:

- Always clean your device thoroughly before and after each use.

- Wash the silicone vibrator with warm water and a mild soap or a specialized toy cleaner.
- Rinse thoroughly and pat dry with a lint-free cloth.
- Ensure the battery cap is securely fastened if cleaning under running water.
- The remote control is not waterproof; clean it with a damp cloth only.

Your browser does not support the video tag.

Video: This video demonstrates the waterproof nature of the vibrator, showing it submerged in water. It also illustrates the battery installation process for both the vibrator and the remote control, and highlights the easy retrieval cord.

Storage:

- Store the device in a clean, dry, and cool place, away from direct sunlight and extreme temperatures.
- Keep it separate from other toys made of different materials to prevent material degradation.
- Remove batteries if the device will not be used for an extended period to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Batteries are dead or incorrectly inserted. Power button not held long enough.	Replace batteries in both the vibrator and remote, ensuring correct polarity. Press and hold the power button on the remote for 3 seconds to activate.
Weak or inconsistent vibration.	Low battery power. Loose battery connection.	Replace batteries in the vibrator. Ensure battery cap is tightly secured.
Remote control not responding.	Remote battery is dead or incorrectly inserted. Out of range.	Replace the battery in the remote, ensuring correct polarity. Ensure the remote is within the operating range (approximately 32.75 ft / 10m).

Specifications

Model Number	SE-0077-20-3
Brand	CalExotics
Material	Silicone
Color	Black
Dimensions (Vibrator)	Approximately 2 x 4.75 x 8.5 inches (5.08 x 12.07 x 21.59 cm)
Weight	Approximately 4.64 ounces (131.5 g)
Power Source	Vibrator: 2 AAA batteries (not included) Remote: 1 AAA battery (not included)
Functions	12 vibration, pulsation, and escalation functions
Waterproof	Vibrator is waterproof
Remote Range	Up to 32.75 feet (10 meters)



Image: A visual representation of the vibrator's dimensions, indicating its length and width.

Warranty and Support

This product comes with a **1-year manufacturer warranty**. For warranty claims or technical support, please contact CalExotics customer service. Refer to the product packaging or the official CalExotics website for contact details.
For additional information and product registration, visit: www.calexotics.com

© 2024 CalExotics. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01KOHQD36

More documents and user manuals: **https://manuals.plus/**