Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 1541

Ariete 1541 Mixy Orange Electric Hand Mixer User Manual

Model: 1541 Mixy Orange (00C154100AR0)

1. Introduction

Thank you for purchasing the Ariete 1541 Mixy Orange Electric Hand Mixer. This appliance is designed for efficient mixing, whisking, and kneading in your kitchen. To ensure safe and optimal performance, please read this instruction manual carefully before first use and retain it for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Keep hands and utensils away from the mixing attachments during operation to prevent injury to persons and/or damage to the mixer.
- Ensure the appliance is switched off before changing accessories or approaching parts that move in use.

3. Product Components

The Ariete 1541 Mixy Orange Electric Hand Mixer comes with the following components:

- Main Motor Unit with Speed Selector and Eject Button
- Two Whisk Attachments (for beating and whisking)

- Two Dough Hook Attachments (for kneading)





Image 1: The Ariete 1541 Mixy Orange Electric Hand Mixer shown with the dough hook attachments inserted. The main unit is white with an orange ribbed design.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging. Dispose of packaging materials responsibly.
2. **Initial Cleaning:** Before first use, wash the whisk and dough hook attachments in warm, soapy water. Rinse thoroughly and dry. Wipe the main motor unit with a damp cloth. Do not immerse the motor unit in water.
3. **Attach Accessories:** Select the desired attachments (whisks or dough hooks). Insert the stems of the attachments into the openings on the underside of the mixer until they click into place. Ensure both attachments are securely fastened. The dough hooks are designed to fit in specific holes; ensure the hook with the collar is inserted into the larger hole.

5. Operating Instructions

The Ariete 1541 Mixy Orange features 6 speed settings and a turbo function for versatile mixing tasks.

1. **Preparation:** Place ingredients in a suitable mixing bowl.
2. **Plug In:** Ensure the mixer is switched off (speed selector at '0') before plugging the appliance into a suitable power outlet (240V).
3. **Start Mixing:** Immerse the attachments into the ingredients. Select the desired speed by sliding the speed selector switch. Start with a low speed and gradually increase as needed.
4. **Turbo Function:** For short bursts of maximum power, press and hold the 'Turbo' button. Release the button to return to the selected speed.
5. **Stop Mixing:** Once mixing is complete, slide the speed selector switch back to '0'. Unplug the mixer from the power outlet.
6. **Eject Attachments:** Press the eject button to release the attachments.

Usage Examples:



Image 2: The hand mixer with whisk attachments, positioned next to a bowl of whipped cream and meringues, demonstrating its use for light mixtures.

- **Whisking (Whisk Attachments):** Ideal for whipping cream, egg whites, making meringues, and light batters. Use speeds 1-6, with turbo for quick finishing.



Image 3: The hand mixer with dough hook attachments, positioned near pizza dough, flour, and eggs, illustrating its use for heavier doughs.

- **Kneading (Dough Hook Attachments):** Suitable for mixing and kneading bread dough, pizza dough, and other heavier mixtures. Start at low speeds (1-3) and gradually increase as the dough forms.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your hand mixer.

- **Always unplug the appliance** from the power outlet before cleaning.
- **Attachments:** The whisk and dough hook attachments are dishwasher safe or can be washed by hand in warm, soapy water. Rinse thoroughly and dry immediately.
- **Motor Unit:** Wipe the exterior of the motor unit with a soft, damp cloth. Do not use abrasive cleaners or scourers. Never immerse the motor unit in water or any other liquid.
- **Storage:** Store the mixer and its attachments in a dry place, away from direct sunlight and out of reach of children.

7. Troubleshooting

If you encounter issues with your Ariete hand mixer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mixer does not turn on.	Not plugged in; power outlet fault; speed selector at '0'.	Ensure plug is securely in outlet; test outlet with another appliance; turn speed selector to a numbered setting.
Attachments do not fit or eject.	Attachments incorrectly inserted; eject button not fully pressed.	Ensure attachments are aligned with the correct holes and pushed in firmly; press the eject button completely.
Unusual noise or vibration.	Attachments not properly secured; excessive load.	Check attachments are securely locked; reduce the amount of ingredients or consistency of mixture.

If the problem persists after attempting these solutions, please contact Ariete customer support.

8. Technical Specifications

Refer to the following specifications for your Ariete 1541 Mixy Orange Electric Hand Mixer:

Feature	Specification
Brand	Ariete
Model Number	00C154100AR0
Power	250 Watts
Voltage	240 Volts
Number of Speeds	6 + Turbo Function
Material	Stainless Steel (attachments), Plastic (body)
Product Dimensions (approx.)	22 x 16.6 x 9.8 cm
Item Weight (approx.)	1.02 kg



Image 4: Diagram showing the approximate dimensions of the Ariete 1541 Mixy Orange Electric Hand Mixer, indicating a height of 20.5cm, width of 19cm, and depth of 9cm for the main unit.

9. Warranty and Support

Your Ariete 1541 Mixy Orange Electric Hand Mixer is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, spare parts, or warranty claims, please contact Ariete customer service through their official website or the contact information provided in your product packaging.

© 2023 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01KSB15NQ

More documents and user manuals: **https://manuals.plus/**