Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

auna MG3-Roadie WhBTUSB

auna Roadie CD Bluetooth Boombox - Instruction Manual

Model: MG3-Roadie WhBTUSB

1. Introduction

Thank you for purchasing the auna Roadie CD Bluetooth Boombox. This portable audio system combines a CD player, USB MP3 playback, Bluetooth connectivity, and an FM radio, all enhanced with integrated LED lighting. This manual provides essential information for safe operation, setup, and maintenance of your device. Please read it thoroughly before use and retain it for future reference.

2. Safety Instructions

To ensure safe operation and prevent damage, please observe the following safety precautions:

- **Power Source:** Use only the specified power adapter or batteries. Ensure the voltage matches the device requirements.
- **Water and Moisture:** Do not expose the device to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids, such as vases, on the device.
- **Ventilation:** Do not block any ventilation openings. Ensure adequate space around the device for proper airflow.
- **Heat:** Keep the device away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the device from the power outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Batteries:** If using batteries, ensure they are inserted with correct polarity. Do not mix old and new batteries, or different types of batteries. Remove batteries if the device will not be used for a long period.

3. Package Contents

Upon unpacking, please verify that all items listed below are present and in good condition:

- 1 x auna Roadie CD Bluetooth Boombox
- 1 x Power Cord

- 1 x Instruction Manual (this document)

4. Product Overview

4.1 Front and Side Views

Familiarize yourself with the main controls and features of your auna Roadie boombox.



Image 1: Front view of the auna Roadie boombox. This image shows the central display, USB port, and the two speaker grilles with integrated LED lighting. Control buttons are visible above the display.



Image 2: Side view of the auna Roadie boombox. This image highlights the rotary volume control knob and the multi-function selector switch for OFF/AM/FM/CD/USB/BT/AUX modes.



Image 3: Opposite side view of the auna Roadie boombox. This image displays the rotary tuning knob used for selecting radio frequencies.

4.2 Rear View



Image 4: Rear view of the auna Roadie boombox. This image shows the AC power input socket and the telescopic FM antenna.

4.3 Controls and Connections

- **Power/Function Selector:** (Side) Switches the unit ON/OFF and selects between AM, FM, CD, USB, Bluetooth (BT), and AUX modes.
- **Volume Knob:** (Side) Adjusts the audio output level.
- **Tuning Knob:** (Side) Used to manually tune FM radio stations.
- **CD Compartment:** (Top) For inserting audio CDs.
- **USB Port:** (Front) For connecting USB storage devices for MP3/WMA playback.
- **Display:** (Front) Shows current mode, track number, and radio frequency.
- **Control Buttons:** (Top) Play/Pause, Stop, Skip/Search (Forward/Backward), Program, Repeat.
- **LED Lighting Button:** (Top) Controls the integrated LED lighting effects.
- **AUX Input (3.5mm):** (Side/Rear, refer to specific model for exact location) For connecting external audio devices.
- **Headphone Output (3.5mm):** (Side/Rear, refer to specific model for exact location) For private listening.
- **AC Power Input:** (Rear) For connecting the power cord.
- **Telescopic Antenna:** (Rear) For improving FM radio reception.

5. Setup

5.1 Powering the Device

Your auna Roadie boombox can be powered by either AC mains or batteries.

5.1.1 AC Power Operation

1. Ensure the Power/Function Selector is in the **OFF** position.
2. Connect the supplied AC power cord to the AC power input socket on the rear of the unit.
3. Plug the other end of the power cord into a standard wall outlet.

5.1.2 Battery Operation

For portable use, the unit requires 6 x C-type batteries (not included).

1. Ensure the Power/Function Selector is in the **OFF** position.
2. Open the battery compartment cover located on the bottom of the unit.
3. Insert 6 x C-type batteries, observing the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

Note: When the AC power cord is connected, battery power is automatically disconnected.

6. Operating Instructions

6.1 Power On/Off and Mode Selection

Rotate the **Power/Function Selector** switch on the side of the unit to turn it ON and select your desired audio source (AM, FM, CD, USB, BT, AUX). To turn off the unit, rotate the selector to the **OFF** position.

6.2 CD Playback

1. Set the Power/Function Selector to **CD** mode.
2. Open the CD compartment cover on the top of the unit.
3. Place a CD (CD, CD-R, CD-RW, or MP3-CD) onto the spindle with the label side facing up.
4. Close the CD compartment cover. The unit will read the disc, and the display will show the total number of tracks.
5. Press the **PLAY/PAUSE** button to start playback.
6. Use the **SKIP/SEARCH** buttons to navigate between tracks.
7. Press the **STOP** button to stop playback.
8. **Program Playback:** While in STOP mode, press the **PROGRAM** button to create a custom playlist (up to 20 tracks for CD, 99 for MP3-CD).
9. **Repeat Playback:** Press the **REPEAT** button to repeat the current track or all tracks.

6.3 USB Playback

1. Set the Power/Function Selector to **USB** mode.
2. Insert a USB storage device (flash drive) containing MP3 or WMA audio files into the USB port on the front of the unit.
3. The unit will automatically detect and begin playing the audio files.
4. Use the **PLAY/PAUSE**, **STOP**, and **SKIP/SEARCH** buttons as you would for CD playback.
5. **Folder Playback:** For MP3-CDs with folder structures, the unit supports folder playback.

6.4 Bluetooth Connection

1. Set the Power/Function Selector to **BT** (Bluetooth) mode. The unit will enter pairing mode, and the Bluetooth indicator on the display may flash.

2. Enable Bluetooth on your smartphone, tablet, or other Bluetooth-enabled device.
3. Search for available devices and select "auna Roadie" from the list.
4. Once paired, the Bluetooth indicator will become solid, and you can play audio from your connected device through the boombox.
5. Control playback (play/pause, skip) from your connected device or using the boombox's controls.

6.5 FM Radio

1. Set the Power/Function Selector to **FM** mode.
2. Extend the telescopic antenna on the rear of the unit for optimal reception.
3. Rotate the **Tuning Knob** on the side of the unit to search for radio stations. The frequency will be shown on the display.
4. Adjust the antenna position for the best signal clarity.

6.6 AUX Input

1. Set the Power/Function Selector to **AUX** mode.
2. Connect an external audio device (e.g., MP3 player, smartphone) to the 3.5mm AUX input jack using a 3.5mm audio cable (not included).
3. Play audio from your external device. The sound will be output through the boombox speakers.
4. Adjust the volume using the boombox's Volume Knob and/or the volume control on your external device.

6.7 Headphone Output

To listen privately, plug 3.5mm stereo headphones (not included) into the headphone output jack. The speakers will automatically mute.

6.8 LED Lighting

The auna Roadie features integrated LED lighting that can react to the rhythm of the music. Press the **LED Lighting Button** (located on the top panel) to cycle through different lighting modes or to turn the lighting off.

7. Maintenance

7.1 Cleaning

- Always unplug the device from the power source before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces.
- Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- For the CD lens, use a specialized CD lens cleaning kit.

7.2 Storage

If the unit will not be used for an extended period, remove the batteries and store the unit in a cool, dry place, away from direct sunlight and extreme temperatures.

8. Troubleshooting

If you encounter issues with your auna Roadie boombox, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cord not connected; Batteries depleted or incorrectly inserted; Power/Function Selector in OFF position.	Check power cord connection; Replace batteries or ensure correct polarity; Rotate selector to an ON mode.
No sound	Volume too low; Incorrect mode selected; Headphones connected.	Increase volume; Select correct source mode (CD, USB, BT, FM, AUX); Disconnect headphones.
CD not playing / skipping	CD dirty or scratched; CD inserted incorrectly; CD compartment not closed.	Clean or replace CD; Insert CD with label side up; Close compartment securely.
USB not playing	USB device not inserted correctly; Incompatible file format; USB device corrupted.	Re-insert USB device; Ensure files are MP3/WMA; Try a different USB device.
Bluetooth not connecting	Boombox not in BT mode; Bluetooth not enabled on external device; Device too far away.	Select BT mode on boombox; Enable Bluetooth on your device; Move devices closer (within 10m).
Poor FM radio reception	Antenna not extended; Weak signal; Interference.	Fully extend and adjust the telescopic antenna; Try moving the unit to a different location.

If the problem persists after trying these solutions, please contact customer support.

9. Specifications

- **Brand:** auna
- **Model Number:** MG3-Roadie WhBTUSB
- **Connectivity Technology:** USB, Bluetooth
- **Color:** White, Lilac
- **Speaker Type:** Stereo
- **Output Power:** 2 x 1.5 W RMS (Total 18 W)
- **Power Source:** AC Power Cable, 6 x C-type Batteries (DC 9V, not included)
- **Compatible Devices:** Smartphones, Tablets, MP3 Players
- **Supported Audio Formats:** MP3, WMA (via USB/CD)
- **Supported CD Formats:** CD, CD-R, CD-RW, MP3-CD
- **Bluetooth Version:** 2.1 + EDR (Profile: A2DP, AVRCP)
- **Radio Tuner:** AM/FM
- **Dimensions (L x W x H):** Approximately 20 x 24 x 13 cm (7.9 x 9.4 x 5.1 inches)
- **Weight:** Approximately 1.5 kg (3.3 lbs)
- **Global Trade Item Number (GTIN):** 04260435919995

10. Warranty and Support

This product comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase or contact your retailer for specific warranty terms and conditions.

For technical support, troubleshooting assistance, or inquiries about replacement parts, please contact auna customer service through their official website or the contact information provided with your purchase documentation.

© 2023 auna. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01KVSTD7G

More documents and user manuals: **https://manuals.plus/**