Beyblade B9491

Beyblade Burst Dual Gaianon & Doomscizor

OFFICIAL INSTRUCTION MANUAL

1. Introduction

Welcome to the world of Beyblade Burst! This manual provides essential information for the assembly, operation, and care of your Beyblade Burst Dual Gaianon and Doomscizor tops. Please read these instructions carefully before use to ensure proper handling and maximum enjoyment.

Beyblade Burst tops are designed for competitive play in a Beyblade Burst Beystadium (sold separately). These tops feature a unique "burst" mechanism, where tops can break into pieces during battle, adding an exciting element to the game.

2. Product Overview

Your Beyblade Burst set includes two distinct tops, each composed of three interchangeable parts: an Energy Layer, a Forge Disc, and a Performance Tip. These components allow for customization and strategic play.

- **Gaianon G2:** Consists of the Gaianon G2 (aka Giga Gaianon) Energy Layer, D21 (aka Quarter) Forge Disc, and TB01 (aka Fusion) Performance Tip.
- **Doomscizor:** Consists of the Doomscizor Energy Layer, D13 (aka Oval) Forge Disc, and TA01 (aka Accel) Performance Tip.

The components of these Beyblade Burst tops are interchangeable with most other Beyblade Burst tops, excluding Beyblade Burst Rip Fire tops. This feature allows for extensive customization and strategic combinations.



Figure 2.1: Assembled Beyblade Burst Gaianon G2 and Doomscizor tops.

Additionally, you can scan the code located on the Beyblade Burst Energy Layers to unlock and battle with your tops within the Beyblade Burst app. The app allows you to experiment with different top component combinations in a virtual stadium environment.

3. What's in the Box

Your Beyblade Burst Dual Gaianon and Doomscizor package includes the following components:

- 1x Gaianon G2 Energy Layer
- 1x D21 (Quarter) Forge Disc
- 1x TB01 (Fusion) Performance Tip
- 1x Doomscizor Energy Layer
- 1x D13 (Oval) Forge Disc
- 1x TA01 (Accel) Performance Tip



Figure 3.1: Contents of the Beyblade Burst Dual Gaianon and Doomscizor package.

4. Setup

To prepare your Beyblade Burst tops for battle, follow these assembly instructions:

1. **Assemble the Top:** Take one Energy Layer, one Forge Disc, and one Performance Tip. Align the tabs on the Forge Disc with the slots on the Energy Layer.
2. **Connect Components:** Press the Forge Disc and Energy Layer together firmly until they click into place.
3. **Attach Performance Tip:** Insert the Performance Tip into the bottom of the assembled Forge Disc and Energy Layer. Twist until it locks securely. Ensure all three parts are tightly connected to prevent premature bursting during launch.
4. **Prepare Launcher (Sold Separately):** Insert your assembled Beyblade Burst top into a Beyblade Burst launcher (sold separately). Ensure the top is securely attached to the launcher.
5. **Prepare Beystadium (Sold Separately):** Place your Beyblade Burst Beystadium (sold separately) on a flat, stable surface. Ensure there is enough clear space around the stadium for safe play.

Note: Beyblade Burst launchers and a Beyblade Burst Beystadium are required for play and are sold separately.

5. Operating Instructions

Once your Beyblade Burst top is assembled and attached to a launcher, you are ready to battle:

1. **Launch Your Top:** Hold the launcher over the Beyblade Burst Beystadium. Pull the ripcord or press the launch button (depending on your launcher type) with a swift, strong motion to launch your top into the stadium. Aim for the center of the stadium for optimal spin.
2. **Battle Mechanics:** The objective is to knock your opponent's top out of the stadium or cause it to stop spinning. Beyblade Burst tops can also "burst" into multiple pieces during battle.
3. **Scoring:** Points are awarded based on the outcome of the battle. If your opponent's top bursts into pieces, you earn 2 points. If your opponent's top is knocked out of the stadium or stops spinning before yours, you earn 1 point. The first player to earn 3 points wins the match.
4. **App Integration:** To enhance your play experience, download the Beyblade Burst app. Scan the code on the Energy Layer of your Beyblade Burst top using the app to unlock it digitally. You can then battle with your digital tops and customize them within the app.

6. Maintenance

Proper care will extend the lifespan of your Beyblade Burst tops:

- **Cleaning:** Wipe the tops with a dry, soft cloth after use to remove dust and debris. Avoid using water or cleaning solutions, as they may damage the components.
- **Storage:** Store your Beyblade Burst tops and components in a clean, dry place away from direct sunlight and extreme temperatures. Keeping them in a dedicated storage case can prevent loss and damage.
- **Handling:** Handle the tops with care. Avoid dropping them or subjecting them to excessive force, which can cause damage to the plastic components.
- **Inspection:** Periodically inspect all components for signs of wear or damage. Replace any broken or severely worn parts to maintain optimal performance.

7. Troubleshooting

If you encounter issues with your Beyblade Burst tops, consider the following:

- **Top Not Spinning Properly:**
    - Ensure the Performance Tip is clean and free of debris.
    - Verify that all three components (Energy Layer, Forge Disc, Performance Tip) are securely locked together.

- Check your launcher for proper function and ensure the top is correctly attached before launching.

- **Top Bursts Too Easily/Not At All:**
  - Burst rates vary between tops and depend on battle conditions. Some tops are designed to burst more frequently than others.
  - Ensure the top is assembled correctly and all parts are firmly clicked into place. Loose connections can affect burst performance.
  - The condition of the Beystadium and the force of the launch can also influence bursting.

- **App Not Scanning Code:**
  - Ensure you have good lighting when scanning the code on the Energy Layer.
  - Clean the code area on the Energy Layer if it is dirty or smudged.
  - Make sure your device's camera is functioning correctly and the app has camera permissions.

8. Specifications

Feature	Detail
Product Dimensions	1.5 x 5.98 x 7.99 inches
Item Weight	3.2 ounces
ASIN	B01LA8TSBW
Item Model Number	B9491
Manufacturer Recommended Age	4 years and up
Manufacturer	Hasbro

9. Warranty Information

Specific warranty details for Beyblade products are typically provided by the manufacturer, Hasbro, or the retailer at the time of purchase. Please refer to the product packaging or visit the official Hasbro website for the most current and detailed warranty information. Keep your proof of purchase for any warranty claims.

10. Customer Support

For further assistance, questions, or to report any issues with your Beyblade Burst product, please contact Hasbro customer service. You can typically find contact information on the product packaging or by visiting the official Beyblade or Hasbro websites.

You may also visit the official Beyblade Store on Amazon for more information and products: Beyblade Store

© 2024 Beyblade / Hasbro. All rights reserved. Beyblade Burst and all related terms are trademarks of Hasbro.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question