Hampton Bay 1001 409 264

Hampton Bay 1-Light Oil Rubbed Bronze Mini Pendant Instruction Manual

Model: 1001 409 264

1. Product Overview

The Hampton Bay 1-Light Oil Rubbed Bronze Mini Pendant is designed to provide ambient lighting in various indoor settings such as kitchens, dining areas, and living rooms. This fixture features a burnished bronze metal finish and a clear glass shade, offering a refined rustic aesthetic. Its adjustable height allows for versatile placement and customization.



Image 1.1: Hampton Bay 1-Light Oil Rubbed Bronze Mini Pendant. This image displays the complete pendant light fixture, featuring an oil rubbed bronze finish on the metal components and a clear bell-shaped glass shade. The fixture is suspended by a rod, illustrating its design and overall appearance.

2. Safety Information

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these instructions carefully.

- Read all instructions before beginning installation.
- Consult a qualified electrician if you are not familiar with electrical installations.
- Turn off the main power supply at the circuit breaker or fuse box before installing or servicing the fixture.
- Ensure all electrical connections comply with local codes and ordinances.
- Use only the specified bulb type and wattage (1 E26 socket, 60-Watt maximum or LED equivalent).
- Do not install this fixture in wet locations. It is designed for indoor use only.
- Handle glass components with care to prevent breakage.

3. Package Contents

Verify that all components are present before beginning installation. If any part is missing or damaged, do not attempt to assemble or install the product.

- Mini Pendant Light Fixture (Oil Rubbed Bronze finish)
- Clear Glass Shade
- Ceiling Canopy (5 in. D)
- Adjustable Metal Rods:
  - One (1) 6-inch rod
  - Three (3) 12-inch rods
- Mounting Hardware (screws, wire nuts, etc.)
- *Bulb not included (requires 1 E26 socket, 60-Watt maximum or LED equivalent)*

4. Setup and Installation

Professional installation is recommended for individuals unfamiliar with electrical wiring. Ensure power is OFF at the circuit breaker before proceeding.

1. **Prepare for Installation:**
   - Turn off power at the main circuit breaker.
   - Clear the work area and gather necessary tools (screwdriver, wire strippers, electrical tape, etc.).
2. **Determine Hanging Height:**
   The fixture includes four removable rods: one 6-inch and three 12-inch rods. Combine these rods to achieve the desired overall hanging height, ranging from 9.6 inches to 51.75 inches (total drop length from ceiling to bottom of fixture).
   - Connect the chosen rods by screwing them together securely.
   - Thread the fixture wires through the assembled rods.
3. **Attach Mounting Plate:**
   - Secure the mounting plate (located inside the ceiling canopy) to the electrical junction box in the ceiling using the provided screws.
   - Ensure the mounting plate is firmly attached and level.
4. **Make Electrical Connections:**
   - Connect the fixture's black wire to the house's black (hot) wire.
   - Connect the fixture's white wire to the house's white (neutral) wire.
   - Connect the fixture's ground wire to the house's ground wire (or to the mounting plate if no house ground is available).
   - Secure all connections with wire nuts and wrap with electrical tape for added safety.
5. **Install Ceiling Canopy:**
   Carefully push the ceiling canopy up against the ceiling, covering the junction box and wiring. Secure it to the mounting plate using the provided screws. The swivel joint under the canopy allows for adjustment on uneven ceilings.
6. **Attach Glass Shade:**
   Carefully attach the clear glass shade to the fixture. Ensure it is securely fastened according to the fixture's design (typically by a threaded ring or screws).

7. **Install Bulb:**
   Screw one E26 base bulb (maximum 60-Watt incandescent or LED equivalent) into the socket.*A vintage filament bulb is suggested for aesthetic purposes.*
8. **Restore Power:**
   Once installation is complete and all connections are secure, restore power at the circuit breaker and test the fixture.

5. Operating Instructions

This pendant light operates via a standard wall switch (not included). Once installed and powered, simply use the wall switch connected to the circuit to turn the light on or off.

- **Power On/Off:** Use the connected wall switch to control the light.
- **Bulb Replacement:** Ensure power is off at the circuit breaker before replacing the bulb. Allow the bulb to cool completely before touching. Unscrew the old bulb and screw in a new E26 base bulb (max 60W or LED equivalent).

6. Maintenance

Regular maintenance will help preserve the appearance and functionality of your pendant light.

- **Cleaning the Fixture:**
  - Turn off power to the fixture before cleaning.
  - Wipe the metal parts with a soft, dry cloth. Do not use abrasive cleaners or polishes, as they may damage the finish.
- **Cleaning the Glass Shade:**
  - Remove the glass shade carefully.
  - Wash with mild soap and water, or a glass cleaner.
  - Rinse thoroughly and dry completely before reattaching.

7. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	• Power is off at the circuit breaker. • Loose wire connections. • Defective bulb.	• Check and reset the circuit breaker. • Turn off power, check all wire connections, and re-secure if loose. • Replace the bulb with a new one.
Light flickers.	• Loose bulb. • Incorrect bulb type/wattage. • Loose wire connections.	• Tighten the bulb. • Ensure the bulb is E26 base, max 60W, or compatible LED. • Turn off power, check and tighten wire connections.
Glass shade is loose.	• Retaining ring/screws not tightened.	• Carefully tighten the retaining ring or screws that secure the glass shade.

8. Specifications

Brand	Hampton Bay

Model Number	1001 409 264
Product Type	Mini Pendant Light
Finish Type	Oil Rubbed Bronze
Shade Material	Clear Glass
Material	Bronze, Glass, Metal
Dimensions (Assembled)	5.5 in. D x 51.75 in. H (maximum, adjustable)
Shade Dimensions	5.5 in. D x 6 in. H
Ceiling Canopy Diameter	5 in.
Adjustable Height	9.6 in. H to 51.75 in. H (total drop length)
Bulb Base	E26
Max Wattage	60 Watts (or LED equivalent)
Voltage	120 Volts (AC)
Indoor/Outdoor Usage	Indoor
Installation Type	Semi Flush Mount
Item Weight	3.39 pounds

9. Warranty and Support

This product is manufactured to high-quality standards. For specific warranty details, please refer to the documentation included with your purchase or contact Hampton Bay customer support.
For technical assistance, missing parts, or general inquiries, please contact Hampton Bay customer service. Contact information can typically be found on the product packaging or the official Hampton Bay website.

© 2025 Hampton Bay. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question