ECONTROLLY GB005WJSA GB105WJSA

Instruction Manual

ECONTROLLY Replacement Remote Control

Model: GB005WJSA, GB105WJSA

1. Introduction

This instruction manual provides essential information for the proper use and maintenance of your ECONTROLLY Replacement Remote Control, models GB005WJSA and GB105WJSA. This remote is designed as a direct replacement for various Sharp AQUOS TV Remote Control models, including GB004WJSA, GA935WJSA, and GA890WJSA. It offers a seamless experience without the need for complex programming.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

2.2 Initial Use

This replacement remote control is designed for immediate use with compatible Sharp AQUOS TVs.

No programming or pairing is required. Once batteries are installed, the remote should function directly with your television.

3. Operating Instructions

Familiarize yourself with the layout and functions of the remote control buttons.



Figure 1: ECONTROLLY Replacement Remote Control Layout

This image displays the full layout of the ECONTROLLY replacement remote control. Key sections include the power buttons at the top, media playback controls, a numeric keypad, volume and channel controls, and navigation buttons with dedicated app shortcuts at the bottom.

3.1 Button Functions

- **POWER (Red Button):** Turns the TV on or off.
- **DISPLAY / POWER (SOURCE):** Displays information or cycles through input sources.
- **TV / STB / DVD-VCR / AUDIO:** Selects the corresponding device mode.
- **Media Playback Controls:** Includes Rewind, Play, Fast Forward, Previous Track, Stop, Next Track, Pause, and REC (Record).
- **OPTION / SLEEP / AUDIO / FREEZE:** Accesses various TV options, sets sleep timer, changes audio tracks, or freezes the screen.
- **Numeric Keypad (0-9, . , ENT):** Enters channel numbers or other numerical inputs.
- **CC (Closed Caption) / AV MODE / VIEW MODE / FLASHBACK:** Controls closed captions, changes AV mode, adjusts view mode, or returns to the previous channel.
- **MUTE:** Mutes or unmutes the TV audio.
- **VOL (+/-):** Adjusts the volume level.
- **CH (Up/Down Arrows):** Changes TV channels.
- **INPUT:** Cycles through available input sources.
- **3D:** Activates or deactivates 3D mode (if supported by TV).
- **MENU:** Opens the TV's main menu.
- **Smart Central:** Accesses Smart Central features (if supported by TV).
- **Navigation Pad (Up, Down, Left, Right, ENTER):** Navigates through menus and confirms selections.
- **EXIT:** Exits the current menu or function.
- **RETURN:** Returns to the previous screen or menu.
- **FAVORITE CH:** Accesses favorite channels.
- **FAV APP (1, 2):** Shortcut buttons for favorite applications.
- **NETFLIX:** Direct access to the Netflix application.
- **Color Buttons (A-Red, B-Green, C-Blue, D-Yellow):** Used for specific functions within menus or applications as indicated on screen.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using abrasive cleaners, solvents, or alcohol, as these can damage the remote's surface and internal components.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote is not responding.	Dead or incorrectly inserted batteries. Obstruction between remote and TV's IR sensor. Remote is out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the TV.
Certain buttons are not working or are sticking.	Dirt or debris under the button. Internal component issue.	Clean the remote surface. If buttons are physically stuck, gently press them repeatedly. If the issue persists, the remote may need replacement.
Remote works intermittently.	Low battery power. Interference from other electronic devices.	Replace batteries. Ensure no strong light sources (like direct sunlight or fluorescent lights) are interfering with the TV's IR sensor.

6. Specifications

- **Brand:** ECONTROLLY
- **Model Numbers:** GB005WJSA, GB105WJSA
- **Compatible TV Brands:** Sharp AQUOS (specific models listed in product description)
- **Connectivity Technology:** Infrared (IR)
- **Power Source:** 2 x AAA Batteries (not included)
- **Product Dimensions:** 9 x 3 x 2 inches
- **Item Weight:** 2 ounces
- **Special Feature:** Ergonomic design

7. Warranty and Support

Specific warranty information for this ECONTROLLY replacement remote control is not provided in this manual. For details regarding warranty coverage or technical support, please refer to the product packaging or contact the seller/manufacturer directly through their official channels.
For a list of compatible TV models, please refer to the product description where this remote was purchased or consult the manufacturer's website.

© 2024 ECONTROLLY. All rights reserved.