Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine LN19C350D1D, LN32C350D1V, LN32C350D1DXZABK10, LN40E550F7FXZACS02, UN32D4003BD

JustFine Replacement Remote Control Instruction Manual

Compatible with Samsung LN19C350D1D, LN32C350D1V, LN32C350D1DXZABK10, LN40E550F7FXZACS02, UN32D4003BD HD Plasma LCD LED TVs

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your JustFine replacement remote control. This remote is designed to be compatible with various Samsung HD Plasma LCD LED TV models, ensuring a seamless replacement experience.

Please read this manual thoroughly before using the remote control.

Setup

1. Battery Installation

The remote control requires AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Back view of the remote control with the battery compartment. To install batteries, slide the cover down and insert two AAA batteries according to polarity markings.

2. Initial Use

This replacement remote control is pre-programmed and does not require any additional setup or programming. Once batteries are installed, it is ready for immediate use with compatible Samsung TV models.

Operating Instructions

Point the remote control directly at your Samsung TV's infrared receiver. Ensure there are no obstructions between the remote and the TV.

- **Power Button:** Turns the TV on or off.
- **Channel Buttons (CH+/CH-):** Changes the TV channel up or down.
- **Volume Buttons (VOL+/VOL-):** Increases or decreases the TV volume.
- **Mute Button:** Mutes or unmutes the TV sound.
- **Number Buttons (0-9):** Directly selects TV channels.
- **Menu/Settings Button:** Accesses the TV's main menu or settings.
- **Navigation Buttons (Up, Down, Left, Right, Enter):**Navigates through TV menus and confirms selections.
- **Source/Input Button:** Changes the input source (e.g., HDMI1, AV).

The maximum effective operating range for this remote control is approximately 10 meters (33 feet).

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are installed correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared receiver.
  - Ensure you are within the effective operating range (approximately 10 meters).
- **Some buttons not working:**
  - This remote is a direct replacement and should function for all standard TV operations. If specific buttons are unresponsive, ensure the TV model is listed as compatible.
  - Try replacing the batteries.

Specifications

Brand	JustFine
Compatible Devices	Television (Samsung HD Plasma LCD LED TVs)
Connectivity Technology	Infrared
Max Number of Supported Devices	1
Controller Type	Button Control

Maximum Range	10 meters (33 feet)
Battery Type	AAA (Not included)
Item Weight	2.72 ounces
Compatible Samsung TV Models	LN19C350D1D, LN32C350D1V, LN32C350D1DXZABK10, LN40E550F7FXZACS02, UN32D4003BD

Warranty and Support

This product is sold with a money-back guarantee and hassle-free return policy. It includes a 30-day quality warranty from the date of purchase.

If you encounter any problems or have questions regarding your remote control, please contact us via email for assistance. We are committed to resolving any issues you may experience.

© 2026 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01LW8BIB2

More documents and user manuals: **https://manuals.plus/**