Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine SG_B01LW9SAYE_US

Instruction Manual for JustFine Replacement Remote Control

Compatible with Samsung BD-FM51C, BD-HM59C, BD-JM51, BD-JM57C/ZA, BD-JM57ZA Blu-Ray DVD Disc Players

Product Overview

This manual provides essential information for the operation and maintenance of your JustFine replacement remote control. This remote is designed as a direct replacement for various Samsung Blu-Ray DVD Disc Player models, ensuring seamless functionality without the need for complex programming.
The remote is pre-programmed to work with compatible Samsung Blu-Ray DVD Disc Players. It is important to note that this remote cannot be reprogrammed.

Setup and Battery Installation

To begin using your replacement remote control, you will need to install two AAA batteries (not included). Follow the steps below for proper battery installation:

1. **Locate the Battery Compartment:** The battery compartment is located on the back of the remote control.
2. **Open the Battery Cover:** Gently slide the battery cover downwards or press the release tab (if present) and lift the cover. Some covers may require firm pressure to open.
3. **Insert Batteries:** Insert two new AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment. Incorrect insertion can prevent the remote from functioning.
4. **Close the Battery Cover:** Slide the battery cover back into place until it clicks securely.





Figure 1: Rear view of the remote control, indicating the location of the battery compartment.

Once batteries are installed, the remote is ready for use with your compatible Samsung Blu-Ray DVD Disc Player.

Operating Instructions

This replacement remote control is pre-programmed for immediate use with the following Samsung Blu-Ray DVD Disc Player models:

- BD-FM51C
- BD-HM59C
- BD-JM51
- BD-JM57C/ZA
- BD-JM57ZA
- BDFM51/ZA
- BDH5900
- BDJ5100E/ZA
- BDJ5900E/ZA
- BDJM51ZA

Simply point the remote control towards your Blu-Ray DVD Disc Player and press the desired function button. No additional pairing or setup is required.



Figure 2: Front view of the remote control, displaying all functional buttons.

Key Functions:

- **Power Button ( ):** Turns the Blu-Ray player on or off.
- **Number Pad (0-9):** Used for direct track selection or inputting numerical data.
- **Volume Control (VOL +/-):** Adjusts the volume of the connected audio system (if supported by the player).
- **Navigation Buttons (Up, Down, Left, Right, Enter):** Used to navigate menus and select options.
- **Play/Pause (► /):** Controls media playback.
- **Stop ( ):** Stops media playback.
- **Fast Forward/Rewind (►► / ◄◄):** Skips forward or backward through media.
- **Skip Track (►►| / |◄◄):** Skips to the next or previous track/chapter.
- **Disc Menu:** Accesses the main menu of the disc.
- **Title Menu/Popup:** Accesses the title menu or pop-up menu of the disc.
- **Home:** Returns to the player's home screen.
- **Subtitle:** Toggles subtitles on/off or cycles through available subtitle tracks.
- **Audio:** Cycles through available audio tracks.
- **Tools:** Accesses additional tools or settings.
- **Info:** Displays information about the current content.
- **Return:** Goes back to the previous screen or menu.
- **Exit:** Exits the current menu or function.
- **Color Buttons (A, B, C, D):** These buttons provide access to specific functions depending on the disc or player menu.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as they can damage the remote's finish or buttons.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact. Dropping the remote can cause internal damage or button malfunction.

Troubleshooting

If you experience issues with your remote control, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Remote is not responding.	Dead or incorrectly installed batteries.	Replace batteries with new AAA batteries, ensuring correct polarity (+/-).
Remote only works intermittently.	Low battery power; obstruction between remote and player; remote sensor on player is blocked.	Replace batteries. Ensure a clear line of sight between the remote and the Blu-Ray player. Clean any dust or debris from the player's remote sensor.
Specific buttons are not working.	Dirt or debris under the button; internal malfunction.	Clean the remote surface around the buttons. If the issue persists, the remote may have an internal fault.

Problem	Possible Cause	Solution
Remote does not control the Blu-Ray player.	Incompatible player model; remote malfunction.	Verify your Blu-Ray player model is listed as compatible. This remote is pre-programmed and cannot be reprogrammed for other devices. If compatible, contact support.

If these steps do not resolve the issue, please refer to the "Warranty and Support" section for further assistance.

Specifications

Feature	Detail
Product Model Number	SG_B01LW9SAYE_US
Brand	JustFine
Compatible Devices	Samsung BD-FM51C, BD-HM59C, BD-JM51, BD-JM57C/ZA, BD-JM57ZA, BDFM51/ZA, BDH5900, BDJ5100E/ZA, BDJ5900E/ZA, BDJM51ZA Blu-Ray DVD Disc Players
Power Source	2 x AAA Batteries (not included)
Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	2.39 ounces
Color	Black
Special Feature	Ergonomic design

Warranty and Support

Your JustFine replacement remote control comes with a **30-day quality warranty** and is sold with a **money-back guarantee**, ensuring a hassle-free return process if you encounter any issues.
For any problems, questions, or support inquiries, please contact us directly via email. Our customer service team is ready to assist you.
Please note that batteries and a physical instruction manual are not included with the product package.

© 2024 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01LW9SAYE

More documents and user manuals: **https://manuals.plus/**