Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine LYSB01LWEWVR2

JustFine Replacement Remote Control User Manual

For LG TV Models: 42LV5400-UB, 47LK550, 55LV5400, 55LW5600UAAUSYLJR, 60PZ950

1. Introduction

This manual provides essential instructions for the JustFine Replacement Remote Control. This remote is designed to be compatible with various LG TV models, including 42LV5400-UB, 47LK550, 55LV5400, 55LW5600UAAUSYLJR, and 60PZ950. It functions as a direct replacement and typically requires no programming; simply insert batteries to begin operation.

2. Setup and Battery Installation

To begin using your JustFine Replacement Remote Control, follow these simple steps for battery installation:

1. **Locate the Battery Compartment:** Turn the remote control over. The battery compartment cover is located on the back of the remote.
2. **Open the Cover:** Gently slide the battery compartment cover downwards or press the latch (if present) and lift the cover off.
3. **Insert Batteries:** Insert two AAA batteries (not included) into the compartment. Ensure the positive (+) and negative (-) terminals of the batteries align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.
4. **Close the Cover:** Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image 1: Rear view of the remote control, highlighting the battery compartment. This shows where to insert the AAA batteries for operation.

Once batteries are installed, the remote control is ready for immediate use with your compatible LG TV. No additional programming is required.

3. Operating Instructions

The JustFine Replacement Remote Control provides full functionality for your compatible LG TV. Below is a general overview of common button functions:





Image 2: Front view of the remote control, displaying all buttons and their labels. This image helps identify the various controls for TV operation.

- **Power (●):** Turns the TV on or off.

- **Input:** Selects the video input source (HDMI, AV, Component, etc.).
- **TV:** Switches to TV mode.
- **Number Buttons (0-9):** Directly select channels.
- **VOL (+/-):** Adjusts the volume level.
- **CH (▲/▼):** Changes channels up or down.
- **MUTE:** Mutes or unmutes the TV audio.
- **Navigation Pad (◀ ▲ ▶ ▼):** Navigates through menus and options.
- **ENTER:** Confirms selections in menus.
- **BACK** / **EXIT:** Returns to the previous screen or exits the current menu.
- **SMART TV** / **HOME:** Accesses the Smart TV interface or Home menu.
- **Color Buttons (Red, Green, Yellow, Blue):** Functionality varies depending on the TV model and current application.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.

Point the remote control directly at the TV's infrared receiver for optimal performance. Ensure there are no obstructions between the remote and the TV.

4. Maintenance

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
- **Cleaning:** To clean the remote, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage.

5. Troubleshooting

If you experience issues with your JustFine Replacement Remote Control, refer to the following common solutions:

- **Remote is not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are pointing the remote directly at the TV.
  - Verify that the TV is powered on.
- **Some buttons are not working:**
  - This remote is pre-programmed for specific LG TV models. Ensure your TV model is listed as compatible.
  - Clean the remote's surface, especially around the unresponsive buttons, to remove any dirt or debris that might be interfering.
- **Remote range is reduced:**
  - Batteries may be low. Replace them.
  - Ensure there are no strong light sources (like direct sunlight or bright fluorescent lights) interfering with the infrared signal.

6. Specifications

Brand	JustFine
Model Number	LYSB01LWEWVR2
Compatible Devices	LG Televisions (42LV5400-UB, 47LK550, 55LV5400, 55LW5600UAAUSYLJR, 60PZ950)
Connectivity Technology	Infrared
Power Source	2 x AAA Batteries (not included)
Product Dimensions	8 x 2 x 0.5 inches (approx.)
Item Weight	2.72 ounces (approx.)

7. Warranty and Support

This product is sold with a 30-day quality warranty. For any issues or inquiries regarding your JustFine Replacement Remote Control, please contact the seller directly for assistance.

© 2023 JustFine. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01LWEWVR2

More documents and user manuals: **https://manuals.plus/**