Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine LYSB01LWJJ4B6-ELECTRNCS

Instruction Manual for JustFine Replacement Remote Control

Model: LYSB01LWJJ4B6-ELECTRNCS

1. Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your JustFine Replacement Remote Control. This remote is designed as a direct replacement for various Philips TV models, offering seamless functionality without the need for complex programming.

1.1. Compatibility

This replacement remote control is compatible with the following Philips TV models:

- 19PFL3403D/27
- 32MF337B/27E
- 37MF437B37E
- 42PFL7422D/37
- 47PFL5422D/37
- 52PFL3603D/27E
- 32PFL5322D37E
- 32PFL3403D27

It is pre-programmed and does not require additional setup for these models. Simply insert batteries to begin operation.

2. Product Features

- Direct replacement for specified Philips TV models.
- Pre-programmed for immediate use; no additional programming required.
- Infrared (IR) connectivity for reliable signal transmission.
- Compact and lightweight design for comfortable handling.

3. Setup

3.1. Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Front view of the remote control, showing all buttons and layout.



Figure 2: Back view of the remote control, showing the battery compartment area.

4. Operating Instructions

This remote control functions identically to your original Philips TV remote. Point the remote directly at your television's infrared receiver for optimal performance.

4.1. Basic Functions

- **Power Button (●):** Turns the TV on or off.
- **Volume Up/Down (VOL +/-):** Adjusts the sound volume.
- **Channel Up/Down (CH +/-):** Changes the TV channel.
- **Mute Button:** Mutes or unmutes the TV sound.
- **Number Buttons (0-9):** Directly select channels.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.

- **Menu Button:** Accesses the TV's main menu.
- **Exit Button:** Exits the current menu or on-screen display.
- **Source Button:** Selects input sources (HDMI, AV, etc.).
- **Back Button:** Returns to the previous screen or menu.

Refer to your Philips TV's original user manual for specific functions and menu navigation details.

5. Maintenance

5.1. Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials, as they may damage the remote's surface or internal components.

5.2. Storage

When not in use for extended periods, store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If storing for several months, it is recommended to remove the batteries to prevent leakage and potential damage to the remote.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote and the TV's IR receiver.
  - Confirm the remote is pointed directly at the TV.
- **Specific buttons not working:**
  - Clean the button area with a soft cloth to remove any debris.
  - If the issue persists after replacing batteries, the remote may be faulty.
- **Limited range:**
  - Ensure batteries are fresh.
  - Reduce distance between remote and TV.
  - Remove any objects blocking the signal path.

If troubleshooting steps do not resolve the issue, please refer to the "Warranty and Support" section for further assistance.

7. Specifications

Feature	Detail
Brand	JustFine
Model Number	LYSB01LWJJ4B6-ELECTRNCS

Connectivity Technology	Infrared (IR)
Compatible Devices	Television (Specific Philips models)
Max Number of Supported Devices	1
Special Feature	Pre-programmed
Product Dimensions	11.51 x 3.99 x 3.51 cm
Item Weight	77.11 g

8. Warranty and Support

This JustFine replacement remote control comes with a 30-day quality warranty and a money-back guarantee, ensuring your satisfaction. Hassle-free returns are available if you encounter any issues.

For any problems, questions, or support inquiries, please contact us via email. Our customer service team is ready to assist you.
Contact: support@justfine.com

© 2024 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01LWJJ4B6

More documents and user manuals: **https://manuals.plus/**