Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine 8541714121

JustFine Replacement Remote Control Instruction Manual

Model: 8541714121

Introduction

This manual provides instructions for the JustFine Replacement Remote Control, designed for various Sony Home Theater Audio/Video Receiver AV Systems. This remote is pre-programmed and requires no additional setup beyond battery installation. It is compatible with models such as STR-KM5000, RM-AAU024, HTSS2300, 1-480-589-11, STR-DG720, and HTD-DW7000.

Setup

1. Battery Installation

The remote control operates on AAA batteries. Batteries are not included with this product and must be purchased separately.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover off.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Back view of the remote control with the battery compartment visible. This is where you will insert the AAA batteries.

Once batteries are installed, the remote is ready for use. No programming is required.

Operating Instructions

This remote control functions identically to the original remote for your compatible Sony Home Theater Audio/Video Receiver AV System.

- **Power On/Off:** Press the **POWER** button to turn your system on or off.
- **Volume Control:** Use the **VOLUME +** and **VOLUME -** buttons to adjust the audio level.
- **Input Selection:** Press the designated input buttons (e.g., **DVD**, **CD**, **TUNER**) to switch between audio/video sources.
- **Navigation:** Use the arrow buttons and **ENTER** button for menu navigation and selection.
- **Playback Controls:** Utilize buttons such as **PLAY**, **PAUSE**, **STOP**, **REWIND**, and **FAST FORWARD** for media playback.

Ensure there is a clear line of sight between the remote control and the infrared sensor on your Sony Home Theater system for optimal performance. The maximum effective range is approximately 10 meters (33 feet).

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, or immerse it in water.

Troubleshooting

Problem	Solution
Remote is not responding.	• Check if the batteries are inserted correctly with the correct polarity (+/-). • Replace old batteries with new AAA batteries. • Ensure there are no obstructions between the remote and the receiver's IR sensor. • Verify that the remote is pointed directly at the receiver.
Some functions do not work.	• Confirm that your Sony Home Theater system model is listed as compatible. • Some advanced functions specific to the original remote might not be supported by a replacement remote. Refer to your system's original manual for specific function details.
Remote works intermittently.	• This often indicates low battery power. Replace the batteries. • Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the IR signal.

Specifications

Brand: JustFine

Model Number: 8541714121

Compatible Devices: Sony Home Theater Audio/Video Receiver AV Systems (STR-KM5000, RM-AAU024, HTSS2300, 1-480-589-11, STR-DG720, HTD-DW7000)

Connectivity Technology: Infrared (IR)

Battery Type: 2 x AAA (not included)

Maximum Range: Approximately 10 meters (33 feet)

Special Feature: Ergonomic design, Pre-programmed

Item Weight: 3.2 ounces

Warranty and Support

This product is sold with a money-back guarantee and a 30-day quality warranty. For any issues or support inquiries, please contact the seller directly.
Seller: JustFine
Please refer to your purchase documentation for specific contact information or return procedures.

© 2024 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01LX79V9P

More documents and user manuals: **https://manuals.plus/**