JustFine 4330958162

JustFine Replacement Remote Control Instruction Manual

Compatible with Samsung Smart LED HDTV Models UN40H5203, UN46H6201AF, UN55H6203AF, UN65H6203BF, UN65H6203BFXZA

1. Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your JustFine replacement remote control. This remote is designed to be compatible with specific Samsung Smart LED HDTV models, offering a direct replacement for your original remote without requiring complex programming.

Please read this manual thoroughly before using the remote control to ensure proper functionality and to avoid any operational issues.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Important: Ensure batteries are inserted with correct polarity. Incorrect installation can damage the remote control.

2.2 Initial Use

This JustFine replacement remote control is pre-programmed for the specified Samsung Smart LED HDTV models. No additional programming or setup is required. Once batteries are installed, the remote is ready for immediate use.



Image 1: The JustFine replacement remote control. This image shows the sleek black design of the remote, highlighting its ergonomic shape and the central navigation/play button.

3. Operating the Remote Control

The remote control provides standard functions for navigating and controlling your Samsung Smart LED HDTV. Point the remote directly at the TV's infrared receiver for optimal performance.

3.1 Basic Functions

- **Power Button:** Turns the TV on or off.
- **Volume Up/Down:** Adjusts the TV's audio level.
- **Channel Up/Down:** Changes the TV channel.
- **Mute Button:** Silences the TV audio.
- **Navigation Pad (Up/Down/Left/Right):** Used to move through menus and selections.

- **Enter/OK Button:** Confirms selections or opens menus.
- **Back/Return Button:** Returns to the previous screen or menu.
- **Smart Hub/Home Button:** Accesses the TV's Smart Hub or home screen.

Refer to your Samsung TV's user manual for specific functions related to its Smart features and menu navigation.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's performance diminishes or stops working. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these may damage the remote's surface or internal components.

4.3 Storage

When storing the remote control for extended periods, remove the batteries to prevent leakage, which can cause damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

If you experience issues with your remote control, please refer to the following common troubleshooting steps:

- **Remote not responding:**
  - Check if the batteries are correctly installed with the proper polarity.
  - Replace the batteries with fresh ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Make sure you are within the effective range of the TV's infrared receiver.
- **Specific buttons not working:**
  - This remote is pre-programmed and cannot be reprogrammed. If specific buttons are unresponsive, ensure the remote is compatible with your exact TV model.
  - Clean the remote control as described in Section 4.2 to remove any debris that might be obstructing button presses.
- **TV not listed as compatible:**
  - This remote is designed for specific Samsung Smart LED HDTV models. If your TV model is not listed in the compatibility information, the remote may not function correctly or at all.

6. Specifications

Brand	JustFine
Model Number	4330958162
Compatible Devices	Samsung Smart LED HDTV (Models: UN40H5203, UN46H6201AF, UN55H6203AF, UN65H6203BF, UN65H6203BFXZA)

Connectivity Technology	Infrared
Battery Type	2 x AAA (not included)
Button Quantity	25
Item Weight	2.72 ounces

7. Warranty and Support

This product comes with a 30-day quality warranty. For any issues or support inquiries, please contact the seller directly through your purchase platform. Please have your order details and product model number (4330958162) available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question