Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Samsung T580

Samsung Galaxy Tab A T580 10.1-inch Tablet User Manual

Model: T580 | Brand: Samsung

Introduction

The Samsung Galaxy Tab A T580 is a versatile 10.1-inch tablet designed for digital entertainment and productivity. It features a vibrant WUXGA display, a powerful Octa-core processor, and a long-lasting battery. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.

What's in the Box

Upon unboxing your Samsung Galaxy Tab A T580, verify that all components are present:

- Samsung Galaxy Tab A T580 10.1-inch Tablet
- 32GB microSD card
- Charging Adapter
- USB Cable
- Quick Start Guide

Setup

1. Initial Charging

Before first use, fully charge your tablet. Connect the USB cable to the tablet's charging port and the adapter, then plug the adapter into a power outlet. The battery indicator on the screen will show charging progress.

2. Powering On/Off

To power on, press and hold the Power button located on the side of the tablet until the Samsung logo appears. To power off, press and hold the Power button, then select 'Power off' from the options.



Image: Side view of the Samsung Galaxy Tab A T580, highlighting the power button, volume controls, and the microSD card slot for memory expansion.

3. Initial Setup Wizard

Follow the on-screen instructions to complete the initial setup. This includes selecting your language, connecting to a Wi-Fi network, and signing in with your Google account. A Google account is required to download apps from the Google Play Store.

4. Inserting a MicroSD Card

Locate the microSD card slot on the side of the tablet. Gently insert the provided 32GB microSD card into the slot until it clicks into place. This expands the tablet's storage capacity.

Operating Instructions

1. Navigation and Gestures

- **Home Button:** Press to return to the home screen.
- **Back Button:** Tap to go back to the previous screen.
- **Recent Apps Button:** Tap to view and switch between recently used applications.
- **Swipe:** Use your finger to swipe across the screen to navigate between home screens, menus, and content.
- **Pinch-to-Zoom:** Use two fingers to zoom in or out on images, web pages, and maps.



Image: Front view of the Samsung Galaxy Tab A T580, showcasing its 10.1-inch display with the home screen and various application

icons.

2. Connecting to Wi-Fi

Go to **Settings** > **Connections** > **Wi-Fi**. Select your desired network from the list and enter the password if prompted. Once connected, the Wi-Fi icon will appear in the status bar.

3. Downloading Applications

Access the Google Play Store app from your home screen or app drawer. Browse or search for apps, then tap 'Install' to download and install them on your tablet.

4. Using the Camera

The tablet features an 8MP rear camera and a 2MP front camera. Open the Camera app to take photos or record videos. Tap the screen to focus and press the shutter button to capture.

5. Media Playback

Use the pre-installed Gallery app to view photos and videos. For music, use the Play Music app or other downloaded media players. The 10.1-inch WUXGA display (1920 x 1200 resolution) provides a clear viewing experience.

Maintenance

1. Battery Care

To maximize battery life (up to 10 hours of average use), avoid extreme temperatures. For optimal performance, use the original charging accessories. Periodically allow the battery to discharge fully before recharging.

2. Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials, which can damage the display or finish.

3. Software Updates

Your tablet runs on Android 6.0 (Marshmallow) and may receive updates to newer Android OS versions. Regularly check for and install software updates to ensure optimal performance and security. Go to **Settings** > **Software update**.

4. Storage Management

The tablet comes with 16GB of internal storage. Utilize the included 32GB microSD card for additional storage of photos, videos, and documents. Regularly clear unnecessary files and uninstall unused apps to free up space.

Troubleshooting

Device Not Turning On

- Ensure the battery is charged. Connect the tablet to its charger for at least 30 minutes.
- Perform a soft reset by holding the Power button and Volume Down button simultaneously for about 10-15 seconds.

Wi-Fi Connection Issues

- Restart your Wi-Fi router and the tablet.
- Forget the network in Wi-Fi settings and reconnect.
- Ensure you are within range of the Wi-Fi signal.

Apps Crashing or Freezing

- Close and reopen the app.
- Clear the app's cache and data in **Settings** > **Apps**.
- Ensure the app is updated to its latest version.
- If issues persist, consider uninstalling and reinstalling the app.

Slow Performance

- Close unused background apps.
- Clear cache data regularly.
- Ensure sufficient storage space is available.
- Restart the tablet periodically.

Specifications

Feature	Detail
Model Number	SM-T580NZKMXAR
Screen Size	10.1 Inches
Display Resolution	1920 x 1200 (WUXGA)
Processor	1.6 GHz Exynos 7870 Octa-Core
RAM Memory	2 GB
Internal Storage	16 GB
Expandable Storage	microSD (up to 256GB, 32GB card included)
Operating System	Android 6.0 Marshmallow (upgradable)
Rear Camera	8 MP
Front Camera	2 MP
Battery Capacity	7300 mAh (approx. 10 hours average life)
Connectivity	802.11 a/b/g/n/ac Wi-Fi, Bluetooth, GPS
Ports	USB-C, 3.5mm Headphone Jack
Weight	0.01 Ounces (approx. 525g)

Warranty and Support

Warranty Information

This Samsung Galaxy Tab A T580 comes with a **90-day limited warranty**. Please retain your proof of purchase for any warranty claims. The warranty covers manufacturing defects but typically excludes damage caused by misuse, accidents, or unauthorized modifications.

Customer Support

For further assistance, technical support, or warranty inquiries, please refer to the official Samsung support website or contact their

customer service. You can find detailed support resources, FAQs, and contact information on the Samsung website.

Online Support: Visit www.samsung.com/us/support/

Phone Support: Refer to your region's Samsung support contact numbers available on their website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01LXDJHNB

More documents and user manuals: **https://manuals.plus/**