JustFine AK59-00123A

JustFine AK59-00123A Remote Control User Manual

MODEL: AK59-00123A

Introduction

This manual provides instructions for the JustFine AK59-00123A replacement remote control. This remote is designed to be compatible with various Samsung BD Blu-Ray DVD Player models, offering a direct replacement experience without the need for complex programming.
Compatible Samsung Blu-Ray DVD Player Models include: BD-D5500/ZC, BDD7500B, BDD5800, BD-D700, BD-D6500/ZV, BDD5700ZC.

Setup

1. Battery Installation

The remote control requires batteries for operation. Batteries are not included with the remote. Please follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image Description: The back of the AK59-00123A remote control is shown, featuring a textured black surface. A rectangular battery compartment cover is visible in the lower half, designed for easy access to insert or replace batteries. There is also a small symbol indicating proper disposal of electronic waste.

2. Initial Use

This remote control is pre-programmed and does not require any additional setup or programming for the

listed compatible Samsung Blu-Ray DVD Players. Once batteries are installed, it is ready for immediate use.

Operating Instructions

The AK59-00123A remote control provides full functionality for your compatible Samsung Blu-Ray DVD Player. Below is a guide to its primary buttons and their functions.



Image Description: The front of the AK59-00123A remote control is displayed, featuring a black body with numerous grey, red, blue, and green buttons. Key sections include power buttons at the top, a numeric keypad, playback controls (play, pause, stop, fast forward, rewind), navigation arrows, menu buttons, and dedicated buttons for Netflix, Smart Hub, and volume/channel controls at the bottom.

- **POWER (Red Button, Top Left):** Turns the Blu-Ray player on or off.

- **TV POWER (Red Button, Top Right):** Controls the power of a connected TV (if compatible).
- **SOURCE (Button, Top Right):** Changes the input source on a connected TV.
- **BONUSVIEW:** Accesses BonusView features on Blu-Ray discs.
- **Numeric Keypad (0-9):** Used for direct track selection, chapter selection, or entering numbers.
- **SUBTITLE:** Toggles subtitles on/off or selects subtitle tracks.
- **AUDIO:** Selects audio tracks or audio modes.
- **Playback Controls (Rewind, Play, Fast Forward, Stop, Pause):** Standard media playback functions.
- **DISC MENU:** Accesses the main menu of the disc.
- **MENU:** Opens the player's system menu.
- **TITLE MENU:** Accesses the title menu of the disc.
- **POPUP:** Displays a pop-up menu.
- **TOOLS:** Accesses quick settings or tools menu.
- **INFO:** Displays information about the current content.
- **Navigation Buttons (Up, Down, Left, Right, Enter):** Used to navigate menus and select options.
- **RETURN:** Goes back to the previous screen or menu.
- **EXIT:** Exits the current menu or function.
- **Color Buttons (A, B, C, D):** Functionality varies depending on the disc or application.
- **NETFLIX:** Direct access to the Netflix application.
- **SMART HUB:** Direct access to Samsung Smart Hub.
- **SEARCH:** Initiates a search function.
- **VOL +/-:** Adjusts the volume level.
- **MUTE:** Mutes or unmutes the audio.
- **CH ^/v:** Changes channels (if controlling a TV).

Maintenance

Cleaning the Remote Control

To clean your remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the remote's surface or internal components.

Battery Replacement

If the remote control becomes unresponsive or its range decreases, the batteries may need to be replaced. Refer to the 'Battery Installation' section for instructions on how to replace the batteries.
Remove batteries if the remote will not be used for an extended period to prevent potential leakage and damage.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote control and the Blu-Ray player's infrared sensor.
  - Ensure you are within the effective range of the Blu-Ray player.

- **Specific buttons not working:**
  - Clean the remote control as described in the Maintenance section, as dirt or debris might be interfering with button contacts.
  - If only certain buttons are unresponsive, and battery replacement does not help, the remote may be faulty.
- **Remote controls TV instead of Blu-Ray player:**
  - Ensure you are pressing the correct power/source buttons for the Blu-Ray player, not the TV specific ones.

If issues persist after following these steps, please contact customer support.

Specifications

- **Model Number:** AK59-00123A (Also known as 4330958168)
- **Brand:** JustFine
- **Compatible Devices:** Samsung BD Blu-Ray DVD Players (BD-D5500/ZC, BDD7500B, BDD5800, BD-D700, BD-D6500/ZV, BDD5700ZC)
- **Connectivity Technology:** Infrared (IR)
- **Max Number of Supported Devices:** 1 (Specific to the Blu-Ray player)
- **Special Feature:** Ergonomic design
- **Product Dimensions:** 4.53 x 1.57 x 1.38 inches
- **Item Weight:** 2.72 ounces
- **ASIN:** B01LXN61FJ
- **Date First Available:** September 25, 2016

Warranty Information

This product comes with a 30-day quality warranty. Additionally, it is sold with a money-back guarantee and hassle-free return policy. Please retain your proof of purchase for any warranty claims.

Customer Support

Should you encounter any problems or have questions regarding your JustFine AK59-00123A remote control, please do not hesitate to contact us. You can reach our support team by emailing the seller directly.
For the fastest assistance, please provide your order number and a detailed description of the issue.