Seagate ST5000LM000

Seagate Barracuda 2.5in 5TB SATA Internal Hard Drive User Manual

Model: ST5000LM000

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your Seagate Barracuda 2.5-inch 5TB SATA internal hard drive. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. Safety Information

Observe the following safety precautions to prevent damage to the drive and ensure user safety:

- **Electrostatic Discharge (ESD) Protection:** Always handle the drive by its edges. Wear an anti-static wrist strap or touch a grounded metal object before handling the drive to discharge static electricity.
- **Physical Handling:** Avoid dropping or subjecting the drive to physical shock. Hard drives contain delicate moving parts.
- **Power Supply:** Ensure your system's power supply meets the drive's power requirements.
- **Ventilation:** Ensure adequate airflow around the drive to prevent overheating.

3. Setup and Installation

Follow these steps to install your Seagate Barracuda internal hard drive:

3.1 Physical Installation

1. **Prepare Your System:** Power off your computer and disconnect it from the power outlet. Open the computer case.
2. **Locate a Drive Bay:** Identify an available 2.5-inch drive bay in your computer case.
3. **Mount the Drive:** Carefully slide the hard drive into the drive bay. Secure it with screws if required by your case design.
4. **Connect Cables:**
    - Connect one end of a SATA data cable to the drive's SATA data port and the other end to an available SATA

port on your motherboard.

- Connect a SATA power cable from your power supply unit (PSU) to the drive's SATA power port.



Figure 1: Back view of the drive, illustrating the circuit board.



Figure 2: Side view showing the SATA data and power connectors.







Figure 3: Detailed view of the SATA data and power ports.

3.2 System Recognition and Formatting

After physical installation, the drive needs to be recognized and prepared by your operating system:

1. **Power On:** Close your computer case and reconnect the power. Turn on your computer.
2. **Access Disk Management (Windows):**
    - Right-click on the Start button and select "Disk Management."
    - The new drive should appear as "Unallocated Space."
3. **Initialize and Format:**
    - Right-click on the unallocated space of the new drive and select "Initialize Disk." Choose GPT (GUID Partition Table) for drives larger than 2TB.
    - After initialization, right-click the unallocated space again and select "New Simple Volume." Follow the wizard to create a partition and format the drive (NTFS is recommended for Windows).
4. **For macOS/Linux:** Use Disk Utility (macOS) or GParted/fdisk (Linux) to initialize and format the drive according to your operating system's requirements.

4. Operating the Drive

The Seagate Barracuda 5TB drive is designed for reliable data storage. Here are key operational aspects:

4.1 Data Storage and Transfer

Once formatted, the drive will appear as a new volume in your operating system. You can now drag and drop files, install applications, or use it as a backup destination. The SATA 6Gb/s interface ensures efficient data transfer rates.

4.2 Performance Considerations

This drive operates at 5400 RPM and utilizes Shingled Magnetic Recording (SMR) technology. While offering high capacity in a compact 2.5-inch form factor, SMR drives are generally optimized for read-heavy workloads and archival storage. For write-intensive applications, performance may vary. The 128MB cache helps to mitigate some performance impacts during typical usage.

Your browser does not support the video tag.

Video 1: A review discussing the Seagate Barracuda HDD, providing insights into its characteristics and suitability for various uses.

5. Maintenance

Proper maintenance ensures the longevity and reliability of your hard drive:

- **Regular Backups:** Regularly back up important data to another storage device. No storage device is infallible.
- **Disk Health Monitoring:** Use disk utility software (e.g., Seagate SeaTools) to monitor the drive's health and perform diagnostic tests.
- **Avoid Physical Shock:** Protect the drive from impacts and vibrations, especially when in operation.
- **Temperature Control:** Ensure your system maintains a stable operating temperature to prevent overheating.

6. Troubleshooting

If you encounter issues with your hard drive, consider the following:

6.1 Drive Not Detected

- **Check Cables:** Ensure both the SATA data and power cables are securely connected to the drive and motherboard/PSU.
- **BIOS/UEFI Settings:** Verify that the SATA port the drive is connected to is enabled in your system's BIOS/UEFI settings.
- **Disk Management:** Check Disk Management (Windows) or Disk Utility (macOS/Linux) to see if the drive is recognized but uninitialized or unformatted.
- **Try Different Port/Cable:** Test the drive with a different SATA port on the motherboard and/or a different SATA cable.

6.2 Slow Performance

- **Check Disk Usage:** High background processes or simultaneous large file transfers can slow down performance.
- **Fragmentation:** For older operating systems or heavily used drives, disk fragmentation can occur. Consider defragmenting the drive (not applicable for SSDs or modern OS with TRIM).
- **SMR Characteristics:** As an SMR drive, sustained write operations, especially when the drive is nearly full, can lead to temporary performance degradation.
- **System Resources:** Ensure your system has sufficient RAM and CPU resources.

6.3 Unusual Noises

Clicking, grinding, or repetitive beeping sounds are indicators of potential drive failure. Immediately back up any accessible data and consider replacing the drive.

7. Specifications

Key technical specifications for the Seagate Barracuda 2.5in 5TB SATA Internal Hard Drive (Model ST5000LM000):



Figure 4: Product label with model and serial information.

Feature	Specification
Model Number	ST5000LM000
Digital Storage Capacity	5 TB
Hard Disk Form Factor	2.5 Inches
Hard Disk Interface	SATA 6 GB/s
Hard Disk Rotational Speed	5400 RPM
Cache Memory Installed Size	128 MB
Read Speed	140 Megabytes Per Second

Feature	Specification
Compatible Devices	Desktop (Note: Due to 15mm thickness, verify compatibility with laptops/enclosures)
Item Weight	190 Grams
Enclosure Material	Aluminum/Glass
GTIN / UPC	763649078969

8. Warranty Information

Seagate products are covered by a limited warranty. For specific warranty terms and conditions applicable to your region and product, please refer to the official Seagate website or the warranty documentation included with your purchase.

9. Support

For further assistance, technical support, or to download utilities like SeaTools, please visit the official Seagate support website:

Seagate Support

You can also verify your product's authenticity and warranty status using the serial number on the drive label:

Seagate Product Verification

© 2026 Seagate Technology. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question